


SL-T30ME

RMT-218

SERVICE MANUAL



September, 1983

711B CHASSIS

Refer to separate adjustment manual,
part number 9-972-269-81

SPECIFICATIONS

System

Video recording system

Video signal Rotary two-head helical scanning
CCIR standards, PAL and SECAM colour
EIA standards, NTSC4.43 colour (playback only)

Aerial input 75-ohm, asymmetrical aerial socket

Channel coverage VHF: Western European channels E2-12
UHF: Western European channels E21-68
(Up to 8 programmes can be preset.)

RF output signal UHF channels E30 to E39 (variable)
75 ohms, unbalanced

Video

Input

VIDEO IN: BNC connector
1.0 V ± 1.0 V (p-p)
75 ohms, unbalanced,
sync negative

Output

VIDEO OUT: BNC connector
1.0 V (p-p) ± 0.1 V (p-p)
75 ohms, unbalanced,
sync negative

Horizontal resolution 260 lines

Signal-to-noise ratio Colour: Better than 40 dB
B/W: Better than 43 dB

Audio

Input

AUDIO IN: phono jack
47 kilohms, -10 dBs (0 dBs = 0.775 V rms)

Output

AUDIO OUT: phono jack
Load impedance less than 10 kilohms
-10 dBs with 47 kilohms load, unbalanced

Frequency response 50 Hz to 10 kHz

Signal-to-noise ratio 40 dB

Audio distortion Less than 4% at 400 Hz

Tape transport

Tape speed

PAL, SECAM
18.73 mm/sec.
NTSC4.43 (playback only)
20 mm/sec. (II)
13.3 mm/sec. (III)

Maximum recording time

2 hours 10 min. (with Sony L-500 cassette)
3 hours 15 min. (with L-750)

Fast forward/rewind time

Under 4 min. (with L-500)

Timer

Clock

Crystal lock

Time indication

24-hour cycle

Timer setting

Only for recording
2 events/week, adjustable for any day or for
all 7 days of the week

Power back-up

Back-up duration of 5 minutes at one time

General

Power requirements 110-240 V ac $\pm 10\%$, 50/60 Hz

Power consumption 38 W

Storage temperature -20°C to +65°C (-4°F to +149°F)

Operating temperature

5°C to 40°C (41°F to 104°F)

Dimensions

Approx. 430 $\times$ 105 $\times$ 392 mm (w/h/d)
(17 $\times$ 4 $\frac{1}{4}$ $\times$ 15 $\frac{1}{2}$ inches)

Weight

including projecting parts and controls
Approx. 9.4 kg (20 lbs 12 oz) net

— Continued on next page —



Consumer
VIDEO



VIDEO CASSETTE RECORDER

SONY®

Accessories supplied

75-ohm coaxial cable for recorder to TV connection	1
Remote Commander RMT-218 with two IEC designation R6 batteries	1
Screwdriver for RF channel adjustment	1
Dust cover	1
Demonstration cassette	1

Design and specifications subject to change without notice.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

TABLE OF CONTENTS

1. GENERAL

1-1. PRECAUTIONS	3
1-2. LOCATION AND FUNCTION OF CONTROLS	4
1-3. CONNECTIONS	6
1-4. ADJUSTING THE TV	7
1-5. TV STATION PRESETTING	8
1-6. CLOCK SETTING	9
1-7. TV PROGRAMME RECORDING	10
1-8. PLAY BACK	12
1-9. TIMER ACTIVATED RECORDING	14
1-10. CAMERA RECORDING	16

2. DISASSEMBLY

2-1. REMOVAL OF THE CASE AND FRONT PANEL	17
2-2. REMOVAL OF THE TM-48, TM-49 BOARDS	18
2-3. REMOVAL OF THE FU-19 BOARD	18
2-4. REMOVAL OF POWER BLOCK	19
2-5. REMOVAL OF THE RF-14 BOARD	19
2-6. REMOVAL OF FL CASSETTE COMPARTMENT ASSEMBLY	20
2-7. REMOVAL OF MECHANICAL CHASSIS BLOCK	20
2-8. REMOVAL OF REEL ASS'Y	22
2-9. REMOVAL OF THE YR-1 BOARD	22
2-10. REMOVAL OF THE SS-20 BOARD	23
2-11. REMOVAL OF THE TA-15 BOARD	23
2-12. REMOVAL OF THE SD-3 BOARD	24
2-13. REMOVAL OF THE CL-7 BOARD	24
2-14. INTERNAL VIEWS	25
2-15. BOARD ARRANGEMENT	26

DIAGRAMS

OVERALL BLOCK DIAGRAM	27
VIDEO BLOCK DIAGRAM	30
SERVO BLOCK DIAGRAM	33
SYSTEM CONTROL BLOCK DIAGRAM	35
SYSTEM CONTROL CIRCUIT AND MECHANISM BLOCK INTERFACE	37
CAPSTAN PHASE SYSTEM TIMING CHART	43
AUDIO BLOCK DIAGRAM	47
AUDIO LEVEL DIAGRAM	49
TIMER BLOCK DIAGRAM	51
SR-15 POWER BLOCK DIAGRAM	53

SR-15S POWER BLOCK DIAGRAM	55
TUNER BLOCK DIAGRAM	57
FRAME SCHEMATIC DIAGRAM	59
RF-14, YR-1 WIRING DIAGRAM	64
RF-14 SCHEMATIC DIAGRAM	67
YR-1 SCHEMATIC DIAGRAM	69
CL-7, SD-3 WIRING DIAGRAM	74
CL-7, SD-3 SCHEMATIC DIAGRAM	79
SS-20, FU-19, VR-3, CS-3, CS-4, RD-6, RD-7, TR-13, CAPSTAN MOTOR, REEL MOTOR WIRING DIAGRAM	84
CAPSTAN MOTOR, REEL MOTOR SCHEMATIC DIAGRAM	90
SS-20, FU-19, VR-3, CS-3, CS-4, RD-6, RD-7, TR-13 SCHEMATIC DIAGRAM	91
TA-15, TM-48, TM-49, N, FU-20 WIRING DIAGRAM	96
TA-15, TM-48, TM-49, N, FU-20 SCHEMATIC DIAGRAM	101
SR-15 POWER BLOCK WIRING DIAGRAM	105
SR-15 POWER BLOCK SCHEMATIC DIAGRAM	107
SR-15S POWER BLOCK WIRING DIAGRAM	109
SR-15S POWER BLOCK SCHEMATIC DIAGRAM	111
SEMICONDUCTORS	113
VHF/UHF SCHEMATIC DIAGRAM	116

4. EXPLODED VIEW

(1) FRONT PANEL AND CABINET ASSEMBLIES	117
(2) TUNER, TIMER AND POWER ASSEMBLIES	118
(3) FRONT LOADING ASSEMBLY	119
(4) REEL MOTOR ASSEMBLY	120
(5) CHASSIS ASSEMBLY (1)	121
(6) CHASSIS ASSEMBLY (2)	122
(7) DRUM AND S LOADING ASSEMBLY	123
(8) HARDWARE LIST	124

5. ELECTRICAL PARTS LIST

6. REMOTE COMMANDER

SECTION 1

GENERAL

1-1. PRECAUTIONS

On safety

- This unit operates on 110–240 V ac, 50/60 Hz. No voltage adjustment is necessary.
- Should any solid object or liquid fall into the cabinet, turn off the unit and have it checked by qualified personnel before operating it any further.
- To disconnect the mains lead (ac power cord), pull it out by the plug. Never pull the lead itself.

On installation

- Allow adequate air circulation to prevent internal heat build-up. Do not place the unit on surfaces (rugs, blankets, etc.) or near materials (curtains, draperies) that may block the ventilation grille.
- Do not install the unit near heat sources such as radiators or air ducts or in a place subject to direct sunlight, excessive dust, mechanical vibration or shock.
- The unit is designed for operation in a horizontal position. Do not install it in an inclined position.
- Keep the unit and cassette tapes away from equipment with strong magnets, such as a microwave oven, large loudspeakers, etc.
- Do not place a heavy object on the cassette compartment window.
- Do not install the unit near an AM receiver, since a noise may be heard when listening to the AM programme.

On operation

- When the unit is not to be used for a long period, turn the power off to conserve energy and to extend the useful life of your unit.
- Remove and store video cassettes after recording or playback.
- This unit should not be operated for two hours after being transported from a cold to a hot environment to avoid condensation from forming on the head drum. Condensation can cause the tape to stick to the head drum, resulting in damage to the tape.

On cleaning

Clean the cabinet, panel and controls with a dry soft cloth. Do not use a moistened cloth or any type of solvent, such as alcohol or benzene, which might damage the finish.

On repacking

Do not throw away the carton and packing materials. They make an ideal container in which to transport the unit. When shipping the unit to another location, repack it as illustrated on the carton.

On colour broadcasting systems

This machine is designed to record and playback using the PAL colour standard. Recording and playback of video sources based on other colour systems cannot be guaranteed.

If you have any questions about this unit, contact your Sony dealer.


SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the B+ voltage to see it is at the values specified.

1-2. LOCATION AND FUNCTION OF CONTROLS

Front



1 REMOTE SENSOR and pilot lamp

Detects the remote control signal transmitted from the supplied Remote Commander. The pilot lamp blinks when any button on the Commander is pressed.

2 Colour system indicators

Show the colour system of a TV programme being received or a tape being played back.

3 ON/STANDBY button and lamp

Press to turn on the unit. The lamp will light up. Press again to turn it off.

The timer section will continue to operate and the time will be displayed even if the ON/STANDBY button is off so long as the ac power cord is connected to the wall outlet.

4 Cassette compartment and CASSETTE INSIDE lamp

Insert a cassette after turning on the recorder. The lamp lights up when a cassette is inside.

5 EJECT button

Press to remove the cassette. This button does not function when the recorder is turned off.

6 Function buttons

▶ **PLAY** button: Press to play the tape back.

◀◀ **REW** button: Press to rewind the tape. Also used for the reverse picture search and skip scan operation.

▶▶ **FF** button: Press to advance the tape rapidly. Also used for the forward picture search and skip scan operation.


■ **STOP** button: Press to stop the tape.

|| **PAUSE** button: Press to stop the tape for a moment during recording or playback. A still picture will be seen during playback. Press again to release the pause mode.

7 TRACKING control

If streaks or snow appears during the playback of a tape recorded on another recorder, turn this knob to obtain the best possible picture.

8 Timer setting section in the front panel compartment



Ⓐ **CLOCK SET** button: Press to set the clock.

Ⓑ **CLEAR** button: Press to clear the timer programme memorized.

Ⓒ **TIMER SET** button: Press to set the turn-on/off time of a recording.


Ⓓ **DAY** button: Press to set the turn-on day of a recording.

Ⓔ **HOURL, 10 MIN and MIN** buttons: Press to set the turn-on/off time of a recording.

Ⓕ **CHANNEL** button: Press to select the TV channel to be recorded by the timer.

Ⓖ **TIMER REC** button: Press to set the recorder in the timer recording stand-by mode.

9 Other controls and jacks in the front panel compartment



Ⓐ **CLOCK/COUNTER** button: Press to set the display to the tape counter. To reset to clock, press it again.


Ⓑ **RESET** button: Press to set the tape counter reading to "0000".

Ⓒ **COLOR SYSTEM SELECT** switch: Usually set the switch to AUTO. The unit will be set to the appropriate colour system mode according to the TV programmes being received or the tape being played back. The associated indicator will light up. If the signal is too weak or has been improperly recorded so that the indicator does not function correctly or the picture on TV is distorted, manually set the switch to PAL, SECAM or NTSC.

Ⓓ **CAMERA PAUSE** jack (special mini jack): For camera recording, connect an ac adaptor to this jack.

Ⓔ **AUDIO IN** jack (phono type): Connect to the audio output of a camera or another video cassette recorder.

Ⓕ **VIDEO IN** jack (BNC type): Connect to the video output of a camera, another video cassette recorder, etc.




10 RECORD button and lamp

Press to start recording. The lamp will light up.

11 CHANNEL buttons

Press the + button for a higher channel number and the - button for a lower channel number. The selected channel number will appear in the display window.

12 Display window



a Day of the week indication: Shows the day of the week on which the timer-activated recording will take place.


b Event number

c Turn-on and turn-off setting indications: The "●" mark shows you are setting the turn-on time and the "○" mark shows the turn-off time.

d Time and counter display: Usually shows the present time. When the CLOCK/COUNTER button is pressed to COUNTER, the display shows the counter number.

e Channel number: Shows the channel number selected with the CHANNEL + or - button.

13 Tuning compartment



13 Tuning control: With the supplied tuning aid, turn until the desired station is properly tuned in.

14 Band-select switch: Using the supplied tuning aid, set to V_L (channels E2 through E4), V_H (channels E5 through E12), or U (channels E21 through E68) according to the channel to be tuned in.

15 Tuning aid: Use to select the band and to turn the tuning control. The indication at its end shows the approximate position within the selected band.

16 AFT switch: When presetting TV stations, set the switch to OFF. After presetting, set the switch to ON. The automatic fine tuning circuit locks in the signal and maintains a sharp picture.


17 Tape speed indicators (effective only for NTSC443)

The $\text{18} \frac{1}{2}$ / $\text{18} \frac{1}{2}$ indicator illuminates according to the tape speed recorded.

18 TIMER REC lamp

Lights when the TIMER REC button behind the front panel is pressed to set the recorder in the stand-by mode. It remains lit till the timer recording is finished.

Rear



16 RF CHANNEL screw

If there is interference on the factory preset channel for RF output and the signal of this recorder be displayed clearly on the TV screen, adjust this screw with the screwdriver attached on the back of the turning compartment cover.

17 AERIAL OUT socket

Connect the aerial input of the TV receiver using the supplied cable.

18 DX/LOCAL switch

Normally set this switch to DX. If the TV signal is very strong, set the switch to LOCAL.

19 AERIAL IN socket

Connect the aerial cable.

20 MULTI OUT connector (8-pin)

Connect to the multi input of a colour monitor or a TV receiver equipped with an 8-pin connector.

21 VIDEO OUT jack (BNC type)

Connect to the video input of another video cassette recorder or a video monitor.

22 AUDIO OUT jack (phono type)

Connect to the audio input of a video monitor or a video cassette recorder.

23 Mains lead


1-3. CONNECTIONS

Notes

- Unplug each unit from the mains outlet before making the following connections.
- Make sure the connections are secure. A loose connection may cause a noisy picture.

CONNECTING A TV

- 1 Remove the aerial cable from its socket in the back of the TV. Then connect the aerial cable to the AERIAL IN socket at the rear of the recorder.
- 2 Connect the aerial input of the TV to the AERIAL OUT socket of the recorder, using the supplied cable.
- 3 Connect the recorder and the TV to the mains supply with their own mains leads.
- 4 Turn on the power of each unit.



Now the recorder is set up to intercept all signals from the aerial on their way to the TV. The recorder then passes on the signals to the TV. This is why you can record a programme while it is being shown on the TV, or while the TV is showing another programme, or even when the TV is turned off.

Notice for customers in a strong signal area

The recorder has a booster to assure stable TV reception. However, in areas near TV stations, where the TV signal is very strong, the picture may be affected by the booster. If this happens, set the DX/LOCAL switch on the rear panel to LOCAL.




CONNECTING A COLOUR MONITOR


To obtain a higher-quality picture, connect the unit to a colour monitor, such as the Sony Profeel colour monitor, instead of a conventional TV. The aerial should be connected to the recorder in the same way as a conventional TV.

When using a colour monitor, the following "Adjusting the TV" is not necessary.

Using the audio and video cables



Using a multi-cable



1-4. ADJUSTING THE TV

One of the television channels must be adjusted to receive the signal from the recorder.


- 1 After making the connections, press the ON/STANDBY button.
 - 2 Insert the supplied cassette with the round window to the left.
 - 3 Press the ► PLAY button.
 - 4 Turn on the TV and select a channel which is not being used to receive a TV station. Tune the channel until you see a clear playback picture.
- **Note** that the playback signal is transmitted on a channel between UHF channels 30 and 39.

If the test picture is free of disturbance, the TV adjustment is complete.

If the test picture is not free of disturbance, proceed with the next adjustment.


Whenever you use the video recorder, you should set the TV to the channel selected in this adjustment.

—If you are not sure how to adjust your TV, please refer to the TV's instruction manual or consult your dealer.



If the test picture is not free of disturbance


- 1 Adjust the channel of the TV to a channel between UHF channels 30 and 39 with the tuning control or the fine tuning control on the TV, so that the TV screen shows no picture and so that a steady rustling sound or no sound is heard.
- 2 Play back the cassette again.
- 3 Using the screwdriver attached on the back of the tuning compartment cover, slowly turn the RF CHANNEL screw on the back of the recorder until you see an undistorted picture on the TV screen.
- 4 Now the TV adjustment is complete.



1-5. TV STATION PRESETTING


Once you have tuned your TV to the recorder, the next step is to tune the recorder to all the TV stations that you can receive in your area. Up to 8 TV stations can be preset in any order.

● Make sure that nothing is connected to the input jacks in the front panel compartment.



When the picture appears, slowly turn the tuning control to the right until a herringbone pattern appears in the coloured part of the picture, then turn the control back until the picture is perfectly clear.

To identify the stations, consult a newspaper or TV programme guide.




6 Repeat the same operation for all the other stations.

7 Set the AFT switch to ON and close the tuning compartment. AFT (automatic fine tuning) circuit locks in the signal and maintains a sharp picture.


After presetting the TV stations, you can use the CHANNEL buttons of the recorder to tune in a station for viewing as well as recording.

PRESETTING PROCEDURE

- 1 Set the COLOR SYSTEM SELECT switch to AUTO. If the signal is too weak, set the switch to the position according to the colour system of your area.
- 2 Press the CHANNEL + or - button to select the channel to be preset.
- 3 Open the tuning compartment and set the AFT switch to OFF.
- 4 Using the supplied tuning aid, set the band-select switch corresponding to the selected channel number to one of the three positions:



- 5 Using the other side of the tuning aid, turn the tuning control until the desired station is properly tuned in. The indicator on the top of the tuning aid shows the approximate position in the selected band.



If you keep turning the tuning control clockwise, you will again get to the lowest-numbered station within that band.

1-6. CLOCK SETTING

When you connect the mains lead to a wall outlet, the clock indicates "0:00" with the two dots blinking.

Example: To set the clock to 7:35 p.m. (19:35) on Tuesday*

* Time indication

AM				PM					
12:00 (midnight)	1:00		11:00	12:00 (noon)	1:00	2:00		10:00	11:00
↓	↓		↓	↓	↓	↓		↓	↓
0:00	1:00		11:00	12:00	13:00	14:00		22:00	23:00

Day indication

Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday
↓	↓	↓	↓	↓	↓	↓
1	2	3	4	5	6	7



1 CLOCK SET SET/START 	
2 DAY 	
3 HOUR 	
4 10 MIN 	
5 MIN 	
6 CLOCK SET SET/START With the time signal, press and immediately release, otherwise the clock will not start operating. If you press the CLOCK SET button for more than a second, clock adjustment will be required again.	 The upper dot blinks for the first half of each minute, and the lower dot for the second half.

Zero second adjustment

Press the CLOCK SET button quickly (less than a second).

While the upper dot is blinking, the clock is set to the time displayed 00 second. For example, if the clock time is 7:30, 20 seconds, it is set to 7:30, 00 second.

While the lower dot is blinking, the clock advances one minute and is set to the time displayed 00 second. For example, if the clock time is 7:30, 40 seconds, it is set to 7:31, 00 second.

If you press the CLOCK SET button for more than a second, "0:00" blinks to show that the clock adjustment is required again.

When power has been interrupted for more than 5 minutes, the time indication "0:00" blinks, showing that the clock must be reset. If power has been interrupted for less than 5 minutes, the displayed time remains correct.

The DAY, HOUR, 10 MIN and MIN buttons can be pressed in two ways:




When you hold a button down, the digits will advance continuously until the button is released.



When you press and immediately release a button, the digits will advance by one.

1-7. TV PROGRAMME RECORDING



RECORDING ONE TV PROGRAMME WHILE VIEWING ANOTHER

You can enjoy one TV programme while recording another TV programme as follows :

1. Start recording the desired TV programme in the usual way.
2. Select the programme you want to view on the TV.

TO STOP RECORDING MOMENTARILY

Press the **|| PAUSE** button. The TV programme can be seen on the TV, but the picture will not be recorded.

To resume recording, press the **|| PAUSE** button again or the **RECORD** button.

To protect the video heads and the tape, the pause mode will be automatically released after about 8 minutes and recording will stop.

CAUTION

Television programmes, films, video tapes and other materials may be copyrighted. Unauthorized recording of such material may be contrary to the provision of the copyright laws.

TO KEEP A RECORDED PROGRAMME FROM BEING ACCIDENTALLY ERASED.

When a new recording is made on a previously recorded cassette, the previous recording will be automatically erased.


To avoid erasing a recording

Break off the safety tab using a screwdriver or similar object.




To re-record on a cassette which has had the safety tab removed

Cover the slot with a piece of plastic tape.



1-8. PLAY BACK




AUTO PLAY To playback from the beginning of the tape after rewinding

Press the ► **PLAY** button and ◀◀ **REW** button simultaneously in the stop mode. The ► **PLAY** button blinks during rewinding. After the tape is completely rewound, it will be automatically played back.


PICTURE SEARCH Viewing the picture at a fast speed to find a particular scene.

During playback mode, keep ►► **FF** button pressed for a fast-speed forward picture and the ◀◀ **REW** button for a fast-speed reverse picture. To resume normal playback, release the button.



SKIP SCAN Viewing the picture momentarily during fast-forward or rewind.


During the fast-forward or rewind mode, keep the same mode button pressed. To resume the normal rewind or fast forward mode, release the button.



- Streaks will appear in the picture search and skip scan modes.


When playing back a tape recorded on another machine

If streaks or snow appears, adjust the **TRACKING** control for the best possible picture. Return the control to the centre position after playing back the tape.




USE OF THE TAPE COUNTER

Turn on the power and press the **CLOCK/COUNTER** button to display the counter reading in the display window. To return the display to the present time, press the **CLOCK/COUNTER** button again.



Before starting recording or playback, press the **RESET** button to set the counter to "0000". By noting the counter reading at the desired point, you can easily find that point later by referring to the counter.



Write the counter readings you want to remember on the label of the cassette.

Normal rewinding will stop at the tape counter's "0000" position. To rewind the tape further, press the ◀◀ button again. With automatic rewinding from the tape end or for "auto play", the tape will not stop at the counter's "0000" position.

Notes

- The counter reading is automatically reset to zero when a cassette is newly inserted.
- While the power is off, the display shows the present time, regardless of the **CLOCK/COUNTER** setting.
- The counter reading will be retained in the memory even after the power is turned off, as long as the cassette is in the cassette compartment.
- The tape counter does not operate when a blank, unrecorded tape is played.


1-9. TIMER-ACTIVATED RECORDING

You can make one or two recordings within 7 days even when you are not at home. These recordings are identified as event 1 or event 2.

Check before setting the timer

- Is the clock set to the correct day and correct time?
- Timer setting can only be made after the clock has been set.
- Is a cassette inserted in the recorder?
- Is the cassette long enough to record the programmes?
- Does the cassette have a safety tab on the bottom?
- Make sure that nothing is connected to the input jacks in the front panel compartment.
- Is COLOR SYSTEM SELECT switch set correctly?

Example: To record a channel 2 broadcast from 9:00 AM to 11:25 AM on Friday for event 1.



1 Button to be pressed. TIMER SET/ EVENT (CHECK) If the recorder is off, it will be turned on automatically.	Time display The segment to be set will blink. Turn-on indication Shows the event number. Event 1 always appears first.
2 Select the turn-on day. DAY Indication changes as follows : 1234567 (everyday) → 1 (Monday) → 2 (Tuesday)... → 7 (Sunday)	
3 Set the turn-on time. H 10M M	
4 Select the channel to be recorded. CHANNEL	

5 TIMER SET/ EVENT (CHECK)	Turn-off indication Blinks.
6 Set the turn-off time. H 10M M	
7 TIMER REC TIMER REC lamp lights up and the power is turned off. At the preset turn-on time, recording will start automatically and will stop at the preset turn-off time. If the inserted cassette is at its end or does not have the safety tab, the cassette will be automatically ejected.	TIMER REC Present day and time

ONCE THE TIMER REC LAMP HAS LIT UP, NO FUNCTION OF THE RECORDER CAN BE ACTIVATED, except for checking the timer setting.

To operate the recorder after setting the timer for recording, press the TIMER REC button so that the TIMER REC lamp goes off. To reactivate the timer recording standby mode, be sure to press the TIMER REC button again.

To record to the end of the tape

Set the turn-off time to a time after the tape will reach its end.

If the tape reaches the end during the timer recording


The recording will stop and the tape will be rewound to the beginning. Then after about a second, the recorder will be turned off.

To stop the on-going timer recording

Press the TIMER REC button so that the TIMER REC lamp goes off. The unit will be turned off automatically after about a second.

To erase the setting of an event

1. Press the TIMER SET button to display the event to be erased.
2. Press the CLEAR button. This event will be erased from the memory.



When a power interruption occurs before and during timer recording

If the clock shows "0:00" and the dots blink

All the timer settings have been erased. Reset the clock time and the timer settings.

If the clock still shows the correct time but the dots blink

The power has been interrupted for less than 5 minutes.

The timer programmes are retained in the memory and the on-going timer recording will resume when the power is resupplied.

To stop the blinking, press any button in the timer-setting compartment.


ERROR INDICATIONS

If the ● and ○ indications as well as the event numbers blink when the TIMER REC button is pressed...

It means that the setting of these events overlap. Check the settings and eliminate the overlap.

Example :


Timer setting



Even with this error indication, recording can be made.

In this case, the first preset recording continues to its turn-off point and then the next recording begins.

Realized recording



If the turn-on time of the 2 events is the same, recording of event 1 will be made.

TO CHECK THE TIMER SETTING

Press the TIMER SET button. Each time you press the button, the indication will change as follows :

Example : Both event 1 and 2 have been programmed.

Turn-on day and time of event 1 → Turn-off day and time →

Turn-on day and time of event 2 → Turn-off day and time →


Present time

During actual timer recording, only the turn-off time of the event being recorded can be checked.

1-10. CAMERA RECORDING

To produce your own programmes

CONNECTIONS



OPERATION

- Press the ON/STANDBY button to turn on the recorder and insert a cassette.
- Turn on the power switch on the ac adaptor.
- Make the necessary adjustments on the camera. See the instruction manual furnished with the camera.
- Press the RECORD button. Recording will begin.
 - If a camera with a tape run/stop button is used, you can momentarily stop recording and restart it using that button.
 - If any other camera is used, use the button on the recorder or on the Remote Commander to stop the recording momentarily and restart it.
- When the recording is finished, press the button.

To view the picture being recorded on the TV screen

- Turn the connected TV on.
- Select the channel for the video recorder on the TV. The picture being recorded will appear on the TV screen.
- If acoustic feedback (a whistle-like sound) is heard when the microphone sound is recorded, turn the microphone (or the camera, if the microphone is built into the camera) away from the TV or turn down the TV volume.


To record the sound from other audio sources

Connect an audio source, such as a tape recorder, into the AUDIO IN jack.

TAPE COPY

To duplicate a tape, you will need two video recorders; one is to play back the original tape and the other is to record.

- 1 Connect the recorders as illustrated.
- 2 Turn on both recorders.
- 3 Insert the original cassette into the recorder for playback.
- 4 Insert a blank cassette into the recorder for duplicating.
- 5 Set the INPUT SELECT switch to LINE if the recorder for duplicating is provided with such switch.
- 6 Set the recorder for playback into the playback mode.
- 7 Set the recorder for duplicating into the record mode.




CAUTION

Television programmes, films, video tapes and other materials may be copyrighted. Unauthorized duplication of such material may be contrary to the provision of the copyright laws.

SECTION 2 DISASSEMBLY


2-1. REMOVAL OF THE CASE AND FRONT PANEL

- 1) Remove the four screws ①.
- 2) Remove the upper case ② in the direction shown by the arrow ①A.
- 3) Remove the eight screws ③ and the lower case ④ in the direction shown by the arrow ①B.
- 4) Remove the two screws ⑤ and the front panel ⑥ in the direction shown by the arrow ①C.




2-2. REMOVAL OF THE TM-48, TM-49 BOARDS

- 1) Pull out the five connectors ①.
- 2) Pull out connector. ②.
- 3) Remove the two screws ③ and the TM-49 board.
- 4) Remove the two screws ④ and the TM-48 board.




2-3. REMOVAL OF THE FU-19 BOARD

- 1) Remove the three screws ①.
- 2) Disconnect the two connectors ② from the SS-20 board.




2-4. REMOVAL OF POWER BLOCK

- 1) Remove the four screws ①.
- 2) Remove the screw ②.
- 3) Remove the seven connectors ③ (CN1-7).
- 4) Remove the power block in the direction shown by the arrow ④.




2-5. REMOVAL OF THE RF-14 BOARD

- 1) Remove the screw ①.
- 2) Pull out the three connectors ②.




2-6. REMOVAL OF FL CASSETTE COMPARTMENT ASSEMBLY

- 1) Loosen the loading belt ① exerting a force on the threading motor.
- 2) Remove the five mounting screws ② of the FL cassette compartment.
- 3) Disconnect the exposed connector from the CS-3 board (CN-7) on the FL cassette compartment.
- 4) Lift the FL cassette compartment assembly in the direction shown by the arrow to remove.




2-7. REMOVAL OF MECHANICAL CHASSIS BLOCK

- (1)
- 1) Stand the set with its power block section down.
 - 2) Remove the two P. C board holders ①, holding the SS-20 board.
 - 3) Pull out the two connectors ②.
 - 4) Remove the SS-20 board in the direction shown by the arrow A.




(2)

- 1) Pull out the connector ① (CN-7)
- 2) Pull out the seventeen connectors from the SS-20 board and pull out the rest one from TA-15 board.
- 3) Remove the seven screws ② and the mechanical chassis block.




2-8. REMOVAL OF REEL ASS'Y

- 1) Remove four screws ①.
- 2) Remove the reel block ②.




2-9. REMOVAL OF THE YR-1 BOARD

- 1) Stand the set with the power block side on the bottom.
- 2) Remove the two screws ① and the panel connector ②.
- 3) Remove the P. C board holders ③, holding the YR-1 board.
- 4) Swing open the YR-1 board in the direction shown by the arrow (A) and rest it on a cassette.




2-10. REMOVAL OF THE SS-20 BOARD

- 1) Stand the set with the right side panel on the bottom.
- 2) Remove the screw ①.
- 3) Remove the two P. C Board Holders ②, holding the SS-20 board.
- 4) Swing open the SS-20 board in the direction shown by the arrow ④ and rest it on a cassette.




2-11. REMOVAL OF THE TA-15 BOARD

- 1) Remove the screw ①.
- 2) Remove the two P.C Board Holders ② holding the TA-15 board.
- 3) Remove the TA-15 board in the direction shown by the arrow ④.




2-12. REMOVAL OF THE SD-3 BOARD

- 1) Refer to (2-11) REMOVAL OF THE TA-15 BOARD.
- 2) Pull out the five connectors ① from the SD-3 board.
- 3) Remove the screw ② and the SD-3 board.




2-13. REMOVAL OF THE CL-7 BOARD

- 1) Refer to (2-9) REMOVAL OF THE YR-1 BOARD.
- 2) Remove the screw ①.
- 3) Remove the two P.C. Board Holders ②, holding the CL-7 board.
- 4) Swing open the CL-7 board in the direction shown by the arrow ③ and rest on a cassette.




2-14. INTERNAL VIEWS


— Top Side —



— Bottom Side —





2-15. BOARD ARRANGEMENT







SECTION 3 DIAGRAMS


OVERALL BLOCK DIAGRAM








SERVO BLOCK DIAGRAM



SYSTEM CONTROL BLOCK DIAGRAM



SYSTEM CONTROL CIRCUIT AND MECHANISM BLOCK INTERFACE

MODE SIGNALI/O Pin No.			EJECTED	LOADING	THREADING	STOP	UN- THREADING	UN- LOADING	FF	REW	PB	PB- PAUSE	PICTURE SEARCH		REC	REC- PAUSE	TIMER REC	FR SEARCH	
													CUE	REV				CUE	REV
REC PROOF	I	IC1 13 pin	H	H	H/L	H/L	H/L	H	H/L	H/L	H/L	H/L	H/L	H/L	L	L	L	H/L	H/L
C-IN	I	IC1 14pin	H	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
C-ON	I	IC1 15pin	H	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
C-DWN	I	IC1 16pin	H	H	L	L	L	H	L	L	L	L	L	L	L	L	L	L	L
LD END	I	IC1 17pin	H	H	H	L	H	H	L	L	L	L	L	L	L	L	L	L	L
UL END	I	IC1 18pin	L	L	H	H	H	L	H	H	H	H	H	H	H	H	H	H	H
UNBRK S	O	IC1 21pin	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H
UNBRK H	O	IC1 22pin	H	H	L	H	L	H	L	L	L	L	L	L	L	H	L	L	L
PINCH S	O	IC1 23pin	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H
PINCH H	O	IC1 24pin	H	L	H	H	H	L	H	H	L	L	L	L	L	H	L	H	H
LOAD	O	IC1 5pin	H	L	L	H	H	H	H	H	H	H	H	H	H	H	H	H	H
UNLOAD	O	IC1 6pin	H	H	H	H	L	L	H	H	H	H	H	H	H	H	H	H	H

SYSTEM CONTROL CIRCUIT AND REMOTE CONTROL/TIMER CIRCUIT INTERFACE

MODE SIGNALI/O Pin No.			STOP	FF	REW	PB	PB- PAUSE	PICTURE SEARCH		REC	REC- PAUSE	TIMER REC	FR SEARCH	
								CUE	REV				CUE	REV
RT ROST	I	IC1 28pin												
RTSD	I	IC1 31pin												
COUNTER RESET	I	IC1 19pin												
SSD	O	IC1 33pin												
SC	O	IC1 30pin												
REC READY	O	IC1 42pin	H/L	H	H	H	H	H	H	H	H	L	H	H

SYSTEM CONTROL CIRCUIT AND

MODE			SIGNAL	I/O	Pin No.
	I	IC1 34	EJECT-K	I	IC1 34
	I	IC1 35	STOP-K	I	IC1 35
	I	IC1 36	FF-K	I	IC1 36
	I	IC1 37	REW-K	I	IC1 37
	I	IC1 38	PB-K	I	IC1 38
	I	IC1 39	PAUSE-K	I	IC1 39
	I	IC1 40	REC-K	I	IC1 40
	O	IC1 44	FF	O	IC1 44
	O	IC1 45	REW	O	IC1 45
	O	IC1 46	PB	O	IC1 46
	O	IC1 47	PAUSE	O	IC1 47
	O	IC1 48	REC	O	IC1 48
	O	IC1 4	C-IN	O	IC1 4

SYSTEM CONTROL CIRCUIT AND

MODE			SIGNAL	I/O	Pin No.
	I	IC1 9	TEND*1	I	IC1 9
	O	IC1 45	REW	O	IC1 45

*1 "L" at tape end.

REW	PB	PB· PAUSE	PICTURE SEARCH		REC	REC· PAUSE	TIMER REC	FR SEARCH	
			CUE	REV				CUE	REV
H/L	H/L	H/L	H/L	H/L	L	L	L	H/L	H/L
L	L	L	L	L	L	L	L	L	L
L	L	L	L	L	L	L	L	L	L
L	L	L	L	L	L	L	L	L	L
L	L	L	L	L	L	L	L	L	L
H	H	H	H	H	H	H	H	H	H
H	H	H	H	H	H	H	H	H	H
L	L	L	L	L	L	H	L	L	L
H	H	H	H	H	H	H	H	H	H
H	L	L	L	L	L	H	L	H	H
H	H	H	H	H	H	H	H	H	H
H	H	H	H	H	H	H	H	H	H

REC	REC· PAUSE	TIMER REC	FR SEARCH	
			CUE	REV
H	H	L	H	H

SYSTEM CONTROL CIRCUIT AND FUNCTION BLOCK INTERFACE

SIGNAL	MODE		STOP	FF	REW	PB	PB· PAUSE	PICTURE SEARCH		REC	REC· PAUSE	TIMER REC	FR SEARCH	
	I/O	Pin No.						CUE	REV				CUE	REV
EJECT·K	I	IC1 34pin	H	H	H	H	H	H	H	H	H	H	H	H
STOP·K	I	IC1 35pin	H	H	H	H	H	H	H	H	H	H	H	H
FF·K	I	IC1 36pin	H	H	H	H	H	L	H	H	H	H	L	H
REW·K	I	IC1 37pin	H	H	H	H	H	H	L	H	H	H	H	L
PB·K	I	IC1 38pin	H	H	H	H	H	H	H	H	H	H	H	H
PAUSE·K	I	IC1 39pin	H	H	H	H	H	H	H	H	H	H	H	H
REC·K	I	IC1 40pin	H	H	H	H	H	H	H	H	H	H	H	H
FF	O	IC1 44pin	H	L	H	H	H	L	H	H	H	H	L	H
REW	O	IC1 45pin	H	H	L	H	H	H	L	H	H	H	H	L
PB	O	IC1 46pin	H	H	H	L	L	L	L	H	H	H	L	L
PAUSE	O	IC1 47pin	H	H	H	H	L	H	H	H	L	H	H	H
REC	O	IC1 48pin	H	H	H	H	H	H	H	L	L	L	H	H
C·IN	O	IC1 4pin	L	L	L	L	L	L	L	L	L	L	L	L

SYSTEM CONTROL CIRCUIT AND ITS PERIPHERAL CIRCUIT INTERFACE

SIGNAL	MODE		STOP	FF	REW	PB	PB· PAUSE	PICTURE SEARCH		REC	REC· PAUSE	TIMER REC	FR SEARCH	
	I/O	Pin No.						CUE	REV				CUE	REV
TEND*1	I	IC1 9pin	H	H	H	H	H	H	H	H	H	H	H	H
REW	O	IC1 45pin	H	H	L	H	H	H	L	H	H	H	H	L

*1 "L" at tape end.

SYSTEM CONTROL CIRCUIT AND REEL MOTOR CONTROL CIRCUIT INTERFACE

MODE			EJECTED	LOADING	THREADING	STOP	UN-THREADING	UN-LOADING	FF	REW	PB	PB-PAUSE	PICTURE SEARCH		REC	REC-PAUSE	TIMER REC	FR SEARCH	
													CUE	REV				CUE	REV
SIGNAL	I/O	Pin No.																	
REEL ROT	I	IC1 12pin																	
REEL LOW	O	IC1 58pin	L	L	H	L	H	L	L	L	H	H	L	L	H	H	H	H	H
REEL FWD	O	IC1 59pin	H	H	H	H	L	H	H	L	H	H	H	L	H	H	H	H	L
REEL STOP	O	IC1 60pin	H	H	L	H	L	H	L	L	L	H	L	L	L	H	L	L	L
FF / REW	O	IC1 61pin	H	H	H	H	H	H	L	L	H	H	H	H	H	H	H	L	L
CUE / REV	O	IC1 54pin	H	H	H	H	H	H	H	H	H	H	L	L	H	H	H	H	H
PINCH S	O	IC1 23pin	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H
UNLOAD	O	IC1 6pin	H	H	H	H	L	L	H	H	H	H	H	H	H	H	H	H	H
LOAD	O	IC1 5pin	H	L	L	H	H	H	H	H	H	H	H	H	H	H	H	H	H
REW	O	IC1 45pin	H	H	H	H	H	H	H	L	H	H	H	L	H	H	H	H	L

SYSTEM CONTROL CIRCUIT AND VIDEO CIRCUIT INTERFACE

MODE			STOP (E-E)	FF	REW	PB	PB-PAUSE	PICTURE SEARCH		REC	REC-PAUSE	TIMER REC	FR SEARCH	
								CUE	REV				CUE	REV
SIGNAL	I/O	Pin No.												
V MUTE	O	IC1 56pin	L	L	L	L	L	L	L	L	L	L	L	L
JOG	O	IC1 57pin	H	H	H	H	L	L	L	H	H	H	L	L
REC-PAUSE	O	IC1 53pin	H	H	H	H	H	H	H	L	H	L	H	H
PB OUT	O	IC1 3pin	H	H	H	L	L	L	L	H	H	H	L	L
β III	O	IC1 1pin	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L
FF / REW	O	IC1 61pin	H	L	L	H	H	H	H	H	H	H	L	L
CUE / REV	O	IC1 54pin	H	H	H	H	H	L	L	H	H	H	H	H

SYSTEM CONTROL CIRCUIT AND SERVO CIRCUIT INTERFA

MODE			STOP	FF	REW
SIGNAL	I/O	Pin No.			
CAP ROT	I	IC1 10pin	L	L	L
VD/CTL	I	IC1 29pin		CTL	CTL
DRUM STOP	O	IC1 50pin	H	L	L
CAP STOP	O	IC1 51pin	H	H	H
PB OUT	O	IC1 3pin	H	H	H
REC-PAUSE	O	IC1 53pin	H	H	H
CUE/REV	O	IC1 54pin	H	H	H
CAP FWD	O	IC1 55pin	H	H	H
194 RESET*1	O	IC1 27pin	H	H	H
RF SW PULSE	I	IC1 20pin			

*1 Reset signal for CX194.


SYSTEM CONTROL CIRCUIT AND AUDIO CIRCUIT INTERFA

MODE			STOP (E-E)	FF	REW
SIGNAL	I/O	Pin No.			
A MUTE	O	IC1 41pin	L	L	L
REC-PAUSE	O	IC1 53pin	H	H	H
PB	O	IC1 3pin	H	H	H
PAUSE	O	IC1 47pin	H	H	H
DRUM STOP	O	IC1 50pin	H	L	L


SYSTEM CONTROL CIRCUIT AND DISTINCTION CIRCUIT IN

MODE			STOP (E-E)	FF	REW
SIGNAL	I/O	Pin No.			
PB OUT	O	IC1 3pin	H	H	H
β III	O	IC1 1pin	H/L	H/L	H/L


CAPSTAN PHASE SYSTEM TIMING CHART (REC)...CCIR ONLY




CAPSTAN PHASE SYSTEM TIMING CHART (PB)




CAPSTAN SPEED SYSTEM TIMING CHART




DRUM PHASE SYSTEM TIMING CHART



DRUM SPEED SYSTEM TIMING CHART





PG SIGNAL TIMING CHART



AUDIO BLOCK DIAGRAM

AUDIO LEVEL




TUNER IN (A)

LINE IN (B)

AUDIO LEVEL DIAGRAM (REC)

REC MODE


0dBs=0.775Vrms
f=333Hz
BIAS OSC : STOPPED




AUDIO LEVEL DIAGRAM (PB)

PB MODE

0dBs=0.775Vrms
f=333Hz
BIAS OSC : STOPPED




TIMER BLOCK DIAGRAM




SR-15 POWER BLOCK DIAGRAM

Note: Model identification of POWER BLOCK is indicated by label on it.




SR-15S POWER BLOCK DIAGRAM


Note: Model identification of POWER BLOCK is indicated by label on it.




TUNER BLOCK DIAGRAM




FRAME SCHEMATIC DIAGRAM






YR-1 BOARD (PAL)




Q R S T

Note: Model identification of POWER BLOCK is indicated by label on it.

Note: The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.



YR-1 BOARD (PAL)




— Ref. No. RF-14 BOARD: 1000 series, YR-1 BOARD: 1000 series —

A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---


Note:

- Color code of sleeving over the end of the jacket.










- ○ — : indicates a lead wire mounted on the component side.
- ● — : indicates a lead wire mounted on the printed side.
- ■■■■ : Soldering side
- ■■■■ : B + pattern


DRUM
DSH - 39A - R


[illegible]

[RF-14 BOARD]

[illegible]

【YR-1 BOARD】



[illegible]

IC501 (5), (11) REC

IC503 (16), (17) PB





IC503 (4) PB

IC503 (18) PB


[RF SIGNAL PROCESS]

— Ref. No. RF-14 BOARD: 1000 series —

VIDEO VIDEO



RF-14 BOARD (PAL)



Note:

- All resistors are in ohms, $\frac{1}{6}$ W unless otherwise noted.
- All capacitors are in μ F (p:pF) unless otherwise noted. 50 V or less are not indicated except for electrolytic capacitors.
- All variable and semi-fixed resistors have characteristic curve B, unless otherwise noted.
-  : Nonflamable resistor
-  : Fusible resistor
-  : B + bus.
- The voltage value is a reference value between the grounding when the color bar signal is received from a color bar generator.

The voltage value is measured using a digital tester (10 M Ω /V).

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.


Note:


- All resistors are in ohms, $\frac{1}{2}W$ unless otherwise noted.
- All capacitors are in μF (p:pF) unless otherwise noted. 50 V or less are not indicated except for electrolytic capacitors.
- All variable and semi-fixed resistors have characteristic curve B, unless otherwise noted.
-  : Nonflammable resistor
-  : Fusible resistor
-  : B + bus.
- The voltage value is a reference value between the grounding when the color bar signal is received from a color bar generator.

The voltage value is measured using a digital tester (10 M Ω /V).

When indicating parts by reference number, please include the board name.

YR-1
BOARD







— Ref. No. CL-7 BOARD: 3000 series, SD-3 BOARD: 4500 series —






A B C D E F G H I J K L M N O P

IC Q	IC506	IC505	IC507	IC508	IC504	502 501	506 IC501	503	504	IC Q
D	502,503,504					501				D
ADJ TP	RV501 LV501 501 502									ADJ TP

[SD-3 BOARD]




< > : E-E mode (PAL, SECAM)
< P > : E-E mode (PAL)
< S > : E-E mode (SECAM)
(N) : PB mode (NTSC)



no mark : REC mode
S no mark : REC mode (SECAM)
() : PB mode
(S) : PB mode (SECAM)
(N) : PB mode (NTSC)
(P) : PB mode (PAL)
(N P) : PB mode (NTSC, PAL)

[CL-7 BOARD]








IC	Q	D	ADJ, TP
8, 9, 11, 7, 13, 12, 18	39	17	LV3
	44, 50		RV7
	38	18, 7	CV2
	40, 41		CV2
	56, 43		
	48, 46	9, 8	RV10
	42	5	RV9
	54		RV8
21, 19	55, 58, 24		
	30, 23	8, 7, 3	
	19, 31	2, 1	
	29, 18, 25	16, 9	RV2
2	15		RV1
	5, 4, 14, 10, 17		RV6, RV4
4			LV1, LV2
14	22, 6, 52		
17, 6, 3	59, 21	11	
	12, 20	4	
	53, 49, 37, 47, 51	3	RV5
IC	Q	D	ADJ, TP

Note:
• Color code of sleeving over the end of the jacket.




- : parts extracted from the component side.
- : parts extracted from the conductor side.
- : B+ pattern


[CHROMA SIGNAL PROCESS]

CHROMA CHROMA


[SECAM/PAL/NTSC AUTOMATIC DISCRIMINATION]

— Ref. No. CL-7 BOARD: 3000 series, SD-3 BOARD: 4500 series





CL-7 BOARD (PAL)



SS-20

[SERVO, SYSTEM CONTROL]

FU-19

[CASSETTE CONTROL SWITCH]

VR-3

[TRACKING VOLUME]

CS-3

[CASSETTE OFF SWITCH]

CS-4


[CASSETTE ON SWITCH]

RD-6


[ROTATION DE]

Note:



- Color code of sleeving over the end of the jacket.




- : parts extracted from the component side.
- : parts extracted from the conductor side.
- : Soldering side
- : Component side
- : B+ pattern




[LM-8 BOARD]




[CAPSTAN MOTOR BOARD]




[REEL MOTOR BOARD]




[SS-20 BOARD]





Q, IC	D	ADJ	TP
517 516 518 510,512 509,511 508,513,515 IC508 IC506 IC507 IC505,IC503 IC504 IC512 530 526 519 531 20,19 06,05 01 10,09 08,07 13,14,11 15,12 16 17 18 22 27 31 26 30,25 29 28,24	525 520 516,515 01 02 27 28 518,525 524,505 501 09 04,03 505 507,506 534 IC502 26 43 44 49 47 54,48 50,53 45 IC511 IC510 11 15 12,14 23 10,13	RV511 RV515,RV520 RV516 RV514,RV521 RV505 RV506 RV504 RV507 RV508 RV503 RV501 RV513,RV512	501 502 503 504
Q, IC	D	ADJ	TP



RD-7




[ROTATION DETECTOR]

TR-13


[REEL MOTOR DRIVE]

CAPSTAN MOTOR


REEL MOTOR

[illegible]

SS-20 (SERVO) BOARD





SS-20 (SYSTEM CONTROL) BOARD



SERVO, SYSTEM CONTROL

— Ref. No. CAPSTAN MOTOR BOARD: 5100 series, REEL MOTOR BOARD: 5000 series —



Note:

- All resistors are in ohms, $\frac{1}{6}$ W unless otherwise noted.
- All capacitors are in μ F (p:pF) unless otherwise noted. 50 V or less are not indicated except for electrolytic capacitors.
- All variable and semi-fixed resistors have characteristic curve B, unless otherwise noted.
- : Nonflamable resistor
- : Fusible resistor
- : B + bus.
- The voltage value is a reference value between the grounding when the color bar signal is received from a color bar generator.

The voltage value is measured using a digital tester (10 M Ω /V).

When indicating parts by reference number, please include the board name.

SS-20

[SERVO, SYSTEM CONTROL]

FU-19

[CASSETTE CONTROL SWITCH]

[TRACKING VOLUME]


CS-3


CS-4

[CASSETTE ON SWITCH]

RD-6

— Ref. No. SS-20 BOARD: 2000 series, FU-19 BOARD: 5000 series, VR-3: 9000 series, CS-3, CS-4: 9300 series, RD-6, RD-7: 9200 series,
TR-13 BOARD: 2000 series, CAPSTAN MOTOR BOARD: 5100 series, REEL MOTOR BOARD: 5000 series —





(DTA114ES, DTC143TS, DTC144ES):
sistors.

RD-7


[ROTATION DETECTOR]

TR-13

[REEL MOTOR DRIVE]

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.


When indicating parts by reference number, please include the board name.



— Ref. No. TA-15 BOARD, TUNER: 7000 series, AUDIO: 7500 series, TIMER: 7800 series, TM-48, TM-49 BOARD: 8000 series,


N BOARD: 9600 series, FU-20 BOARD: 5000 series —

TA-15 BOARD





Note:

- Color code of sleeving over the end of the jacket.




- — indicates a lead wire mounted on the component side.
- — indicates a lead wire mounted on the printed side.
- — Soldering side
- — B+ pattern





[MT-6 BOARD]



TO YR-1 BOARD
CN8

AUDIO OUT (G) BLK
AUDIO OUT (Y) RED
AUDIO OUT (X) WHT

FULL ERASE HEAD

AUDIO ERASE HEAD

AUDIO HEAD

AUDIO HEAD (G)

AUDIO HEAD (Y)

ERASE HEAD (X)

ERASE HEAD (Y)

CN504 (WHT)

BLK -05

RED -04

WHT -03

BLK -02

BLK -01

BLK

RED

YEL

BLU

ORG

CN001(YEL)

GND

REG 12V


REG 5V

UNSW'D -26V

UNSW'D -38V

TO POWER BLOCK
CN1

[TA-15 BOARD]





IC	Q	D	ADJ,TP
2	1.2 501 816 3 810 3 501 817 809 808 502 508 803 509	501 1.2 813 812 504 11 503 10 9 8 20-27 807 13-19 804 504,505,506 803 502 808 502 502	LV501 RV502 RV501 TP507 TP506 RV503,TP504 TP804 TP505 TP801 TP501,TP502
803	11 3 811 4 801 6,5 805 803 802	29 805 806,811 7 807 809,810 6,5	TP802 CV801 TP803 RV2,RV1,TP1
IC	Q	D	ADJ,TP

no mark : REC mode
S no mark : REC mode (SECAM)
(: PB mode
(N : PB mode (NTSC)
(NS : PB mode (NTSC,SECAM)
< : E-E mode (PAL,SECAM)
[: PAUSE
PAL : Voltage measured during CH-1 resection.
SECAM NTSC : Voltage measured during CH-2 resection.


— Ref. No. TA-15 BOARD, TUNER: 7000 series, AUDIO: 7500 series, TIMER: 7800 series, TM-48, TM-49 BOARD: 8000 series,

N BOARD: 9600 series, FU-20 BOARD: 5000 series —





Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.



Note:


- All resistors are in ohms, $\frac{1}{8}$ W unless otherwise noted.
- All capacitors are in μ F (p:pF) unless otherwise noted. 50 V or less are not indicated except for electrolytic capacitors.
- All variable and semi-fixed resistors have characteristic curve B, unless otherwise noted.
-  : Nonflammable resistor
-  : Fusible resistor
- ——— : B + bus.
- - - - : B - bus.
- The voltage value is a reference value between the grounding when the color bar signal is received from a color bar generator.

The voltage value is measured using a digital tester (10 M Ω /V).


When indicating parts by reference number, please include the board name.

Note: Model identification of POWER BLOCK is indicated by label on it.


	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
Q							623			624		602		601	
D							633	632	631	630	621		603	602	601
							623		626	625	634	629	628		




MBOARD




RBOARD



DBOARD




CBOARD



Note:

- Color code of sleeving over the end of the jacket.



- indicates a lead wire mounted on the component side.
- indicates a lead wire mounted on the printed side.
- : Soldering side
- : B+ pattern
- : B- pattern

Note: Model by lab

- No mark
- ()
-
- *

SR-15 POWER BLOCK SR-15 POWER BLOCK

SR-15


M

C

D

R

[POWER BLOCK, SWITCHING REGULATOR]



Note: Model identification of POWER BLOCK is indicated by label on it.

- No mark: E-E mode, 220 V 50 Hz
- (): E-E mode, 110 V 50 Hz
- []: Voltages are measured from emitter of Q602
- *: selected to yield optimum performance.

Note:

- All resistors are in ohms, $\frac{1}{8}$ W unless otherwise noted.
- All capacitors are in μ F (p:pF) unless otherwise noted. 50 V or less are not indicated except for electrolytic capacitors.

- All variable and semi-fixed resistors have characteristic curve B, unless otherwise noted.
- []: Nonflammable resistor
- []: Fusible resistor
- : B + bus.
- - - : B - bus.
- The voltage value is a reference value between the grounding when the color bar signal is received from a color bar generator.









The voltage value is measured using a digital tester (10 M Ω /V).

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

Note: Model identification of POWER BLOCK is indicated by label on it.

Q	IC3	51	50	IC2	4	3	SCR1	2	1	Q
IC		6	5		IC1					IC
D	ZD51	ZD50	51	ZD2	50	7	8	4	3	D
		52		9			5			
ADJ			VR2		VR1		10	ZD1	1	ADJ



Note:

- Color code of sleeving over the end of the jacket.


- : indicates a lead wire mounted on the component side.
- : indicates a lead wire mounted on the printed side.
- : B+ pattern
- : B- pattern

SR-15S

[POWER BLOCK, SWITCHING REGULATOR]

SR-15S POWER BLOCK

SR-15S POWER BLOCK



Note: Model identification of POWER BLOCK is indicated by label on it.

- No mark: E-E mode, 220 V 50 Hz
- (): E-E mode, 110 V 50 Hz

Note:

- All resistors are in ohms, 1/8 W unless otherwise noted.
- All capacitors are in μF (p:pF) unless otherwise noted. 50 V or less are not indicated except for electrolytic capacitors.
- All variable and semi-fixed resistors have characteristic curve B, unless otherwise noted.
- : Nonflamable resistor
- : Fusible resistor
- : B + bus.
- : B - bus.
- The voltage value is a reference value between the ground when the color bar signal is received from a color bar generator.

The voltage value is measured using a digital tester (10 M Ω /V).

Note: The components identified by shading and are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

SECTION 4 EXPLODED VIEWS


NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.

- Items marked "▲" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

1. FRONT PANEL AND CABINET ASSEMBLIES



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
1	A-6703-376-A	PANEL BLOCK ASSY, FRONT (N/GOLD)	2	5	3-682-625-00	WINDOW, TAPE	
	A-6703-392-A	PANEL BLOCK ASSY, FRONT (N/RED)	2	6	3-679-380-11	PLATE, ORNAMENTAL	
	A-6703-409-A	PANEL BLOCK ASSY, FRONT (N/SILVER)	2	7	3-682-630-01	LID, PRESET	
2	X-3679-183-0	DOOR ASSY, TIMER (N/GOLD)		8	3-656-301-00	SCREWDRIER, CONTROL	
	X-3679-190-0	DOOR ASSY, TIMER (N/RED)		9	▲ 1-413-161-00	POWER BLOCK (SR-15)	1, 3, 14
	X-3679-209-0	DOOR ASSY, TIMER (N/SILVER)		10	3-682-615-00	PANEL, REAR	
3	▲ 3-679-397-00	COVER, BNC		11	3-682-631-00	PLATE, BOTTOM	
4	X-3679-196-0	CASE ASSY, UPPER (N/GOLD)	5, 6	12	3-703-354-01	SCREW (OS), CASE, CLAW	
	X-3679-191-0	CASE ASSY, UPPER (N/RED)	5, 6	13	3-703-244-00	STOPPER, CORD	
	X-3679-210-0	CASE ASSY, UPPER (N/SILVER)	5, 6	14	1-534-817-12	CORD, POWER	


2. TUNER, TIMER AND POWER ASSEMBLIES



The components identified by shading and mark **▲** are critical for safety. Replace only with part number specified.

No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
51	▲ :3-679-381-00	PLATE, LIGHT GUIDE		75	▲ :3-682-621-00	CASE (MAIN), SHIELD, T	
52	▲ :3-682-645-00	HOUSE, LAMP		76	▲ :3-682-620-00	CASE (UPPER), SHIELD, T	
53	▲ :1-611-071-00	FU-19 BOARD		77	3-670-155-00	LEG	
54	3-682-648-00	KNOB, TRACK CONTROL		78	▲ :4-342-117-00	CASE, SHIELD (MAIN), R	
55	▲ :1-611-073-00	VR-3 BOARD		79	▲ :1-606-794-00	N BOARD	
56	▲ :1-611-070-00	TM-49 BOARD		80	▲ :4-342-118-00	LID, SHIELD CASE, R	
57	▲ :3-682-650-00	HOUSE, INDICATION LAMP		81	▲ :3-682-612-00	CLIP (B), ANCHOR	
58	▲ :1-611-069-00	TM-48 BOARD		82	▲ :3-681-101-00	BRACKET (RIGHT), RBM	
59	▲ :1-611-068-00	TR-13 BOARD		83	▲ :1-464-289-00	BOOSTER MIXER, RF MODULATOR	
60	3-701-754-00	PLATE, INSULATING		84	▲ :3-682-613-00	CLIP (C), ANCHOR	
61	▲ :A-6711-476-A	RF-14 BOARD, COMPLETE	62,63,64	85	▲ :A-6715-194-A	SD-3 BOARD, COMPLETE	
62	▲ :3-682-678-00	CASE (UPPER), SHIELD		86	▲ :A-6711-474-A	YR-1 BOARD, COMPLETE	
63	▲ :3-682-680-00	CASE (MAIN), SHIELD, RF		87	▲ :A-6711-475-A	CL-7 BOARD, COMPLETE	88,89,90
64	▲ :3-682-679-00	CASE (LOWER), SHIELD, RF		88	▲ :3-682-603-00	CASE (LOWER), SHIELD, CL	
65	3-681-186-00	KNOB, TUNING		89	▲ :3-682-602-00	CASE (MAIN), SHIELD, CL	
66	3-682-681-11	COVER, PRESET		90	▲ :3-682-601-00	CASE (UPPER), SHIELD, CL	
67	▲ :A-6721-191-A	TA-15 BOARD, COMPLETE	68,69,70,71,72 73,74,75,76,93	91	▲ :3-682-611-00	CLIP (A), ANCHOR	
68	▲ :3-662-383-00	BAND, RETAINER, TUNER		92	▲ :1-611-072-00	FU-20 BOARD	
69	▲ :1-463-350-00	TUNER (BT-881)		93	▲ :1-611-061-00	MT-6 BOARD	
70	▲ :3-682-677-00	CASE (UPPER), SHIELD, AUDIO		94	▲ :1-555-716-00	CABLE, PIN	
71	▲ :3-682-624-00	CASE (MAIN), SHIELD, AUDIO		95	▲ :A-6715-193-A	SS-20 BOARD, COMPLETE	73,96,97
72	▲ :3-682-676-00	CASE (LOWER), SHIELD, AUDIO		96	▲ :3-682-606-00	CASE (MAIN), SHIELD, SS	
73	▲ :3-655-214-00	CLIP, CABLE		97	▲ :3-682-607-00	CASE (LOWER), SHIELD, SS	
74	▲ :3-682-622-00	CASE (LOWER), SHIELD, T		98	4-308-030-11	WASHER, DOUBLE STICK TAPE	
				99	4-309-378-00	WASHER	


3. FRONT LOADING ASSEMBLY



No.	Part No.	Description	Remark
101	3-679-226-00	GEAR (LEFT), ARM, DRIVING	
102	3-679-145-00	SPRING (LEFT)	
103	3-679-220-00	ARM (LEFT), DRIVING	
104	X-3679-105-0	SHAFT ASSY, GEAR, MIDWAY	
105	3-679-222-00	DOOR, UPPER	
106	X-3679-180-0	DOOR, ASSY LOWER	
107	3-679-137-00	HOLDER, OUTER DOOR	
108	3-679-143-00	ROLLER	
109	3-679-188-00	SPRING, TENSION	
110	3-679-132-00	LEVER (LEFT), PREVENTION	
111	3-679-130-00	LEVER (LEFT), RETAINER, CASSETTE	
112	3-679-288-00	SPRING, TENSION	
113	3-679-135-00	RUBBER, RETAINER, CASSETTE	
114	3-679-128-00	ROLLER (RIGHT), DRIVING	
115	•:X-3679-107-0	PLATE ASSY, SIDE, BASE LEFT	
116	•:3-679-266-00	PLATE, SIDE, LEFT	
117	•:3-679-265-00	PLATE, SIDE, RIGHT	
118	3-679-217-04	GEAR (A), LIMITER	
119	3-679-139-00	SPRING	
120	3-679-215-00	GEAR, WORM	
121	3-679-123-00	SHAFT, GEAR, WORM	
122	3-679-124-00	CAM (CASSETTE OFF)	
123	3-669-480-21	+ PTPWH 2	


No.	Part No.	Description	Remark
124	3-679-219-00	ARM (RIGHT), DRIVING	
125	3-679-216-00	WHEEL, WORM	
126	3-679-316-00	ROLLER (LEFT), DRIVING	
127	3-679-129-00	LEVER (RIGHT), RETAINER, CASSETTE	
128	•:X-3679-106-0	PLATE ASSY, SIDE, BASE RIGHT	
129	3-679-131-00	LEVER (RIGHT), PREVENTION	
130	3-679-133-00	ARM, LID OPEN	
131	3-679-189-00	SPRING, TENSION	
132	3-679-134-00	ARM, SWITCHING, DOOR	
133	3-679-221-00	PLATE, RACK, SWITCHING, DOOR	
134	3-679-126-00	GEAR (RIGHT), MIDWAY	
135	3-679-218-00	GEAR (B), LIMITER	
136	3-679-144-00	SPRING (RIGHT)	
137	3-679-225-00	GEAR (RIGHT), ARM, DRIVING	
138	3-679-125-00	GEAR, DRIVING	
139	3-679-138-00	CAM (CASSETTE ON)	
140	•:3-679-214-00	HOLDER, GEAR, WORM	
141	•:1-609-227-00	CS-3 BOARD	
142	3-669-480-21	+ PTPWH 2	
143	•:1-609-228-00	CS-4 BOARD	
144	1-554-241-00	SWITCH, LEVER	
145	•:3-682-626-00	PLATE, TOP	

4. REEL TABLE ASSEMBLY




No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
151	X-3679-120-0	BAND ASSY, TENSION REGULATOR		165	X-3679-118-0	BRAKE ASSY, T	
152	3-669-465-00	WASHER (1.5), STOPPER		166	1-454-348-00	SOLENOID, BRAKE PLUNGER	
	3-679-231-00	LEVER, BRAKE, SOFT		167	3-679-190-00	SPRING, TENSION	
153	X-3679-122-0	LEVER ASSY, TENSION REGULATOR		168	X-3681-104-0	TABLE ASSY, S REEL	
154	3-679-156-00	SPRING, TENSION		169	3-646-185-00	BEARING	
155	3-679-230-00	LEVER, FUNCTION		170	1-554-374-00	SWITCH, LEVER	
156	3-679-151-00	SPRING, TENSION		171	3-679-318-00	WASHER, PENDULUM ARM	
158	X-3679-117-0	BRAKE ASSY, S		172	A-6759-074-A	ARM ASSY, PENDULUM	
159	3-681-163-00	HOOK, SPRING, REWIND		173	X-2622-201-0	ROTOR ASSY, R	
160	3-681-156-00	SPRING, TENSION		174	3-681-157-00	HOLDER, RD	
161	X-3681-105-0	ARM ASSY, REWIND BRAKE		175	X-3679-130-0	CHASSIS ASSY, SUB	
162	3-679-168-00	JOINT, BRAKE, L		176	A-4910-021-A	R STATOR BOARD, COMPLETE	
163	3-669-595-00	WASHER (2), STOPPER		177	1-610-401-00	RD-6 BOARD	
164	X-3679-119-0	ARM ASSY, STOPPER, PENDULUM		179	1-610-402-00	RD-7 BOARD	

5. CHASSIS ASSEMBLY (1)



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
201	3-669-596-00	WASHER (2.3), STOPPER		220	3-669-465-00	WASHER (1.5), STOPPER	
202	•:X-3679-108-0	ARM ASSY, PRESS, PINCH		221	•:X-3679-145-0	ARM ASSY, CAR, TENSION	
203	3-669-480-11	+ PTPWH 2		222	•:3-679-117-05	CHASSIS, ARM, STOPPER	
204	•:3-672-540-00	PLATE, GROUND, TAPE GUIDE		223	1-454-349-41	SOLENOID, PLUNGER	
205	•:3-669-618-00	PLATE (2), ADJUST		224	X-3679-152-0	ARM (B) ASSY, PINCH SOLENOID	
206	3-679-164-00	SPRING, TENSION		225	•:3-672-542-00	BRACKET, SWITCH, LE	
207	1-464-286-00	SENSOR, S COIL		226	1-553-539-00	SWITCH, MICRO	
208	•:3-669-476-04	PLATE, GUIDE		227	3-669-595-00	WASHER (2), STOPPER	
209	X-3679-149-0	ARM (B) ASSY, LOCK	210	228	•:X-3669-379-0	ARM (P) ASSY, PINCH LIMITER	229
210	3-679-323-00	SPRING, TENSION		229	3-465-159-XX	SPRING, TENSION	
211	3-669-697-00	SPACER, CAPSTAN		230	•:3-679-163-00	PLATE, LID OPEN	
212	3-679-359-00	SPRING, COMPRESSION		231	X-3681-106-0	LEVER ASSY, SLIDE	
213	3-669-633-00	SCREW, + PW2		232	3-681-154-00	SPRING, TORSION	
214	•:3-672-507-00	PLATE (3-1), ADJUSTMENT		233	X-3681-107-0	ARM ASSY, REVIEW BRAKE	
215	1-464-250-00	SENSOR, T COIL		234	8-838-027-00	MOTOR, DC (BHF-1901B)	
216	3-508-108-XX	SPRING, TENSION		235	•:3-682-120-00	PROTECTOR	
217	•:3-679-251-00	LIMITER, STOPPER		236	3-669-607-00	+PSW (SMALL ROUND) 2.6	
218	•:X-3679-123-0	ARM ASSY, STOPPER		237	3-669-607-31	+PSW (SMALL ROUND) (2.6)	
219	3-679-307-00	GEAR, TENSION					

6. CHASSIS ASSEMBLY (2)



No. Part No. Description

251	A-6761-065-A	ACE ASSY
252	3-669-480-11	+ PTPWH 2
253	3-669-316-00	SPRING, COMPRESSION
254	3-669-598-00	WASHER, CTL
255	3-669-318-00	NUT, ADJUSTMENT, GUIDE
256	3-669-317-00	SPRING, COMPRESSION
257	3-669-465-00	WASHER (1.5), STOPPER
258	X-3679-147-0	CHASSIS (B) ASSY, DRIVE GEAR
259	X-3679-148-0	GEAR (F) ASSY (B)
260	3-669-596-00	WASHER (2.3), STOPPER
261	X-3669-307-6	ARM ASSY, PINCH ROLLER
262	3-669-431-00	FLANGE (UPPER), GUIDE
263	3-669-438-00	ROLLER, GUIDE
264	3-669-443-00	BEARING, BALL (NO FLANGE)
265	3-669-337-00	GEAR (D)
266	3-669-338-00	GEAR (E)
267	3-669-444-00	SPRING, TORSION
268	3-669-432-00	FLANGE (LOWER), GUIDE
269	3-669-452-00	SPRING, COMPRESSION

Remark
252, 253, 254


No. Part No. Description

270	3-549-014-00	SPRING, TENSION
271	3-669-607-31	+PSW (SMALL ROUND) (2.6)
272	3-679-165-00	STOPPER, SLIDER
273	3-679-119-00	BELT, SYNCHRO
274	3-679-140-00	FLANGE, GEAR, INTERNAL
275	3-679-101-00	GEAR, INTERNAL
276	3-679-104-00	GEAR
277	3-679-115-00	GEAR (LARGE), LOADING
279	X-3679-111-0	CARRIER ASSY
280	X-3679-112-0	CHASSIS ASSY, GEAR, PLANET
281	3-679-114-00	GEAR (SMALL), LOADING
282	X-3669-321-0	GEAR (C) ASSY
283	A-6737-118-A	MOTOR ASSY, L
284	1-605-071-00	LM-8 BOARD
285	3-669-613-00	INSULATOR, L MOTOR
286	3-669-595-00	WASHER (2), STOPPER
287	1-541-163-00	MOTOR
288	3-657-841-31	SPACER (2X2.5)

Remark

287

7. DRUM AND S LOADING ASSEMBLIES



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
301	A-6050-205-A	DRUM ASSY (DSH-39A-R)	302,303,304,305,306	324	3-669-616-00	RETAINER	
302	A-6760-066-B	SPRING ASSY, TAPE RETAINER		325	3-669-430-0	HOLDER BLOCK ASSY, #3 GUIDE	
303	A-6760-138-A	DRUM ASSY, UPPER		326	3-669-478-00	SCREW (1X3), TAPPING	
304	3-669-157-00	BOLT (WASHER) (2.6X8)		327	3-669-479-11	SCREW (1.4X3.5), TAPPING	
305	A-6762-139-A	DISK ASSY		328	3-669-429-0	HOLDER BLOCK ASSY, #2 GUIDE	
306	X-3669-105-0	SPACER BLOCK ASSY		329	3-669-472-00	RETAINER, SPRING, LEAF	
307	X-2621-210-2	STATOR ASSY, D		330	3-672-583-00	SPRING	
308	X-2621-202-0	ROTOR ASSY, D		331	3-672-586-00	SCREW (1.4X3), TAPPING	
309	3-669-466-00	SCREW (M 2.6)		332	3-669-465-00	WASHER (1.5), STOPPER	
310	3-669-585-00	GUIDE (2), SHUTTLE		333	3-669-597-00	ROLLER (B), RING	
311	3-679-290-00	GUIDE (1-YA), SHUTTLE		334	3-669-630-00	ROLLER (C), RING	
312	3-669-446-00	NUT, GUIDE, NO. 6		335	3-669-646-11	SPACER, DRUM	
313	3-679-910-00	FLANGE, GUIDE, NO. 6		336	3-669-607-31	+PSW (SMALL ROUND) (2.6)	
314	3-669-445-00	SPACER, GUIDE, NO. 6		337	3-669-329-0	PLATE ASSY, ADJUSTMENT	
315	3-669-615-00	SPRING, COMPRESSION		338	3-669-355-00	HOLDER, SWITCH, ULE	
316	3-669-606-00	SCREW (2.6)		339	1-553-718-00	SWITCH, MICRO	
317	8-825-508-10	HEAD, FE		340	3-669-360-00	ROLLER, RING	
318	3-669-313-0	BASE ASSY, SLANT		341	3-669-600-11	WASHER, FLAT (3.5)	
319	3-669-480-11	+ PTPWH 2		342	3-429-123-00	SPRING	
320	A-6750-108-B	SHUTTLE BLOCK ASSY, THREADING		343	3-669-302-00	SCREW, FITTING	
322	3-669-327-0	ARM ASSY, SWITCH, ULE		344	3-669-646-00	SPACER, DRUM	
323	3-669-477-00	LINER, LINK, PIN					
	X-3679-150-0	RING (YA) ASSY, S LOADING	324,325,326,327,328,329,330,331				

8. HARDWARE LIST

SCREW

7-621-759-35 +PSW, 2.6X5
7-621-759-45 +PSW, 2.6X6
7-621-259-32 SCREW +P 2.6X5
7-621-259-35 SCREW +P 2.6X5
7-627-551-08 SCREW, PRECISION +P 1.4X1.6

7-627-551-28 SCREW, PRECISION +P 1.4X2.5
7-628-253-45 SCREW +PS 2X10
7-628-253-95 SCREW +PS 2.6X4
7-628-254-15 SCREW +PS 2.6X6
7-685-134-01 SCREW +P 2.6X8 TYPE1

7-685-134-11 SCREW +P 2.6X8 TYPE2 NON-SLIT
7-685-135-11 SCREW +P 2.6X10 TYPE2 NON-SLIT
7-685-534-19 SCREW +BTP 2.6X8 TYPE2 N-S
7-685-791-01 SCREW +PTT 2.6X5 (S)
7-685-860-01 SCREW +BVTT 2.6X4 (S)

7-685-861-09 SCREW +BVTT 2.6X5 (S)
7-685-862-01 SCREW +BVTT 2.6X6 (S)

SET-SCREW

7-621-712-26 SET-SCREW, SLOT 2.6X3FLAT POINT
7-621-712-35 SET-SCREW, SLOT 2.6X4CONE POINT
7-621-712-46 SET-SCREW, SLOT 2.6X5FLAT POINT
7-621-731-08 SET-SCT, HEX. 2X2.5, FLAT POINT

SPRING PIN

7-626-302-31 SPRING PIN, 2.5X14

TAPPING

7-685-105-11 TPG +P 2X8, TYPE 2, NON-SLIT

NUT

7-622-205-05 N 2, TYPE 2

WASHER

7-688-002-11 W 2.6, MIDDLE
7-688-004-01 W 4, SMALL

SECTION 5

ELECTRICAL PARTS LIST

NOTE:

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

• =>: Due to standardization, interchangeable replacements may be substituted for parts specified in the diagrams.

• Items marked " Δ " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

• All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

CAPACITORS
• MF : μ F, PF : μ μ F

RESISTORS
• All resistors are in ohms
• F : nonflammable

COILS
• MMH : mH, UH : μ H

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
Δ :A-4910-021-A	R STATOR BOARD, COMPLETE	*****		C006	1-131-398-00	ELECT(SOLID) 0.22MF	10% 16V
Δ :1-560-460-00	PIN, CONNECTOR 4P			C007	1-123-356-00	ELECT 10MF	20% 16V
	<u>CAPACITOR</u>			C008	1-102-074-00	CERAMIC 0.001MF	10% 50V
C1	1-123-821-41	ELECT 47MF	20% 16V	C009	1-161-032-00	CERAMIC 0.01MF	20% 25V
C2	1-123-821-41	ELECT 47MF	20% 16V	C010	1-123-380-00	ELECT 1MF	20% 50V
C3	1-123-821-41	ELECT 47MF	20% 16V	C011	1-123-356-00	ELECT 10MF	20% 16V
C4	1-123-821-41	ELECT 47MF	20% 16V	C012	1-123-307-00	ELECT 100MF	20% 10V
	<u>DIODE</u>			C013	1-102-951-00	CERAMIC 15PF	5% 50V
D1	8-719-941-48	DIODE 1N4148TP		C014	1-101-880-00	CERAMIC 47 PF	5% 50V
	<u>IC</u>			C015	1-102-951-00	CERAMIC 15PF	5% 50V
IC1	8-759-108-77	IC CX-877		C016	1-161-036-00	CERAMIC 0.047 MF	20% 25V
	<u>TRANSISTOR</u>			C017	1-123-296-00	ELECT 220MF	20% 6.3V
Q1	8-729-100-01	TRANSISTOR 2SD992		C018	1-102-973-00	CERAMIC 100PF	5% 50V
Q2	8-729-100-01	TRANSISTOR 2SD992		C019	1-102-973-00	CERAMIC 100PF	5% 50V
Q3	8-729-100-01	TRANSISTOR 2SD992		C020	1-123-381-00	ELECT 2.2MF	20% 50V
Q4	8-729-100-01	TRANSISTOR 2SD992		C021	1-161-036-00	CERAMIC 0.047 MF	20% 25V
Q5	8-729-100-01	TRANSISTOR 2SD992		C022	1-161-032-00	CERAMIC 0.01MF	20% 25V
Q6	8-729-100-01	TRANSISTOR 2SD992		C023	1-123-306-00	ELECT 47 MF	20% 10V
	<u>RESISTOR</u>			C024	1-102-129-00	CERAMIC 0.01MF	10% 50V
R1	1-247-823-00	CARBON 470 5% 1/6W		C025	1-102-125-00	CERAMIC 0.0047 MF	10% 50V
R2	1-247-823-00	CARBON 470 5% 1/6W		C026	1-161-063-00	CERAMIC 0.1MF	20% 25V
R3	1-247-823-00	CARBON 470 5% 1/6W		C027	1-123-318-00	ELECT 33MF	20% 16V
R4	1-247-829-00	CARBON 820 5% 1/6W		C028	1-161-036-00	CERAMIC 0.047 MF	20% 25V
R5	1-247-871-00	CARBON 47K 5% 1/6W		C029	1-131-398-00	ELECT(SOLID) 0.22MF	10% 16V
R6	1-247-871-00	CARBON 47K 5% 1/6W		C032	1-123-307-00	ELECT 100MF	20% 10V
R7	1-247-871-00	CARBON 47K 5% 1/6W		C035	1-123-306-00	ELECT 47 MF	20% 10V
R8	1-247-871-00	CARBON 47K 5% 1/6W		C036	1-123-306-00	ELECT 47 MF	20% 10V
	<u>DIODE</u>			C037	1-123-306-00	ELECT 47 MF	20% 10V
S1	8-719-810-31	DIODE THS103-1		C039	1-161-036-00	CERAMIC 0.047 MF	20% 25V
S2	8-719-810-31	DIODE THS103-1		C040	1-123-307-00	ELECT 100MF	20% 10V
*****				C041	1-123-306-00	ELECT 47 MF	20% 10V
Δ :A-6711-474-A	YR-1 BOARD, COMPLETE	*****		C044	1-161-036-00	CERAMIC 0.047 MF	20% 25V
Δ :3-655-214-00	CLIP, CABLE			C045	1-123-306-00	ELECT 47 MF	20% 10V
3-682-615-00	PANEL, REAR			C046	1-161-032-00	CERAMIC 0.01MF	20% 25V
	<u>CAPACITOR</u>			C047	1-161-032-00	CERAMIC 0.01MF	20% 25V
C001	1-161-032-00	CERAMIC 0.01MF	20% 25V	C048	1-108-595-00	MYLAR 0.047 MF	5% 50V
C002	1-123-307-00	ELECT 100MF	20% 10V	C049	1-101-059-00	CERAMIC 510 PF	5% 50V
C003	1-102-951-00	CERAMIC 15PF	5% 50V	C050	1-102-074-00	CERAMIC 0.001MF	10% 50V
C004	1-101-880-00	CERAMIC 47 PF	5% 50V	C051	1-123-306-00	ELECT 47 MF	20% 10V
C005	1-102-951-00	CERAMIC 15PF	5% 50V	C052	1-123-306-00	ELECT 47 MF	20% 10V
				C055	1-123-356-00	ELECT 10MF	20% 16V
				C056	1-102-973-00	CERAMIC 100PF	5% 50V
				C057	1-102-820-00	CERAMIC 330 PF	5% 50V
				C058	1-123-354-00	ELECT 3.3MF	20% 50V
				C059	1-123-380-00	ELECT 1MF	20% 50V
				C060	1-123-356-00	ELECT 10MF	20% 16V
				C061	1-161-063-00	CERAMIC 0.1MF	20% 25V
				C062	1-101-882-00	CERAMIC 51PF	5% 50V
				C063	1-161-032-00	CERAMIC 0.01MF	20% 25V
				C064	1-161-036-00	CERAMIC 0.047 MF	20% 25V
				C065	1-101-880-00	CERAMIC 47 PF	5% 50V
				C066	1-161-032-00	CERAMIC 0.01MF	20% 25V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C067	1-102-947-00	CERAMIC	10PF 5% 50V	C136	1-161-036-00	CERAMIC	0.047MF 20% 25V
C068	1-123-306-00	ELECT	47MF 20% 10V	C148	1-161-032-00	CERAMIC	0.01MF 20% 25V
C069	1-161-036-00	CERAMIC	0.047MF 20% 25V	C149	1-101-880-00	CERAMIC	47PF 5% 50V
C070	1-161-032-00	CERAMIC	0.01MF 20% 25V	C161	1-101-059-00	CERAMIC	510PF 5% 50V
C071	1-102-947-00	CERAMIC	10PF 5% 50V	C162	1-102-821-00	CERAMIC	360PF 5% 50V
C075	1-101-361-00	CERAMIC	150PF 5% 50V	C163	1-102-981-00	CERAMIC	300PF 5% 50V
C076	1-123-332-00	ELECT	47MF 20% 16V	C164	1-102-976-00	CERAMIC	180PF 5% 50V
C077	1-161-036-00	CERAMIC	0.047MF 20% 25V	C165	1-101-880-00	CERAMIC	47PF 5% 50V
C078	1-102-950-00	CERAMIC	13PF 5% 50V	C166	1-161-036-00	CERAMIC	0.047MF 20% 25V
C079	1-101-882-00	CERAMIC	51PF 5% 50V	C167	1-161-036-00	CERAMIC	0.047MF 20% 25V
C080	1-101-882-00	CERAMIC	51PF 5% 50V	C168	1-123-306-00	ELECT	47MF 20% 10V
C081	1-102-950-00	CERAMIC	13PF 5% 50V	C169	1-161-036-00	CERAMIC	0.047MF 20% 25V
C082	1-123-306-00	ELECT	47MF 20% 10V	C170	1-161-032-00	CERAMIC	0.01MF 20% 25V
C083	1-102-978-00	CERAMIC	220PF 5% 50V	C171	1-161-032-00	CERAMIC	0.01MF 20% 25V
C085	1-102-953-00	CERAMIC	18PF 5% 50V	C172	1-161-032-00	CERAMIC	0.01MF 20% 25V
C086	1-102-820-00	CERAMIC	330PF 5% 50V	C173	1-161-032-00	CERAMIC	0.01MF 20% 25V
C087	1-102-820-00	CERAMIC	330PF 5% 50V	C174	1-161-032-00	CERAMIC	0.01MF 20% 25V
C088	1-102-981-00	CERAMIC	300PF 5% 50V	C175	1-161-036-00	CERAMIC	0.047MF 20% 25V
C089	1-102-976-00	CERAMIC	180PF 5% 50V	C176	1-161-036-00	CERAMIC	0.047MF 20% 25V
C091	1-102-981-00	CERAMIC	300PF 5% 50V	C177	1-123-332-00	ELECT	47MF 20% 16V
C092	1-102-820-00	CERAMIC	330PF 5% 50V	C178	1-161-032-00	CERAMIC	0.01MF 20% 25V
C093	1-102-978-00	CERAMIC	220PF 5% 50V	C179	1-102-950-00	CERAMIC	13PF 5% 50V
C094	1-102-981-00	CERAMIC	300PF 5% 50V	C180	1-101-882-00	CERAMIC	51PF 5% 50V
C095	1-101-880-00	CERAMIC	47PF 5% 50V	C181	1-101-882-00	CERAMIC	51PF 5% 50V
C097	1-161-036-00	CERAMIC	0.047MF 20% 25V	C182	1-102-950-00	CERAMIC	13PF 5% 50V
C098	1-123-307-00	ELECT	100MF 20% 10V	C183	1-123-296-00	ELECT	220MF 20% 6.3V
C099	1-123-306-00	ELECT	47MF 20% 10V	C184	1-123-296-00	ELECT	220MF 20% 6.3V
C100	1-123-656-00	ELECT	1000MF 20% 10V	C185	1-102-973-00	CERAMIC	100PF 5% 50V
C101	1-123-656-00	ELECT	1000MF 20% 10V	C186	1-161-017-00	CERAMIC	0.022MF 10% 25V
C102	1-123-306-00	ELECT	47MF 20% 10V	C187	1-123-356-00	ELECT	10MF 20% 16V
C103	1-161-036-00	CERAMIC	0.047MF 20% 25V	C188	1-102-816-00	CERAMIC	120PF 5% 50V
C104	1-123-306-00	ELECT	47MF 20% 10V	C189	1-102-973-00	CERAMIC	100PF 5% 50V
C105	1-123-306-00	ELECT	47MF 20% 10V	C190	1-123-380-00	ELECT	1MF 20% 50V
C109	1-123-307-00	ELECT	100MF 20% 10V	C191	1-123-307-00	ELECT	100MF 20% 10V
C110	1-123-306-00	ELECT	47MF 20% 10V	C192	1-102-122-00	CERAMIC	0.0027MF 10% 50V
C111	1-161-036-00	CERAMIC	0.047MF 20% 25V	C193	1-102-117-00	CERAMIC	820PF 10% 50V
C112	1-161-032-00	CERAMIC	0.01MF 20% 25V	C194	1-123-307-00	ELECT	100MF 20% 10V
C113	1-161-063-00	CERAMIC	0.1MF 20% 25V	C195	1-102-951-00	CERAMIC	15PF 5% 50V
C114	1-123-354-00	ELECT	3.3MF 20% 50V	C196	1-108-589-00	MYLAR	0.027MF 5% 50V
C115	1-123-381-00	ELECT	2.2MF 20% 50V	C197	1-161-032-00	CERAMIC	0.01MF 20% 25V
C116	1-123-381-00	ELECT	2.2MF 20% 50V	C200	1-161-063-00	CERAMIC	0.1MF 20% 25V
C118	1-123-306-00	ELECT	47MF 20% 10V	C201	1-123-356-00	ELECT	10MF 20% 16V
C121	1-161-032-00	CERAMIC	0.01MF 20% 25V	C202	1-161-036-00	CERAMIC	0.047MF 20% 25V
C122	1-123-381-00	ELECT	2.2MF 20% 50V	CONNECTOR			
C123	1-161-036-00	CERAMIC	0.047MF 20% 25V	CN002#:	1-560-891-00	PIN, CONNECTOR 3P	
C124	1-161-036-00	CERAMIC	0.047MF 20% 25V	CN003#:	1-560-894-00	PIN, CONNECTOR 6P	
C127	1-161-032-00	CERAMIC	0.01MF 20% 25V	CN004#:	1-560-892-00	PIN, CONNECTOR 4P	
C128	1-161-032-00	CERAMIC	0.01MF 20% 25V	CN005#:	1-560-896-00	PIN, CONNECTOR 8P	
C131	1-123-356-00	ELECT	10MF 20% 16V	CN006#:	1-560-896-00	PIN, CONNECTOR 8P	
C132	1-161-063-00	CERAMIC	0.1MF 20% 25V	CN007#:	1-560-890-00	PIN, CONNECTOR 2P	
C133	1-101-059-00	CERAMIC	510PF 5% 50V	CN008#:	1-560-891-00	PIN, CONNECTOR 3P	
C134	1-108-595-00	MYLAR	0.047MF 5% 50V	CN009#:	1-560-893-00	PIN, CONNECTOR 5P	
C135	1-101-059-00	CERAMIC	510PF 5% 50V				

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
CN010	1-560-898-00	PIN, CONNECTOR 10P		L013	1-408-419-00	MICRO INDUCTOR 68UH	
CN011	1-560-895-00	PIN, CONNECTOR 7P		L014	1-408-412-00	MICRO INDUCTOR 18UH	
<u>JACK</u>				L015	1-408-423-00	MICRO INDUCTOR 150UH	
CNJ001	1-507-588-32	PIN JACK, 1P		L017	1-408-419-00	MICRO INDUCTOR 68UH	
CNJ002	1-560-751-21	CONNECTOR ASSY, BNC		L020	1-408-414-00	MICRO INDUCTOR 27UH	
CNJ003	1-561-468-00	SOCKET, CONNECTOR (DIN8P)		L022	1-408-410-00	MICRO INDUCTOR 12UH	
<u>DIODE</u>				L023	1-408-423-00	MICRO INDUCTOR 150UH	
D001	=>8-7 19-200-02	DIODE 10E-2		L024	1-408-412-00	MICRO INDUCTOR 18UH	
D002	=>8-7 19-200-02	DIODE 10E-2		L025	1-408-412-00	MICRO INDUCTOR 18UH	
D005	8-7 19-811-48	DIODE 1SS148		L026	1-408-423-00	MICRO INDUCTOR 150UH	
D006	8-7 19-811-48	DIODE 1SS148		L027	1-408-422-00	MICRO INDUCTOR 120UH	
D007	8-7 19-811-48	DIODE 1SS148		L028	1-408-424-00	MICRO INDUCTOR 180UH	
D008	8-7 19-811-48	DIODE 1SS148		L029	1-408-422-00	MICRO INDUCTOR 120UH	
D009	8-7 19-811-48	DIODE 1SS148		L031	1-408-423-00	MICRO INDUCTOR 150UH	
D010	8-7 19-811-48	DIODE 1SS148		L032	1-407-703-00	MICRO INDUCTOR 68UH	
D020	8-7 19-811-48	DIODE 1SS148		L033	1-407-703-00	MICRO INDUCTOR 68UH	
D021	8-7 19-811-48	DIODE 1SS148		<u>TRANSISTOR</u>			
D022	8-7 19-811-48	DIODE 1SS148		Q001	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
D023	8-7 19-811-48	DIODE 1SS148		Q003	8-7 29-245-83	TRANSISTOR 2SC2458	
<u>DELAY LINE</u>				Q004	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR	
DL001	1-415-148-00	DELAY LINE		Q005	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
DL004	1-415-204-00	DELAY LINE		Q006	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
DL005	1-415-203-00	DELAY LINE		Q007	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
<u>FILTER</u>				Q008	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
FL001	1-527-849-00	FILTER, CERAMIC		Q009	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR	
FL002	1-235-097-00	FILTER, LOW PASS		Q010	8-7 29-245-83	TRANSISTOR 2SC2458	
<u>IC</u>				Q011	8-7 29-245-83	TRANSISTOR 2SC2458	
IC001	8-7 59-201-00	IC TL8609P		Q013	8-7 29-245-83	TRANSISTOR 2SC2458	
IC002	8-7 59-240-53	IC TC4053BP		Q014	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
IC003	8-7 59-208-94	IC CX-894		Q015	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
IC004	8-7 59-101-00	IC CX20043		Q016	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR	
IC005	8-7 52-003-00	IC CX20039		Q017	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
IC006	8-7 58-220-00	IC CX-822		Q019	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
IC008	8-7 59-201-00	IC TA7357AP		Q022	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
IC009	8-7 59-240-53	IC TC4053BP		Q030	8-7 29-245-83	TRANSISTOR 2SC2458	
IC010	8-7 51-350-00	IC CX-135		Q031	8-7 29-245-83	TRANSISTOR 2SC2458	
<u>COIL</u>				Q032	8-7 29-245-83	TRANSISTOR 2SC2458	
L001	1-408-416-00	MICRO INDUCTOR 39UH		Q033	8-7 29-245-83	TRANSISTOR 2SC2458	
L002	1-408-416-00	MICRO INDUCTOR 39UH		Q042	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR	
L003	1-408-416-00	MICRO INDUCTOR 39UH		Q043	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
L004	1-408-416-00	MICRO INDUCTOR 39UH		Q044	8-7 29-245-83	TRANSISTOR 2SC2458	
L005	1-408-408-00	MICRO INDUCTOR 8.2UH		Q045	8-7 29-245-83	TRANSISTOR 2SC2458	
L008	1-408-427-00	MICRO INDUCTOR 330UH		Q046	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR	
L009	1-408-422-00	MICRO INDUCTOR 120UH		Q047	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
L010	1-408-424-00	MICRO INDUCTOR 180UH		Q048	=>8-7 29-603-50	TRANSISTOR 2SC403SP	
L011	1-408-422-00	MICRO INDUCTOR 120UH		Q049	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR	
L012	1-408-413-00	MICRO INDUCTOR 22UH		Q050	8-7 29-245-83	TRANSISTOR 2SC2458	
				Q051	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR	
				Q054	8-7 29-245-83	TRANSISTOR 2SC2458	
				Q055	8-7 29-245-83	TRANSISTOR 2SC2458	
				Q056	8-7 29-245-83	TRANSISTOR 2SC2458	

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
Q057	=>8-7 29-603-50	TRANSISTOR 2SC403SP		R056	1-247-831-00	CARBON 1K 5%	1/6W
Q058	=>8-7 29-603-50	TRANSISTOR 2SC403SP		R057	1-247-823-00	CARBON 470 5%	1/6W
Q059	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR		R058	1-247-838-00	CARBON 2K 5%	1/6W
Q060	=>8-7 29-603-50	TRANSISTOR 2SC403SP		R059	1-247-855-00	CARBON 10K 5%	1/6W
Q061	=>8-7 29-603-50	TRANSISTOR 2SC403SP		R060	1-247-863-00	CARBON 22K 5%	1/6W
Q062	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR		R062	1-247-837-00	CARBON 1.8K 5%	1/6W
RESISTOR				R063	1-247-836-00	CARBON 1.6K 5%	1/6W
R001	1-247-863-00	CARBON 22K 5%	1/6W	R064	1-247-817-00	CARBON 270 5%	1/6W
R002	1-247-874-00	CARBON 62K 5%	1/6W	R065	1-247-816-00	CARBON 240 5%	1/6W
R003	1-247-903-00	CARBON 1M 5%	1/6W	R066	1-247-825-00	CARBON 560 5%	1/6W
R004	1-247-827-00	CARBON 680 5%	1/6W	R067	1-247-838-00	CARBON 2K 5%	1/6W
R005	1-247-832-00	CARBON 1.1K 5%	1/6W	R068	1-247-859-00	CARBON 15K 5%	1/6W
R006	1-247-903-00	CARBON 1M 5%	1/6W	R069	1-247-827-00	CARBON 680 5%	1/6W
R007	1-247-827-00	CARBON 680 5%	1/6W	R070	1-247-859-00	CARBON 15K 5%	1/6W
R008	1-247-832-00	CARBON 1.1K 5%	1/6W	R071	1-247-863-00	CARBON 22K 5%	1/6W
R009	1-247-831-00	CARBON 1K 5%	1/6W	R072	1-247-855-00	CARBON 10K 5%	1/6W
R010	1-247-814-00	CARBON 200 5%	1/6W	R073	1-247-829-00	CARBON 820 5%	1/6W
R012	1-247-814-00	CARBON 200 5%	1/6W	R074	1-247-863-00	CARBON 22K 5%	1/6W
R013	1-247-842-00	CARBON 3K 5%	1/6W	R075	1-247-863-00	CARBON 22K 5%	1/6W
R014	1-247-871-00	CARBON 47K 5%	1/6W	R076	1-247-829-00	CARBON 820 5%	1/6W
R015	1-247-871-00	CARBON 47K 5%	1/6W	R077	1-247-833-00	CARBON 1.2K 5%	1/6W
R016	1-247-871-00	CARBON 47K 5%	1/6W	R078	1-247-835-00	CARBON 1.5K 5%	1/6W
R019	1-247-871-00	CARBON 47K 5%	1/6W	R079	1-247-843-00	CARBON 3.3K 5%	1/6W
R023	1-247-863-00	CARBON 22K 5%	1/6W	R080	1-247-863-00	CARBON 22K 5%	1/6W
R024	1-247-863-00	CARBON 22K 5%	1/6W	R081	1-247-855-00	CARBON 10K 5%	1/6W
R025	1-247-855-00	CARBON 10K 5%	1/6W	R084	1-247-855-00	CARBON 10K 5%	1/6W
R026	1-247-855-00	CARBON 10K 5%	1/6W	R085	1-247-863-00	CARBON 22K 5%	1/6W
R027	1-247-807-00	CARBON 100 5%	1/6W	R086	1-247-838-00	CARBON 2K 5%	1/6W
R028	1-247-855-00	CARBON 10K 5%	1/6W	R087	1-247-811-00	CARBON 150 5%	1/6W
R029	1-247-859-00	CARBON 15K 5%	1/6W	R088	1-247-831-00	CARBON 1K 5%	1/6W
R030	1-247-895-00	CARBON 470K 5%	1/6W	R089	1-247-863-00	CARBON 22K 5%	1/6W
R031	1-247-857-00	CARBON 12K 5%	1/6W	R090	1-247-835-00	CARBON 1.5K 5%	1/6W
R032	1-247-861-00	CARBON 18K 5%	1/6W	R091	1-247-829-00	CARBON 820 5%	1/6W
R033	1-247-831-00	CARBON 1K 5%	1/6W	R092	1-247-835-00	CARBON 1.5K 5%	1/6W
R034	1-247-861-00	CARBON 18K 5%	1/6W	R093	1-247-835-00	CARBON 1.5K 5%	1/6W
R035	1-247-847-00	CARBON 4.7K 5%	1/6W	R094	1-247-839-00	CARBON 2.2K 5%	1/6W
R036	1-247-831-00	CARBON 1K 5%	1/6W	R095	1-247-836-00	CARBON 1.6K 5%	1/6W
R037	1-247-839-00	CARBON 2.2K 5%	1/6W	R096	1-247-819-00	CARBON 330 5%	1/6W
R038	1-247-875-00	CARBON 68K 5%	1/6W	R097	1-247-831-00	CARBON 1K 5%	1/6W
R039	1-247-883-00	CARBON 150K 5%	1/6W	R098	1-247-831-00	CARBON 1K 5%	1/6W
R040	1-247-839-00	CARBON 2.2K 5%	1/6W	R099	1-247-803-00	CARBON 68 5%	1/6W
R041	1-247-835-00	CARBON 1.5K 5%	1/6W	R100	1-247-803-00	CARBON 68 5%	1/6W
R042	1-247-843-00	CARBON 3.3K 5%	1/6W	R101	1-247-867-00	CARBON 33K 5%	1/6W
R043	1-247-852-00	CARBON 7.5K 5%	1/6W	R105	1-247-829-00	CARBON 820 5%	1/6W
R044	1-247-835-00	CARBON 1.5K 5%	1/6W	R106	1-247-831-00	CARBON 1K 5%	1/6W
R048	1-247-837-00	CARBON 1.8K 5%	1/6W	R107	1-247-839-00	CARBON 2.2K 5%	1/6W
R049	1-247-827-00	CARBON 680 5%	1/6W	R108	1-247-849-00	CARBON 5.6K 5%	1/6W
R051	1-247-859-00	CARBON 15K 5%	1/6W	R109	1-247-839-00	CARBON 2.2K 5%	1/6W
R052	1-247-845-00	CARBON 3.9K 5%	1/6W	R112	1-247-871-00	CARBON 47K 5%	1/6W
R053	1-247-825-00	CARBON 560 5%	1/6W	R113	1-247-873-00	CARBON 56K 5%	1/6W
R054	1-247-825-00	CARBON 560 5%	1/6W	R114	1-247-869-00	CARBON 39K 5%	1/6W
R055	1-247-827-00	CARBON 680 5%	1/6W				

When indicating parts by reference number, please include the board name.

YR-1**CL-7**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
RV008	1-228-753-00	RES, ADJ, CARBON 470K		C036	1-102-119-00	CERAMIC 0.0015MF	10% 50V
RV010	1-228-745-00	RES, ADJ, CARBON 1K		C037	1-161-013-00	CERAMIC 0.01MF	10% 25V
RV011	1-228-745-00	RES, ADJ, CARBON 1K		C038	1-102-960-00	CERAMIC 24PF	5% 50V
RV013	1-228-745-00	RES, ADJ, CARBON 1K		C039	1-123-354-00	ELECT 3.3MF	20% 50V
RV014	1-228-750-00	RES, ADJ, CARBON 47K		C040	1-161-017-00	CERAMIC 0.022MF	10% 25V
RV015	1-228-750-00	RES, ADJ, CARBON 47K		C041	1-123-332-00	ELECT 47MF	20% 16V
RV016	1-228-994-00	RES, ADJ, METAL GLAZE 10K		C042	1-161-021-00	CERAMIC 0.047MF	10% 25V
RV023	1-228-747-00	RES, ADJ, CARBON 4.7K		C043	1-102-963-00	CERAMIC 33PF	5% 50V
RV024	1-228-745-00	RES, ADJ, CARBON 1K		C044	1-161-013-00	CERAMIC 0.01MF	10% 25V
THERMISTOR				C047	♣:A-6711-475-A	COMPLETE PCB, CL-7	
TH001	1-800-071-XX	TH DIRECT-HEATING DISK S-300		C048	1-161-013-00	CERAMIC 0.01MF	10% 25V
	1-800-071-XX	THERMISTER, S-300		C049	1-161-013-00	CERAMIC 0.01MF	10% 25V
*****				C052	1-123-356-00	ELECT 10MF	20% 16V
♣:A-6711-475-A	CL-7 BOARD, COMPLETE	*****		C053	1-161-021-00	CERAMIC 0.047MF	10% 25V
♣:3-655-214-00	CLIP, CABLE			C054	1-161-013-00	CERAMIC 0.01MF	10% 25V
♣:3-682-601-00	CASE (UPPER), SHIELD, CL			C055	1-161-013-00	CERAMIC 0.01MF	10% 25V
♣:3-682-602-00	CASE (MAIN), SHIELD, CL			C056	1-161-013-00	CERAMIC 0.01MF	10% 25V
♣:3-682-603-00	CASE (LOWER), SHIELD, CL			C057	1-123-328-00	ELECT 4.7MF	20% 25V
CAPACITOR				C058	1-161-021-00	CERAMIC 0.047MF	10% 25V
C001	1-161-013-00	CERAMIC 0.01MF	10% 25V	C059	1-123-356-00	ELECT 10MF	20% 16V
C002	1-161-013-00	CERAMIC 0.01MF	10% 25V	C060	1-102-512-00	CERAMIC 16PF	5% 50V
C003	1-123-356-00	ELECT 10MF	20% 16V	C061	1-102-512-00	CERAMIC 16PF	5% 50V
C005	1-161-013-00	CERAMIC 0.01MF	10% 25V	C062	1-102-851-00	CERAMIC 15PF	5% 50V
C006	1-161-013-00	CERAMIC 0.01MF	10% 25V	C063	1-102-851-00	CERAMIC 15PF	5% 50V
C007	1-161-013-00	CERAMIC 0.01MF	10% 25V	C064	1-102-529-00	CERAMIC 100PF	5% 50V
C008	1-102-649-00	CERAMIC 56PF	5% 50V	C065	1-102-529-00	CERAMIC 100PF	5% 50V
C009	1-123-356-00	ELECT 10MF	20% 16V	C066	1-161-013-00	CERAMIC 0.01MF	10% 25V
C010	1-161-021-00	CERAMIC 0.047MF	10% 25V	C069	1-161-013-00	CERAMIC 0.01MF	10% 25V
C011	1-161-013-00	CERAMIC 0.01MF	10% 25V	C072	1-161-013-00	CERAMIC 0.01MF	10% 25V
C012	1-161-013-00	CERAMIC 0.01MF	10% 25V	C073	1-161-013-00	CERAMIC 0.01MF	10% 25V
C013	1-161-013-00	CERAMIC 0.01MF	10% 25V	C074	1-161-013-00	CERAMIC 0.01MF	10% 25V
C014	1-161-013-00	CERAMIC 0.01MF	10% 25V	C075	1-161-013-00	CERAMIC 0.01MF	10% 25V
C015	1-161-013-00	CERAMIC 0.01MF	10% 25V	C079	1-123-332-00	ELECT 47MF	20% 16V
C016	1-161-021-00	CERAMIC 0.047MF	10% 25V	C080	1-123-332-00	ELECT 47MF	20% 16V
C017	1-161-021-00	CERAMIC 0.047MF	10% 25V	C081	1-123-318-00	ELECT 33MF	20% 16V
C018	1-102-973-00	CERAMIC 100PF	5% 50V	C082	1-161-039-00	CERAMIC 0.001MF	10% 25V
C020	1-161-013-00	CERAMIC 0.01MF	10% 25V	C085	1-161-013-00	CERAMIC 0.01MF	10% 25V
C021	1-161-013-00	CERAMIC 0.01MF	10% 25V	C086	1-161-021-00	CERAMIC 0.047MF	10% 25V
C022	1-161-013-00	CERAMIC 0.01MF	10% 25V	C087	1-123-330-00	ELECT 22MF	20% 16V
C023	1-161-013-00	CERAMIC 0.01MF	10% 25V	C088	1-131-341-00	TANTALUM 0.1MF	10% 35V
C024	1-161-013-00	CERAMIC 0.01MF	10% 25V	C089	1-161-017-00	CERAMIC 0.022MF	10% 25V
C025	1-123-356-00	ELECT 10MF	20% 16V	C090	1-123-332-00	ELECT 47MF	20% 16V
C026	1-161-013-00	CERAMIC 0.01MF	10% 25V	C091	1-161-021-00	CERAMIC 0.047MF	10% 25V
C028	1-161-013-00	CERAMIC 0.01MF	10% 25V	C092	1-161-009-00	CERAMIC 0.0047MF	10% 25V
C029	1-123-380-00	ELECT 1MF	20% 50V	C093	1-123-380-00	ELECT 1MF	20% 50V
C030	1-102-947-00	CERAMIC 10PF	5% 50V	C094	1-161-013-00	CERAMIC 0.01MF	10% 25V
C031	1-102-965-00	CERAMIC 39PF	5% 50V	C095	1-161-039-00	CERAMIC 0.001MF	10% 25V
C032	1-123-356-00	ELECT 10MF	20% 16V	C096	1-102-950-00	CERAMIC 13PF	5% 50V
C035	1-102-120-00	CERAMIC 0.0018MF	10% 50V	C097	1-123-354-00	ELECT 3.3MF	20% 50V
				C098	1-161-013-00	CERAMIC 0.01MF	10% 25V
				C099	1-161-013-00	CERAMIC 0.01MF	10% 25V
				C100	1-161-013-00	CERAMIC 0.01MF	10% 25V
				C101	1-161-013-00	CERAMIC 0.01MF	10% 25V

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C102	1-123-356-00	ELECT	10MF 20% 16V	C167	1-161-013-00	CERAMIC 0.01MF 10% 25V	
C103	1-123-356-00	ELECT	10MF 20% 16V	C168	1-161-021-00	CERAMIC 0.047MF 10% 25V	
C104	1-161-013-00	CERAMIC	0.01MF 10% 25V			<u>FILTER</u>	
C105	1-102-978-00	CERAMIC	220PF 5% 50V	CF002	1-527-875-00	FILTER, CERAMIC	
C106	1-123-379-00	ELECT	0.47MF 20% 50V	CF003	1-527-874-00	FILTER, CERAMIC	
C107	1-161-013-00	CERAMIC	0.01MF 10% 25V	CF004	1-527-831-00	FILTER, CERAMIC	
C108	1-161-013-00	CERAMIC	0.01MF 10% 25V	CF005	1-527-874-00	FILTER, CERAMIC	
C109	1-161-013-00	CERAMIC	0.01MF 10% 25V	CF006	1-527-874-00	FILTER, CERAMIC	
C110	1-161-013-00	CERAMIC	0.01MF 10% 25V			<u>CONNECTOR</u>	
C111	1-161-013-00	CERAMIC	0.01MF 10% 25V	CN001	1-560-896-00	PIN, CONNECTOR 8P	
C112	1-123-356-00	ELECT	10MF 20% 16V	CN002	1-560-892-00	PIN, CONNECTOR 4P	
C113	1-161-021-00	CERAMIC	0.047MF 10% 25V	CN003	1-560-898-00	PIN, CONNECTOR 10P	
C114	1-161-013-00	CERAMIC	0.01MF 10% 25V	CN004	1-560-891-00	PIN, CONNECTOR 3P	
C115	1-161-013-00	CERAMIC	0.01MF 10% 25V	CN005	1-560-894-00	PIN, CONNECTOR 6P	
C116	1-161-013-00	CERAMIC	0.01MF 10% 25V	CN006	1-560-891-00	PIN, CONNECTOR 3P	
C117	1-102-883-00	CERAMIC	27PF 5% 50V			<u>TRIMMER</u>	
C118	1-161-013-00	CERAMIC	0.01MF 10% 25V	CV001	1-141-275-00	CAP, TRIMMER	
C119	1-102-649-00	CERAMIC	56PF 5% 50V	CV002	1-141-275-00	CAP, TRIMMER	
C120	1-161-021-00	CERAMIC	0.047MF 10% 25V			<u>DIODE</u>	
C121	1-123-380-00	ELECT	1MF 20% 50V	D003	8-719-911-19	DIODE 1SS119	
C122	1-161-021-00	CERAMIC	0.047MF 10% 25V	D004	8-719-911-19	DIODE 1SS119	
C123	1-102-522-00	CERAMIC	51PF 5% 50V	D005	8-719-911-19	DIODE 1SS119	
C124	1-101-361-00	CERAMIC	150PF 5% 50V	D007	8-719-911-19	DIODE 1SS119	
C125	1-161-013-00	CERAMIC	0.01MF 10% 25V	D008	8-719-911-19	DIODE 1SS119	
C126	1-161-013-00	CERAMIC	0.01MF 10% 25V	D009	8-719-911-19	DIODE 1SS119	
C128	1-161-013-00	CERAMIC	0.01MF 10% 25V	D017	8-719-911-19	DIODE 1SS119	
C129	1-102-522-00	CERAMIC	51PF 5% 50V	D018	8-719-911-19	DIODE 1SS119	
C130	1-101-059-00	CERAMIC	510PF 5% 50V			<u>DELAY LINE</u>	
C131	1-161-013-00	CERAMIC	0.01MF 10% 25V	DL001	1-415-198-00	DELAY LINE (1H)	
C132	1-161-013-00	CERAMIC	0.01MF 10% 25V	DL002	1-415-198-00	DELAY LINE (1H)	
C133	1-161-013-00	CERAMIC	0.01MF 10% 25V	DL003	1-415-338-00	DELAY LINE (300NS)	
C135	1-123-354-00	ELECT	3.3MF 20% 50V	DL005	1-415-338-00	DELAY LINE (300NS)	
C136	1-108-557-00	MYLAR	0.0012MF 5% 50V	DL006	1-415-198-00	DELAY LINE (1H)	
C137	1-161-039-00	CERAMIC	0.001MF 10% 25V			<u>FILTER</u>	
C138	1-161-007-00	CERAMIC	0.0033MF 10% 25V	FL001	1-235-281-00	ENCAPSULATED FILTER	
C139	1-123-356-00	ELECT	10MF 20% 16V			<u>IC</u>	
C140	1-161-021-00	CERAMIC	0.047MF 10% 25V	IC001	8-759-208-94	IC CX-894	
C143	1-161-013-00	CERAMIC	0.01MF 10% 25V	IC002	8-752-006-10	IC CX20061	
C144	1-123-356-00	ELECT	10MF 20% 16V	IC003	8-759-240-52	IC TC4052BP	
C145	1-123-356-00	ELECT	10MF 20% 16V	IC004	8-759-608-82	IC CX-882	
C146	1-161-013-00	CERAMIC	0.01MF 10% 25V	IC006	8-759-919-05	IC CX-7905A	
C147	1-161-013-00	CERAMIC	0.01MF 10% 25V	IC007	8-759-208-94	IC CX-894	
C149	1-161-021-00	CERAMIC	0.047MF 10% 25V	IC008	8-759-240-69	IC TC4069UBP	
C150	1-161-013-00	CERAMIC	0.01MF 10% 25V	IC009	8-752-000-80	IC CX20008	
C152	1-161-013-00	CERAMIC	0.01MF 10% 25V	IC011	8-759-600-08	IC CX-870A	
C153	1-161-021-00	CERAMIC	0.047MF 10% 25V	IC012	8-758-691-00	IC CX-869A	
C155	1-123-356-00	ELECT	10MF 20% 16V				
C156	1-161-021-00	CERAMIC	0.047MF 10% 25V				
C158	1-161-021-00	CERAMIC	0.047MF 10% 25V				
C159	1-123-356-00	ELECT	10MF 20% 16V				
C160	1-102-816-00	CERAMIC	120PF 5% 50V				
C165	1-161-013-00	CERAMIC	0.01MF 10% 25V				
C166	1-102-820-00	CERAMIC	330PF 5% 50V				

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description
---------	----------	-------------

IC013	8-759-208-94	IC CX-894
IC014	8-759-240-53	IC TC4053BP
IC017	8-759-240-13	IC TC4013BP
IC018	8-759-201-68	IC CX10023
IC019=>	8-752-006-10	IC CX20061

IC021=>	8-752-006-10	IC CX20061
---------	--------------	------------

COIL		
------	--	--

L001	1-408-407-00	MICRO INDUCTOR 6.8UH
L002	1-408-408-00	MICRO INDUCTOR 8.2UH
L003	1-408-410-00	MICRO INDUCTOR 12UH
L004	1-408-429-00	MICRO INDUCTOR 470UH
L005	1-408-429-00	MICRO INDUCTOR 470UH

L006	1-407-197-00	MICRO INDUCTOR 1.8MMH
L007	1-408-426-00	MICRO INDUCTOR 270UH
L008	1-408-412-00	MICRO INDUCTOR 18UH
L009	1-407-503-00	MICRO INDUCTOR 8.2MMH
L010	1-408-429-00	MICRO INDUCTOR 470UH

L011	1-408-418-00	MICRO INDUCTOR 56UH
L012	1-407-197-00	MICRO INDUCTOR 1.8MMH
L013	1-408-407-00	MICRO INDUCTOR 6.8UH
L014	1-408-406-00	MICRO INDUCTOR 5.6UH
L015	1-407-503-00	MICRO INDUCTOR 8.2MMH

L016	1-408-416-00	MICRO INDUCTOR 39UH
------	--------------	---------------------

VARIABLE COIL		
---------------	--	--

LV001	1-408-513-00	COIL (VARIABLE)
LV002	1-408-512-00	COIL (VARIABLE)
LV003	1-408-513-00	COIL (VARIABLE)

TRANSISTOR		
------------	--	--

Q001	8-7 29-603-50	TRANSISTOR 2SC403SP
Q002	8-7 29-603-50	TRANSISTOR 2SC403SP
Q003	8-7 29-603-50	TRANSISTOR 2SC403SP
Q004	8-7 29-603-50	TRANSISTOR 2SC403SP
Q005	8-7 29-603-50	TRANSISTOR 2SC403SP

Q006 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q007	8-7 29-603-50	TRANSISTOR 2SC403SP
Q008	8-7 29-603-50	TRANSISTOR 2SC403SP
Q009	8-7 29-603-50	TRANSISTOR 2SC403SP
Q010	8-7 29-603-50	TRANSISTOR 2SC403SP

Q011	8-7 29-603-50	TRANSISTOR 2SC403SP
Q012	8-7 29-603-50	TRANSISTOR 2SC403SP
Q014	8-7 29-603-50	TRANSISTOR 2SC403SP
Q015	8-7 29-603-50	TRANSISTOR 2SC403SP
Q016	8-7 29-603-50	TRANSISTOR 2SC403SP

Q017	8-7 29-603-50	TRANSISTOR 2SC403SP
Q018	8-7 29-603-50	TRANSISTOR 2SC403SP
Q019 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q020 =>	8-7 29-204-83	TRANSISTOR 2SA1048
Q021 =>	8-7 29-204-83	TRANSISTOR 2SA1048

Q022 =>	8-7 29-245-83	TRANSISTOR 2SC2458
---------	---------------	--------------------

Remark

Ref.No.	Part No.	Description
---------	----------	-------------

Q023	8-7 29-603-50	TRANSISTOR 2SC403SP
Q024 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q025	8-7 29-603-50	TRANSISTOR 2SC403SP
Q029 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q030 =>	8-7 29-204-83	TRANSISTOR 2SA1048

Q031 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q037 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q038	8-7 29-603-50	TRANSISTOR 2SC403SP
Q039 =>	8-7 29-204-83	TRANSISTOR 2SA1048
Q040	8-7 29-603-50	TRANSISTOR 2SC403SP

Q041 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q042	8-7 29-603-50	TRANSISTOR 2SC403SP
Q043	8-7 29-603-50	TRANSISTOR 2SC403SP
Q044	8-7 29-603-50	TRANSISTOR 2SC403SP
Q046 =>	8-7 29-245-83	TRANSISTOR 2SC2458

Q047 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q048 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q049 =>	8-7 29-204-83	TRANSISTOR 2SA1048
Q049 =>	8-7 29-204-83	TRANSISTOR 2SA1048
Q050 =>	8-7 29-204-83	TRANSISTOR 2SA1048

Q051 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q052	8-7 29-603-50	TRANSISTOR 2SC403SP
Q053 =>	8-7 29-245-83	TRANSISTOR 2SC2458
Q054	8-7 29-603-50	TRANSISTOR 2SC403SP
Q055	8-7 29-603-50	TRANSISTOR 2SC403SP

Q056	8-7 29-603-50	TRANSISTOR 2SC403SP
Q058	8-7 29-603-50	TRANSISTOR 2SC403SP
Q059 =>	8-7 29-245-83	TRANSISTOR 2SC2458

RESISTOR					
----------	--	--	--	--	--

R001	1-247-875-00	CARBON	68K	5%	1/6W
R002	1-247-865-00	CARBON	27K	5%	1/6W
R003	1-247-832-00	CARBON	1.1K	5%	1/6W
R004	1-247-845-00	CARBON	3.9K	5%	1/6W
R005	1-247-834-00	CARBON	1.3K	5%	1/6W

R006	1-247-873-00	CARBON	56K	5%	1/6W
R007	1-247-855-00	CARBON	10K	5%	1/6W
R008	1-247-831-00	CARBON	1K	5%	1/6W
R009	1-247-831-00	CARBON	1K	5%	1/6W
R010	1-247-831-00	CARBON	1K	5%	1/6W

R011	1-247-831-00	CARBON	1K	5%	1/6W
R012	1-247-873-00	CARBON	56K	5%	1/6W
R013	1-247-868-00	CARBON	36K	5%	1/6W
R014	1-247-841-00	CARBON	2.7K	5%	1/6W
R015	1-247-824-00	CARBON	510	5%	1/6W

R016	1-247-805-00	CARBON	82	5%	1/6W
R017	1-247-790-00	CARBON	20	5%	1/6W
R018	1-247-864-00	CARBON	24K	5%	1/6W
R020	1-247-867-00	CARBON	33K	5%	1/6W
R021	1-247-867-00	CARBON	33K	5%	1/6W

R022	1-247-867-00	CARBON	33K	5%	1/6W
R023	1-247-875-00	CARBON	68K	5%	1/6W
R024	1-247-830-00	CARBON	910	5%	1/6W

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R025	1-247-875-00	CARBON	68K 5% 1/6W	R085	1-247-867-00	CARBON	33K 5% 1/6W
R026	1-247-867-00	CARBON	33K 5% 1/6W	R086	1-247-842-00	CARBON	3K 5% 1/6W
R027	1-247-863-00	CARBON	22K 5% 1/6W	R087	1-247-840-00	CARBON	2.4K 5% 1/6W
R028	1-247-870-00	CARBON	43K 5% 1/6W	R088	1-247-831-00	CARBON	1K 5% 1/6W
R029	1-247-821-00	CARBON	390 5% 1/6W	R091	1-247-831-00	CARBON	1K 5% 1/6W
R030	1-247-821-00	CARBON	390 5% 1/6W	R092	1-247-879-00	CARBON	100K 5% 1/6W
R031	1-247-821-00	CARBON	390 5% 1/6W	R093	1-247-879-00	CARBON	100K 5% 1/6W
R032	1-247-863-00	CARBON	22K 5% 1/6W	R094	1-247-867-00	CARBON	33K 5% 1/6W
R033	1-247-847-00	CARBON	4.7K 5% 1/6W	R095	1-247-867-00	CARBON	33K 5% 1/6W
R034	1-247-839-00	CARBON	2.2K 5% 1/6W	R096	1-247-855-00	CARBON	10K 5% 1/6W
R035	1-247-821-00	CARBON	390 5% 1/6W	R097	1-247-867-00	CARBON	33K 5% 1/6W
R036	1-247-821-00	CARBON	390 5% 1/6W	R098	1-247-864-00	CARBON	24K 5% 1/6W
R037	1-247-821-00	CARBON	390 5% 1/6W	R100	1-247-867-00	CARBON	33K 5% 1/6W
R038	1-247-821-00	CARBON	390 5% 1/6W	R101	1-247-895-00	CARBON	470K 5% 1/6W
R039	1-247-821-00	CARBON	390 5% 1/6W	R102	1-247-895-00	CARBON	470K 5% 1/6W
R040	1-247-839-00	CARBON	2.2K 5% 1/6W	R103	1-247-831-00	CARBON	1K 5% 1/6W
R041	1-247-839-00	CARBON	2.2K 5% 1/6W	R104	1-247-879-00	CARBON	100K 5% 1/6W
R042	1-247-831-00	CARBON	1K 5% 1/6W	R105	1-247-831-00	CARBON	1K 5% 1/6W
R043	1-247-831-00	CARBON	1K 5% 1/6W	R106	1-247-873-00	CARBON	56K 5% 1/6W
R049	1-247-869-00	CARBON	39K 5% 1/6W	R107	1-247-871-00	CARBON	47K 5% 1/6W
R050	1-247-855-00	CARBON	10K 5% 1/6W	R108	1-247-873-00	CARBON	56K 5% 1/6W
R051	1-247-839-00	CARBON	2.2K 5% 1/6W	R109	1-247-873-00	CARBON	56K 5% 1/6W
R052	1-247-829-00	CARBON	820 5% 1/6W	R110	1-247-873-00	CARBON	56K 5% 1/6W
R053	1-247-839-00	CARBON	2.2K 5% 1/6W	R111	1-247-875-00	CARBON	68K 5% 1/6W
R054	1-247-847-00	CARBON	4.7K 5% 1/6W	R112	1-247-862-00	CARBON	20K 5% 1/6W
R055	1-247-867-00	CARBON	33K 5% 1/6W	R113	1-247-843-00	CARBON	3.3K 5% 1/6W
R056	1-247-867-00	CARBON	33K 5% 1/6W	R114	1-247-847-00	CARBON	4.7K 5% 1/6W
R057	1-247-871-00	CARBON	47K 5% 1/6W	R116	1-247-849-00	CARBON	5.6K 5% 1/6W
R058	1-247-855-00	CARBON	10K 5% 1/6W	R117	1-247-807-00	CARBON	100 5% 1/6W
R059	1-247-821-00	CARBON	390 5% 1/6W	R119	1-247-867-00	CARBON	33K 5% 1/6W
R060	1-247-839-00	CARBON	2.2K 5% 1/6W	R120	1-247-858-00	CARBON	13K 5% 1/6W
R061	1-247-831-00	CARBON	1K 5% 1/6W	R121	1-247-867-00	CARBON	33K 5% 1/6W
R062	1-247-831-00	CARBON	1K 5% 1/6W	R122	1-247-867-00	CARBON	33K 5% 1/6W
R063	1-247-867-00	CARBON	33K 5% 1/6W	R123	1-247-867-00	CARBON	33K 5% 1/6W
R065	1-247-867-00	CARBON	33K 5% 1/6W	R124	1-247-831-00	CARBON	1K 5% 1/6W
R066	1-247-867-00	CARBON	33K 5% 1/6W	R125	1-247-831-00	CARBON	1K 5% 1/6W
R067	1-247-867-00	CARBON	33K 5% 1/6W	R126	1-247-831-00	CARBON	1K 5% 1/6W
R069	1-247-867-00	CARBON	33K 5% 1/6W	R127	1-247-831-00	CARBON	1K 5% 1/6W
R070	1-247-867-00	CARBON	33K 5% 1/6W	R140	1-247-867-00	CARBON	33K 5% 1/6W
R071	1-247-873-00	CARBON	56K 5% 1/6W	R141	1-247-867-00	CARBON	33K 5% 1/6W
R072	1-247-873-00	CARBON	56K 5% 1/6W	R142	1-247-831-00	CARBON	1K 5% 1/6W
R073	1-247-839-00	CARBON	2.2K 5% 1/6W	R144	1-247-831-00	CARBON	1K 5% 1/6W
R074	1-247-859-00	CARBON	15K 5% 1/6W	R145	1-247-851-00	CARBON	6.8K 5% 1/6W
R075	1-247-859-00	CARBON	15K 5% 1/6W	R146	1-247-864-00	CARBON	24K 5% 1/6W
R076	1-247-839-00	CARBON	2.2K 5% 1/6W	R148	1-247-831-00	CARBON	1K 5% 1/6W
R077	1-247-839-00	CARBON	2.2K 5% 1/6W	R149	1-247-838-00	CARBON	2K 5% 1/6W
R078	1-247-825-00	CARBON	560 5% 1/6W	R150	1-247-844-00	CARBON	3.6K 5% 1/6W
R079	1-247-855-00	CARBON	10K 5% 1/6W	R151	1-247-852-00	CARBON	7.5K 5% 1/6W
R080	1-247-851-00	CARBON	6.8K 5% 1/6W	R152	1-247-855-00	CARBON	10K 5% 1/6W
R081	1-247-860-00	CARBON	16K 5% 1/6W	R153	1-247-872-00	CARBON	51K 5% 1/6W
R082	1-247-842-00	CARBON	3K 5% 1/6W	R154	1-247-843-00	CARBON	3.3K 5% 1/6W
R083	1-247-862-00	CARBON	20K 5% 1/6W	R155	1-247-831-00	CARBON	1K 5% 1/6W
R084	1-247-844-00	CARBON	3.6K 5% 1/6W	R156	1-247-847-00	CARBON	4.7K 5% 1/6W

When indicating parts by reference number, please include the board name.

CL-7

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
▲:A-6711-476-A	RF-14 BOARD, COMPLETE	*****					
▲:3-682-678-00	CASE (UPPER), SHIELD, RF						
▲:3-682-679-00	CASE (LOWER), SHIELD, RF						
▲:3-682-680-00	CASE (MAIN), SHIELD, RF						
<u>CAPACITOR</u>				<u>DIODE</u>			
C501	1-161-036-00	CERAMIC	0.047MF 20% 25V	D501	8-719-911-19	DIODE 1SS119	
C502	1-123-330-00	ELECT	22MF 20% 16V				
C503	1-161-036-00	CERAMIC	0.047MF 20% 25V	<u>IC</u>			
C504	1-161-036-00	CERAMIC	0.047MF 20% 25V	IC501	8-758-620-00	IC CX-862	
C505	1-161-036-00	CERAMIC	0.047MF 20% 25V	IC503	8-751-340-10	IC CX-134A	
C506	1-123-305-00	ELECT	33MF 20% 10V				
C510	1-161-036-00	CERAMIC	0.047MF 20% 25V	<u>COIL</u>			
C511	1-161-036-00	CERAMIC	0.047MF 20% 25V	L501	1-408-421-00	MICRO INDUCTOR 100UH	
C512	1-101-882-00	CERAMIC	51PF 5% 50V	L502	1-408-024-00	MICRO INDUCTOR 0.22UH	
C513	1-101-882-00	CERAMIC	51PF 5% 50V	L504	1-408-024-00	MICRO INDUCTOR 0.22UH	
C514	1-123-381-00	ELECT	2.2MF 20% 50V	L505	1-408-158-00	MICRO INDUCTOR 6.8MMH	
C515	1-161-009-00	CERAMIC	0.0047MF 10% 25V	L506	1-408-411-00	MICRO INDUCTOR 15UH	
C516	1-161-017-00	CERAMIC	0.022MF 10% 25V	L507	1-408-158-00	MICRO INDUCTOR 6.8MMH	
C517	1-123-356-00	ELECT	10MF 20% 16V	L508	1-408-411-00	MICRO INDUCTOR 15UH	
C518	1-102-114-00	CERAMIC	470PF 10% 50V	L509	1-408-422-00	MICRO INDUCTOR 120UH	
C519	1-102-973-00	CERAMIC	100PF 5% 50V	L510	1-408-427-00	MICRO INDUCTOR 330UH	
C520	1-161-032-00	CERAMIC	0.01MF 20% 25V	L511	1-408-427-00	MICRO INDUCTOR 330UH	
C521	1-123-356-00	ELECT	10MF 20% 16V	L512	1-408-421-00	MICRO INDUCTOR 100UH	
C522	1-102-112-00	CERAMIC	330PF 10% 50V	L513	1-407-717-00	MICRO INDUCTOR 1MMH	
C523	1-161-017-00	CERAMIC	0.022MF 10% 25V				
C524	1-161-032-00	CERAMIC	0.01MF 20% 25V	<u>TRANSISTOR</u>			
C525	1-161-017-00	CERAMIC	0.022MF 10% 25V	Q501	8-729-245-83	TRANSISTOR 2SC2458	
C526	1-161-019-00	CERAMIC	0.033MF 10% 25V	Q502	=>8-729-204-83	TRANSISTOR 2SA1048-GR	
C527	1-161-063-00	CERAMIC	0.1MF 20% 25V	Q503	8-729-245-83	TRANSISTOR 2SC2458	
C528	1-161-036-00	CERAMIC	0.047MF 20% 25V	Q505	8-729-245-83	TRANSISTOR 2SC2458	
C529	1-123-380-00	ELECT	1MF 20% 50V	Q506	=>8-729-205-02	TRANSISTOR 2SA1150	
C531	1-123-333-00	ELECT	100MF 20% 16V	Q507	8-729-245-83	TRANSISTOR 2SC2458	
C532	1-123-380-00	ELECT	1MF 20% 50V	Q508	8-729-245-83	TRANSISTOR 2SC2458	
C533	1-102-947-00	CERAMIC	10PF 5% 50V	Q509	=>8-729-603-50	TRANSISTOR 2SC403SP	
C534	1-102-953-00	CERAMIC	18PF 5% 50V				
C536	1-102-951-00	CERAMIC	15PF 5% 50V	<u>RESISTOR</u>			
C537	1-102-953-00	CERAMIC	18PF 5% 50V	R501	1-247-863-00	CARBON 22K 5% 1/6W	
C538	1-161-036-00	CERAMIC	0.047MF 20% 25V	R502	1-247-855-00	CARBON 10K 5% 1/6W	
C539	1-161-032-00	CERAMIC	0.01MF 20% 25V	R503	1-247-844-00	CARBON 3.6K 5% 1/6W	
C542	1-161-032-00	CERAMIC	0.01MF 20% 25V	R504	1-247-852-00	CARBON 7.5K 5% 1/6W	
C543	1-123-332-00	ELECT	47MF 20% 16V	R505	1-247-855-00	CARBON 10K 5% 1/6W	
C544	1-123-332-00	ELECT	47MF 20% 16V	R506	1-247-844-00	CARBON 3.6K 5% 1/6W	
C545	1-161-032-00	CERAMIC	0.01MF 20% 25V	R507	1-247-867-00	CARBON 33K 5% 1/6W	
C546	1-131-500-51	TANTALUM	2.2MF 20% 16V	R515	1-247-831-00	CARBON 1K 5% 1/6W	
				R517	1-247-829-00	CARBON 820 5% 1/6W	
				R518	1-247-829-00	CARBON 820 5% 1/6W	
<u>CONNECTOR</u>				R519	1-247-779-00	CARBON 6.8 5% 1/6W	
CN501▲:1-508-845-00	PIN, CONNECTOR 6P			R520	1-247-822-00	CARBON 430 5% 1/6W	
CN502▲:1-564-031-11	PIN, CONNECTOR 6P			R521	1-247-855-00	CARBON 10K 5% 1/6W	
CN503▲:1-508-846-00	PIN, CONNECTOR 8P			R522▲:1-247-028-11	CARBON 8.2 5% 1/8W F		
CN504▲:1-508-744-00	PIN, CONNECTOR 10P			R523	1-247-839-00	CARBON 2.2K 5% 1/6W	
CN505▲:1-564-027-00	PIN, CONNECTOR 2P			R524	1-247-839-00	CARBON 2.2K 5% 1/6W	
				R525	1-247-839-00	CARBON 2.2K 5% 1/6W	
				R526	1-247-839-00	CARBON 2.2K 5% 1/6W	
				R527	1-247-831-00	CARBON 1K 5% 1/6W	
				R528	1-247-831-00	CARBON 1K 5% 1/6W	

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R529	1-247-825-00	CARBON	560 5% 1/6W	C008	1-123-318-00	ELECT	33MF 20% 16V
R530	1-247-833-00	CARBON	1.2K 5% 1/6W	C009	1-130-491-00	MYLAR	0.047MF 5% 50V
~~R531~~	~~1-247-028-11~~	~~CARBON~~	~~8.2 5% 1/8W~~	C010	1-161-021-00	CERAMIC	0.047MF 10% 25V
R532	1-247-807-00	CARBON	100 5% 1/6W	C012	1-123-380-00	ELECT	1MF 20% 50V
R533	1-247-867-00	CARBON	33K 5% 1/6W	C013	1-123-380-00	ELECT	1MF 20% 50V
R534	1-247-847-00	CARBON	4.7K 5% 1/6W	C014	1-123-356-00	ELECT	10MF 20% 16V
R535	1-247-809-00	CARBON	120 5% 1/6W	C015	1-129-794-00	FILM	0.0033MF 5% 100V
R536	1-247-839-00	CARBON	2.2K 5% 1/6W	C016	1-129-794-00	FILM	0.0033MF 5% 100V
R537	1-247-849-00	CARBON	5.6K 5% 1/6W	C017	1-123-318-00	ELECT	33MF 20% 16V
R538	1-247-826-00	CARBON	620 5% 1/6W	C018	1-130-491-00	MYLAR	0.047MF 5% 50V
R539	1-247-831-00	CARBON	1K 5% 1/6W	C019	1-161-021-00	CERAMIC	0.047MF 10% 25V
R540	1-247-819-00	CARBON	330 5% 1/6W	C020	1-123-333-00	ELECT	100MF 20% 16V
R541	1-247-783-00	CARBON	10 5% 1/6W	C501	1-123-318-00	ELECT	33MF 20% 16V
R542	1-247-855-00	CARBON	10K 5% 1/6W	C502	1-123-356-00	ELECT	10MF 20% 16V
R543	1-247-819-00	CARBON	330 5% 1/6W	C503	1-130-620-00	MYLAR	0.01MF 10% 50V
R544	1-247-783-00	CARBON	10 5% 1/6W	C504	1-130-620-00	MYLAR	0.01MF 10% 50V
R545	1-247-844-00	CARBON	3.6K 5% 1/6W	C505	1-123-305-00	ELECT	33MF 20% 10V
R546	1-247-844-00	CARBON	3.6K 5% 1/6W	C506	1-123-354-00	ELECT	3.3MF 20% 50V
R547	1-247-828-00	CARBON	750 5% 1/6W	C507	1-161-021-00	CERAMIC	0.047MF 20% 25V
R548	1-247-807-00	CARBON	100 5% 1/6W	C508	1-161-021-00	CERAMIC	0.047MF 10% 25V
R549	1-247-837-00	CARBON	1.8K 5% 1/6W	C509	1-161-021-00	CERAMIC	0.047MF 10% 25V
R550	1-247-837-00	CARBON	1.8K 5% 1/6W	C510	1-123-354-00	ELECT	3.3MF 20% 50V
R551	1-247-835-00	CARBON	1.5K 5% 1/6W	C511	1-123-354-00	ELECT	3.3MF 20% 50V
R552	1-247-835-00	CARBON	1.5K 5% 1/6W	C512	1-130-516-51	MYLAR	0.01MF 10% 50V
R553	1-247-837-00	CARBON	1.8K 5% 1/6W	C513	1-161-016-00	CERAMIC	0.018MF 10% 25V
R554	1-247-847-00	CARBON	4.7K 5% 1/6W	C514	1-161-016-00	CERAMIC	0.018MF 10% 25V
R555	1-247-847-00	CARBON	4.7K 5% 1/6W	C515	1-123-356-00	ELECT	10MF 20% 16V
R556	1-247-843-00	CARBON	3.3K 5% 1/6W	C516	1-161-016-00	CERAMIC	0.018MF 10% 25V
R557	1-247-815-00	CARBON	220 5% 1/6W	C517	1-161-013-00	CERAMIC	0.01MF 10% 25V
R558	1-247-828-00	CARBON	750 5% 1/6W	C518	1-123-330-00	ELECT	22MF 20% 16V
VARIABLE RESISTOR				C519	1-161-021-00	CERAMIC	0.047MF 10% 25V
RV501	1-228-920-00	RES, ADJ, CARBON	2.2K	C521	1-161-021-00	CERAMIC	0.047MF 10% 25V
RV502	1-228-920-00	RES, ADJ, CARBON	2.2K	C522	1-161-017-00	CERAMIC	0.022MF 10% 25V
RV503	1-228-920-00	RES, ADJ, CARBON	2.2K	C523	1-161-002-00	CERAMIC	0.0012MF 10% 25V
RV504	1-228-919-00	RES, ADJ, CARBON	1K	C524	1-123-306-00	ELECT	47MF 20% 10V
RV505	1-228-921-00	RES, ADJ, CARBON	4.7K	C525	1-161-016-00	CERAMIC	0.018MF 10% 25V
*****				C526	1-161-013-00	CERAMIC	0.01MF 10% 25V
▲ : A-6715-193-A SS-20 BOARD, COMPLETE				C527	1-123-318-00	ELECT	33MF 20% 16V
*****				C528	1-123-333-00	ELECT	100MF 20% 16V
▲ : 3-655-214-00 CLIP, CABLE				C529	1-161-021-00	CERAMIC	0.047MF 10% 25V
▲ : 3-682-606-00 CASE (MAIN), SHIELD, SS				C530	1-108-602-51	MYLAR	0.091MF 5% 50V
▲ : 3-682-607-00 CASE (LOWER), SHIELD, SS				C531	1-131-398-00	ELECT(SOLID)	0.22MF 10% 16V
CAPACITOR				C532	1-123-306-00	ELECT	47MF 20% 10V
C001	1-161-021-00	CERAMIC	0.047MF 10% 25V	C533	1-161-013-00	CERAMIC	0.01MF 10% 25V
C002	1-102-517-00	CERAMIC	30PF 5% 50V	C534	1-123-328-00	ELECT	4.7MF 20% 25V
C003	1-102-517-00	CERAMIC	30PF 5% 50V	C535	1-123-354-00	ELECT	3.3MF 20% 50V
C004	1-123-380-00	ELECT	1MF 20% 50V	C536	1-123-294-00	ELECT	47MF 20% 6.3V
C005	1-161-013-00	CERAMIC	0.01MF 10% 25V	C537	1-123-295-00	ELECT	100MF 20% 6.3V
C006	1-123-306-00	ELECT	47MF 20% 10V	C538	1-161-021-00	CERAMIC	0.047MF 10% 25V
C007	1-123-318-00	ELECT	33MF 20% 16V	C539	1-123-381-00	ELECT	2.2MF 20% 50V
				C540	1-123-381-00	ELECT	2.2MF 20% 50V
				C541	1-123-297-00	ELECT	330MF 20% 6.3V
				C542	1-102-106-00	CERAMIC	100PF 10% 50V

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C544	1-102-106-00	CERAMIC 100PF	10% 50V	DIODE			
C545	1-161-016-00	CERAMIC 0.018MF	10% 25V	D001	8-719-911-19	DIODE 1SS119	
C546	1-161-013-00	CERAMIC 0.01MF	10% 25V	D002	8-719-911-19	DIODE 1SS119	
C547	1-123-354-00	ELECT 3.3MF	20% 50V	D003	8-719-911-19	DIODE 1SS119	
C548	1-161-021-00	CERAMIC 0.047MF	10% 25V	D004	8-719-911-19	DIODE 1SS119	
C549	1-161-021-00	CERAMIC 0.047MF	10% 25V	D005	8-719-100-69	DIODE RD13EB3	
C550	1-123-306-00	ELECT 47MF	20% 10V	D008	8-719-911-19	DIODE 1SS119	
C551	1-131-375-00	TANTALUM 4.7MF	10% 10V	D009	8-719-911-19	DIODE 1SS119	
C552	1-131-375-00	TANTALUM 4.7MF	10% 10V	D010	8-719-911-19	DIODE 1SS119	
C553	1-130-499-51	MYLAR 0.22MF	5% 50V	D011	8-719-911-19	DIODE 1SS119	
C554	1-123-356-00	ELECT 10MF	20% 16V	D012	8-719-911-19	DIODE 1SS119	
C555	1-102-978-00	CERAMIC 220PF	5% 50V	D013	8-719-911-19	DIODE 1SS119	
C556	1-161-021-00	CERAMIC 0.047MF	10% 25V	D014	8-719-911-19	DIODE 1SS119	
C557	1-102-114-00	CERAMIC 470PF	10% 50V	D015	8-719-911-19	DIODE 1SS119	
C558	1-123-318-00	ELECT 33MF	20% 16V	D016	8-719-911-19	DIODE 1SS119	
C559	1-102-125-00	CERAMIC 0.0047MF	10% 50V	D017	8-719-911-19	DIODE 1SS119	
C560	1-123-380-00	ELECT 1MF	20% 50V	D018	8-719-911-19	DIODE 1SS119	
C561	1-123-381-00	ELECT 2.2MF	20% 50V	D019	8-719-911-19	DIODE 1SS119	
C562	1-161-021-00	CERAMIC 0.047MF	10% 25V	D020	8-719-911-19	DIODE 1SS119	
C563	1-124-429-00	ELECT 0.68MF	20% 50V	D022	8-719-911-19	DIODE 1SS119	
FILTER				D023	8-719-911-19	DIODE 1SS119	
CF001	1-527-822-00	OSCILLATOR, CERAMIC		D024	8-719-911-19	DIODE 1SS119	
CONNECTOR				D026	8-719-911-19	DIODE 1SS119	
CN001	1-560-893-00	PIN, CONNECTOR 5P		D027	8-719-911-19	DIODE 1SS119	
CN002	1-560-891-00	PIN, CONNECTOR 3P		D028	8-719-911-19	DIODE 1SS119	
CN003	1-560-899-00	PIN, CONNECTOR 11P		D029	8-719-911-19	DIODE 1SS119	
CN004	1-560-890-00	PIN, CONNECTOR 2P		D030	8-719-911-19	DIODE 1SS119	
CN005	1-560-890-00	PIN, CONNECTOR 2P		D501	8-719-100-57	DIODE RD10EB2	
CN006	1-560-890-00	PIN, CONNECTOR 2P		D505	8-719-911-19	DIODE 1SS119	
CN007	1-560-892-00	PIN, CONNECTOR 4P		D506	8-719-911-19	DIODE 1SS119	
CN008	1-560-890-00	PIN, CONNECTOR 2P		D515	8-719-911-19	DIODE 1SS119	
CN009	1-560-892-00	PIN, CONNECTOR 4P		D516	8-719-911-19	DIODE 1SS119	
CN010	1-560-891-00	PIN, CONNECTOR 3P		D518	8-719-911-19	DIODE 1SS119	
CN011	1-560-891-00	PIN, CONNECTOR 3P		D520	8-719-982-04	DIODE ERB81-004	
CN012	1-560-895-00	PIN, CONNECTOR 7P		D524	8-719-911-19	DIODE 1SS119	
CN013	1-560-890-00	PIN, CONNECTOR 2P		D525	8-719-911-19	DIODE 1SS119	
CN014	1-560-892-00	PIN, CONNECTOR 4P		D526	8-719-911-19	DIODE 1SS119	
CN015	1-560-890-00	PIN, CONNECTOR 2P		IC			
CN016	1-560-894-00	PIN, CONNECTOR 6P		IC001	8-759-909-27	IC MB88421-12M	
CN017	1-560-896-00	PIN, CONNECTOR 8P		IC002	8-759-800-72	IC LA7205	
CN018	1-560-892-00	PIN, CONNECTOR 4P		IC003	8-759-600-24	IC M54543L	
CN019	1-560-891-00	PIN, CONNECTOR 3P		IC004	8-759-908-40	IC EWA116	
CN020	1-560-891-00	PIN, CONNECTOR 3P		IC501	8-751-941-00	IC CX-1948-0	
CN021	1-560-891-00	PIN, CONNECTOR 3P		IC502	8-759-135-80	IC UPC358C	
CN022	1-560-892-00	PIN, CONNECTOR 4P		IC503	8-759-240-66	IC TC4066BP	
CN501	1-560-892-00	PIN, CONNECTOR 4P		IC504	8-759-132-40	IC UPC324C	
CN502	1-560-896-00	PIN, CONNECTOR 8P		IC505	8-759-132-40	IC UPC324C	
CN503	1-560-890-00	PIN, CONNECTOR 2P		IC506	8-759-240-51	IC TC4051BP	
CN504	1-560-467-00	PIN, CONNECTOR 4P		IC507	8-759-240-51	IC TC4051BP	
CN506	1-560-466-00	PIN, CONNECTOR 3P		IC508	8-759-240-53	IC TC4053BP	
CN507	1-560-467-00	PIN, CONNECTOR 4P		IC509	8-759-240-66	IC TC4066BP	

When indicating parts by reference number, please include the board name.

Ref.No. Part No. Description

IC510 8-759-135-80 IC UPC358C
 IC511 8-759-135-80 IC UPC358C
 IC512 8-759-904-94 IC TL494CN
 IC513 8-741-109-10 IC 8X-1091
 IC514 8-741-013-00 IC 8X-1013

COIL

L001 1-408-418-00 MICRO INDUCTOR 56UH
 L001 1-408-418-00 MICRO INDUCTOR 56UH
 L501 1-408-711-00 COIL, CHOKE
 L502 1-408-710-00 COIL, CHOKE

TRANSISTOR

Q001 8-7 29-900-61 TRANSISTOR DTA114ES
 Q005 8-7 29-900-61 TRANSISTOR DTA114ES
 Q006 8-7 29-900-61 TRANSISTOR DTA114ES
 Q007 8-7 29-900-61 TRANSISTOR DTA114ES
 Q008 8-7 29-900-61 TRANSISTOR DTA114ES

 Q009 8-7 29-900-61 TRANSISTOR DTA114ES
 Q010 8-7 29-900-61 TRANSISTOR DTA114ES
 Q011 8-7 29-900-61 TRANSISTOR DTA114ES
 Q012 8-7 29-900-61 TRANSISTOR DTA114ES
 Q013 8-7 29-900-89 TRANSISTOR DTC144ES

 Q014 =>8-7 29-204-83 TRANSISTOR 2SA1048-GR
 Q015 8-7 29-900-89 TRANSISTOR DTC144ES
 Q016 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q017 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q018 =>8-7 29-245-83 TRANSISTOR 2SC2458

 Q019 8-7 29-900-61 TRANSISTOR DTA114ES
 Q020 8-7 29-900-61 TRANSISTOR DTA114ES
 Q022 8-7 29-900-61 TRANSISTOR DTA114ES
 Q023 8-7 29-900-61 TRANSISTOR DTA114ES
 Q024 8-7 29-116-42 TRANSISTOR 2SD1164

 Q025 8-7 29-900-89 TRANSISTOR DTC144ES
 Q026 8-7 29-177-32 TRANSISTOR 2SD773
 Q027 8-7 29-900-89 TRANSISTOR DTC144ES
 Q028 8-7 29-116-42 TRANSISTOR 2SD1164
 Q029 8-7 29-900-89 TRANSISTOR DTC144ES

 Q030 8-7 29-177-32 TRANSISTOR 2SD773
 Q031 8-7 29-900-89 TRANSISTOR DTC144ES
 Q032 8-7 29-900-89 TRANSISTOR DTC144ES
 Q033 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q034 8-7 29-900-89 TRANSISTOR DTC144ES

 Q035 8-7 29-900-69 TRANSISTOR DTA144WS
 Q036 8-7 29-900-89 TRANSISTOR DTC144ES
 Q037 8-7 29-900-89 TRANSISTOR DTC144ES
 Q038 8-7 29-900-69 TRANSISTOR DTA144WS
 Q039 8-7 29-900-89 TRANSISTOR DTC144ES

 Q040 8-7 29-900-89 TRANSISTOR DTC144ES
 Q041 8-7 29-900-89 TRANSISTOR DTC144ES
 Q042 8-7 29-900-89 TRANSISTOR DTC144ES
 Q043 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q044 =>8-7 29-245-83 TRANSISTOR 2SC2458

Remark

Ref.No. Part No. Description

Q045 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q047 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q048 8-7 29-177-32 TRANSISTOR 2SD773
 Q049 8-7 29-900-89 TRANSISTOR DTC144ES
 Q050 8-7 29-900-89 TRANSISTOR DTC144ES

 Q051 8-7 29-900-89 TRANSISTOR DTC144ES
 Q052 8-7 29-900-74 TRANSISTOR DTC143TS
 Q053 =>8-7 29-204-83 TRANSISTOR 2SA1048-GR
 Q054 8-7 29-900-89 TRANSISTOR DTC144ES
 Q501 =>8-7 29-177-43 TRANSISTOR 2SD774

 Q502 8-7 29-900-89 TRANSISTOR DTC144ES
 Q505 8-7 29-900-89 TRANSISTOR DTC144ES
 Q506 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q507 8-7 29-900-89 TRANSISTOR DTC144ES
 Q508 =>8-7 29-245-83 TRANSISTOR 2SC2458

 Q509 =>8-7 29-204-83 TRANSISTOR 2SA1048-GR
 Q510 =>8-7 29-177-43 TRANSISTOR 2SD774
 Q511 =>8-7 29-204-83 TRANSISTOR 2SA1048-GR
 Q512 =>8-7 29-177-43 TRANSISTOR 2SD774
 Q513 8-7 29-900-89 TRANSISTOR DTC144ES

 Q515 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q516 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q517 =>8-7 29-113-33 TRANSISTOR 2SB733-4
 Q518 =>8-7 29-204-83 TRANSISTOR 2SA1048-GR
 Q519 =>8-7 29-245-83 TRANSISTOR 2SC2458

 Q525 8-7 29-900-89 TRANSISTOR DTC144ES
 Q526 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q530 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q531 8-7 29-900-89 TRANSISTOR DTC144ES
 Q532 8-7 29-900-89 TRANSISTOR DTC144ES

 Q533 =>8-7 29-245-83 TRANSISTOR 2SC2458
 Q534 8-7 29-900-89 TRANSISTOR DTC144ES

RESISTOR

R020 1-247-831-00 CARBON 1K 5% 1/6W
 R021 1-247-831-00 CARBON 1K 5% 1/6W
 R022 1-247-831-00 CARBON 1K 5% 1/6W
 R023 1-247-831-00 CARBON 1K 5% 1/6W
 R024 1-247-831-00 CARBON 1K 5% 1/6W

 R025 1-247-831-00 CARBON 1K 5% 1/6W
 R026 1-247-831-00 CARBON 1K 5% 1/6W
 R027 1-247-831-00 CARBON 1K 5% 1/6W
 R033 1-247-863-00 CARBON 22K 5% 1/6W
 R034 1-247-855-00 CARBON 10K 5% 1/6W

 R036 1-247-865-00 CARBON 27K 5% 1/6W
 R037 1-247-863-00 CARBON 22K 5% 1/6W
 R038 1-247-809-00 CARBON 120 5% 1/6W
 R039 1-247-829-00 CARBON 820 5% 1/6W
 R040 1-247-843-00 CARBON 3.3K 5% 1/6W

 R041 1-247-849-00 CARBON 5.6K 5% 1/6W
 R042 1-247-873-00 CARBON 56K 5% 1/6W
 R044 1-247-831-00 CARBON 1K 5% 1/6W
 R045 1-247-855-00 CARBON 10K 5% 1/6W

Remark

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R047	1-247-831-00	CARBON	1K 5% 1/6W	R136	1-247-863-00	CARBON	22K 5% 1/6W
R048	1-247-831-00	CARBON	1K 5% 1/6W	R501	1-246-444-00	CARBON	62 5% 1/4W
R049	1-247-831-00	CARBON	1K 5% 1/6W	R502	1-246-423-00	CARBON	8.2 5% 1/4W
R050	1-247-831-00	CARBON	1K 5% 1/6W	R503	1-247-821-00	CARBON	390 5% 1/6W
R051	1-247-831-00	CARBON	1K 5% 1/6W	R504	1-247-863-00	CARBON	22K 5% 1/6W
R057	1-247-831-00	CARBON	1K 5% 1/6W	R505	1-247-863-00	CARBON	22K 5% 1/6W
R064	1-247-827-00	CARBON	680 5% 1/6W	R506	1-247-855-00	CARBON	10K 5% 1/6W
R065	1-247-855-00	CARBON	10K 5% 1/6W	R508	1-247-851-00	CARBON	6.8K 5% 1/6W
R066	1-247-831-00	CARBON	1K 5% 1/6W	R509	1-247-873-00	CARBON	56K 5% 1/6W
R068	1-247-831-00	CARBON	1K 5% 1/6W	R510	1-247-859-00	CARBON	15K 5% 1/6W
R069	1-247-817-00	CARBON	270 5% 1/6W	R515	1-247-831-00	CARBON	1K 5% 1/6W
R070	1-247-831-00	CARBON	1K 5% 1/6W	R516	1-247-871-00	CARBON	47K 5% 1/6W
R072	1-247-831-00	CARBON	1K 5% 1/6W	R517	1-247-871-00	CARBON	47K 5% 1/6W
R073 A	1-212-366-61	METAL OXIDE	3.3 5% 1W F	R518	1-247-851-00	CARBON	6.8K 5% 1/6W
R074 A	1-246-981-11	CARBON	4.7 5% 1/6W F	R519	1-247-857-00	CARBON	12K 5% 1/6W
R075	1-247-855-00	CARBON	10K 5% 1/6W	R520	1-247-849-00	CARBON	5.6K 5% 1/6W
R077	1-247-855-00	CARBON	10K 5% 1/6W	R521	1-247-887-00	CARBON	220K 5% 1/6W
R078	1-247-855-00	CARBON	10K 5% 1/6W	R522	1-247-887-00	CARBON	220K 5% 1/6W
R080	1-247-855-00	CARBON	10K 5% 1/6W	R523	1-247-865-00	CARBON	27K 5% 1/6W
R082	1-247-855-00	CARBON	10K 5% 1/6W	R524	1-247-865-00	CARBON	27K 5% 1/6W
R083	1-247-855-00	CARBON	10K 5% 1/6W	R525	1-247-848-00	CARBON	5.1K 5% 1/6W
R090	1-247-808-00	CARBON	110 5% 1/6W	R526	1-247-867-00	CARBON	33K 5% 1/6W
R094	1-247-842-00	CARBON	3K 5% 1/6W	R527	1-247-867-00	CARBON	33K 5% 1/6W
R095	1-247-845-00	CARBON	3.9K 5% 1/6W	R528	1-247-867-00	CARBON	33K 5% 1/6W
R096	1-247-863-00	CARBON	22K 5% 1/6W	R529	1-247-835-00	CARBON	1.5K 5% 1/6W
R097	1-247-853-00	CARBON	8.2K 5% 1/6W	R530	1-247-847-00	CARBON	4.7K 5% 1/6W
R099	1-247-859-00	CARBON	15K 5% 1/6W	R531	1-247-879-00	CARBON	100K 5% 1/6W
R102	1-247-831-00	CARBON	1K 5% 1/6W	R532	1-247-895-00	CARBON	470K 5% 1/6W
R103	1-247-857-00	CARBON	12K 5% 1/6W	R535	1-215-397-00	METAL	100 1% 1/6W
R106	1-247-855-00	CARBON	10K 5% 1/6W	R538	1-247-831-00	CARBON	1K 5% 1/6W
R107	1-247-831-00	CARBON	1K 5% 1/6W	R539	1-247-838-00	CARBON	2K 5% 1/6W
R108	1-247-871-00	CARBON	47K 5% 1/6W	R540	1-247-855-00	CARBON	10K 5% 1/6W
R109	1-247-871-00	CARBON	47K 5% 1/6W	R541	1-247-855-00	CARBON	10K 5% 1/6W
R112	1-247-855-00	CARBON	10K 5% 1/6W	R542 A	1-246-981-11	CARBON	4.7 5% 1/6W F
R113	1-247-855-00	CARBON	10K 5% 1/6W	R543	1-247-872-00	CARBON	51K 5% 1/6W
R114	1-247-855-00	CARBON	10K 5% 1/6W	R544	1-247-863-00	CARBON	22K 5% 1/6W
R115 A	1-212-360-61	METAL OXIDE	1 5% 1W F	R545	1-247-843-00	CARBON	3.3K 5% 1/6W
R116	1-247-831-00	CARBON	1K 5% 1/6W	R546	1-247-843-00	CARBON	3.3K 5% 1/6W
R117	1-247-879-00	CARBON	100K 5% 1/6W	R547	1-247-837-00	CARBON	1.8K 5% 1/6W
R118	1-247-873-00	CARBON	56K 5% 1/6W	R548	1-247-900-00	CARBON	750K 5% 1/6W
R119	1-247-862-00	CARBON	20K 5% 1/6W	R549	1-247-847-00	CARBON	4.7K 5% 1/6W
R120	1-247-813-00	CARBON	180 5% 1/6W	R550	1-247-856-00	CARBON	11K 5% 1/6W
R121	1-247-823-00	CARBON	470 5% 1/6W	R551	1-247-883-00	CARBON	150K 5% 1/6W
R122	1-247-865-00	CARBON	27K 5% 1/6W	R552	1-247-883-00	CARBON	150K 5% 1/6W
R123	1-247-865-00	CARBON	27K 5% 1/6W	R553	1-247-857-00	CARBON	12K 5% 1/6W
R124	1-247-870-00	CARBON	43K 5% 1/6W	R554	1-247-847-00	CARBON	4.7K 5% 1/6W
R125	1-247-855-00	CARBON	10K 5% 1/6W	R555	1-247-867-00	CARBON	33K 5% 1/6W
R129	1-247-862-00	CARBON	20K 5% 1/6W	R556	1-247-881-00	CARBON	120K 5% 1/6W
R130	1-247-855-00	CARBON	10K 5% 1/6W	R557	1-247-883-00	CARBON	150K 5% 1/6W
R131	1-247-813-00	CARBON	180 5% 1/6W	R558	1-247-847-00	CARBON	4.7K 5% 1/6W
R132	1-247-888-00	CARBON	240K 5% 1/6W	R559	1-247-867-00	CARBON	33K 5% 1/6W
R134	1-247-831-00	CARBON	1K 5% 1/6W	R560	1-247-842-00	CARBON	3K 5% 1/6W
R135	1-247-863-00	CARBON	22K 5% 1/6W	R561	1-247-817-00	CARBON	270 5% 1/6W

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R562	1-247-849-00	CARBON	5.6K 5% 1/6W	R619	1-247-850-00	CARBON	6.2K 5% 1/6W
R563	1-247-839-00	CARBON	2.2K 5% 1/6W	R621	1-247-873-00	CARBON	56K 5% 1/6W
R564	1-247-818-00	CARBON	300 5% 1/6W	R622	1-247-871-00	CARBON	47K 5% 1/6W
R565	1-212-360-61	METAL OXIDE	1 5% 1W F	R623	1-247-873-00	CARBON	56K 5% 1/6W
R566	1-247-879-00	CARBON	100K 5% 1/6W	R629	1-247-855-00	CARBON	10K 5% 1/6W
R567	1-247-879-00	CARBON	100K 5% 1/6W	R630	1-247-879-00	CARBON	100K 5% 1/6W
R568	1-247-887-00	CARBON	220K 5% 1/6W	R631	1-247-879-00	CARBON	100K 5% 1/6W
R569	1-247-855-00	CARBON	10K 5% 1/6W	R632	1-247-883-00	CARBON	150K 5% 1/6W
R570	1-247-867-00	CARBON	33K 5% 1/6W	R633	1-247-883-00	CARBON	150K 5% 1/6W
R571	1-247-871-00	CARBON	47K 5% 1/6W	R634	1-247-867-00	CARBON	33K 5% 1/6W
R572	1-247-855-00	CARBON	10K 5% 1/6W	R635	1-247-871-00	CARBON	47K 5% 1/6W
R573	1-247-855-00	CARBON	10K 5% 1/6W	R637	1-247-873-00	CARBON	56K 5% 1/6W
R574	1-247-831-00	CARBON	1K 5% 1/6W	R638	1-247-867-00	CARBON	33K 5% 1/6W
R575	1-247-831-00	CARBON	1K 5% 1/6W	R639	1-247-868-00	CARBON	36K 5% 1/6W
R576	1-246-418-00	CARBON	5.1 5% 1/4W	R640	1-247-874-00	CARBON	62K 5% 1/6W
R577	1-247-831-00	CARBON	1K 5% 1/6W	R641	1-247-868-00	CARBON	36K 5% 1/6W
R578	1-247-859-00	CARBON	15K 5% 1/6W	R642	1-247-876-00	CARBON	75K 5% 1/6W
R579	1-247-831-00	CARBON	1K 5% 1/6W	R643	1-247-883-00	CARBON	150K 5% 1/6W
R580	1-247-873-00	CARBON	56K 5% 1/6W	R650	1-215-462-00	METAL	51K 1% 1/6W
R582	1-247-859-00	CARBON	15K 5% 1/6W	R651	1-215-417-31	METAL	680 1% 1/6W
R585	1-247-871-00	CARBON	47K 5% 1/6W	R652	1-215-443-00	METAL	8.2K 1% 1/6W
R586	1-247-831-00	CARBON	1K 5% 1/6W	R653	1-215-426-31	METAL	1.6K 1% 1/6W
R587	1-247-899-00	CARBON	680K 5% 1/6W	R654	1-247-855-00	CARBON	10K 5% 1/6W
R588	1-247-831-00	CARBON	1K 5% 1/6W	R655	1-215-456-00	METAL	30K 1% 1/6W
R589	1-247-855-00	CARBON	10K 5% 1/6W	R656	1-215-424-31	METAL	1.3K 1% 1/6W
R590	1-247-855-00	CARBON	10K 5% 1/6W	R657	1-247-857-00	CARBON	12K 5% 1/6W
R591	1-215-462-00	METAL	51K 1% 1/6W	R658	1-247-873-00	CARBON	56K 5% 1/6W
R592	1-247-859-00	CARBON	15K 5% 1/6W	R659	1-247-873-00	CARBON	56K 5% 1/6W
R593	1-247-835-00	CARBON	1.5K 5% 1/6W	R660	1-247-835-00	CARBON	1.5K 5% 1/6W
R594	1-247-883-00	CARBON	150K 5% 1/6W	R661	1-247-873-00	CARBON	56K 5% 1/6W
R595	1-247-879-00	CARBON	100K 5% 1/6W	R666	1-247-840-00	CARBON	2.4K 5% 1/6W
R596	1-247-903-00	CARBON	1M 5% 1/6W	R667	1-247-867-00	CARBON	33K 5% 1/6W
R597	1-247-859-00	CARBON	15K 5% 1/6W	R669	1-247-863-00	CARBON	22K 5% 1/6W
R598	1-247-843-00	CARBON	3.3K 5% 1/6W	R670	1-247-867-00	CARBON	33K 5% 1/6W
R599	1-247-889-00	CARBON	270K 5% 1/6W	R671	1-247-867-00	CARBON	33K 5% 1/6W
R600	1-215-413-00	METAL	470 1% 1/6W	R673	1-247-841-00	CARBON	2.7K 5% 1/6W
R601	1-247-867-00	CARBON	33K 5% 1/6W	R674	1-247-867-00	CARBON	33K 5% 1/6W
R602	1-247-867-00	CARBON	33K 5% 1/6W	R675	1-247-879-00	CARBON	100K 5% 1/6W
R603	1-247-895-00	CARBON	470K 5% 1/6W	R676	1-215-413-00	METAL	470 1% 1/6W
R604	1-247-840-00	CARBON	2.4K 5% 1/6W	R677	1-215-467-00	METAL	82K 1% 1/6W
R605	1-247-840-00	CARBON	2.4K 5% 1/6W	R679	1-247-863-00	CARBON	22K 5% 1/6W
R606	1-247-903-00	CARBON	1M 5% 1/6W	R680	1-247-855-00	CARBON	10K 5% 1/6W
R607	1-247-871-00	CARBON	47K 5% 1/6W	R681	1-247-863-00	CARBON	22K 5% 1/6W
R608	1-247-850-00	CARBON	6.2K 5% 1/6W	R683	1-247-839-00	CARBON	2.2K 5% 1/6W
R609	1-247-867-00	CARBON	33K 5% 1/6W	R684	1-247-867-00	CARBON	33K 5% 1/6W
R611	1-247-883-00	CARBON	150K 5% 1/6W	R685	1-247-861-00	CARBON	18K 5% 1/6W
R612	1-247-867-00	CARBON	33K 5% 1/6W	R686	1-247-844-00	CARBON	3.6K 5% 1/6W
R613	1-247-867-00	CARBON	33K 5% 1/6W	R687	1-247-871-00	CARBON	47K 5% 1/6W
R614	1-247-895-00	CARBON	470K 5% 1/6W	R690	1-215-437-00	METAL	4.7K 1% 1/6W
R615	1-247-840-00	CARBON	2.4K 5% 1/6W	R691	1-215-437-00	METAL	4.7K 1% 1/6W
R616	1-247-840-00	CARBON	2.4K 5% 1/6W	R692	1-215-437-00	METAL	4.7K 1% 1/6W
R617	1-247-903-00	CARBON	1M 5% 1/6W	R693	1-215-437-00	METAL	4.7K 1% 1/6W
R618	1-247-871-00	CARBON	47K 5% 1/6W	R696	1-212-356-61	METAL OXIDE	0.47 5% 1W F

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R697	1-247-867-00	CARBON 33K 5% 1/6W		CN503*:1-560-891-00	PIN, CONNECTOR 3P		
<u>VARIABLE RESISTOR</u>				CN504*:1-560-892-00	PIN, CONNECTOR 4P		
RV501	1-228-753-00	RES, ADJ, CARBON 470K		CN505*:1-560-892-00	PIN, CONNECTOR 4P		
RV503	1-228-996-00	RES, ADJ, METAL GLAZE 47K		<u>DIODE</u>			
RV504	1-228-996-00	RES, ADJ, METAL GLAZE 47K		D501	8-719-911-19	DIODE 1SS119	
RV505	1-228-996-00	RES, ADJ, METAL GLAZE 47K		D502	8-719-911-19	DIODE 1SS119	
RV506	1-228-996-00	RES, ADJ, METAL GLAZE 47K		D503	8-719-911-19	DIODE 1SS119	
RV507	1-228-996-00	RES, ADJ, METAL GLAZE 47K		D504	8-719-911-19	DIODE 1SS119	
RV508	1-228-996-00	RES, ADJ, METAL GLAZE 47K		<u>IC</u>			
RV511	1-228-991-00	RES, ADJ, METAL GLAZE 2.2K		IC501	8-759-979-16	IC CX-7916	
RV512	1-228-989-00	RES, ADJ, METAL GLAZE 470		IC504	8-759-240-11	IC TC4011BP	
RV513	1-228-989-00	RES, ADJ, METAL GLAZE 470		IC505	8-759-240-11	IC TC4011BP	
RV514	1-228-994-00	RES, ADJ, METAL GLAZE 10K		IC506	8-759-904-95	IC BA7007	
RV515	1-228-994-00	RES, ADJ, METAL GLAZE 10K		IC507	8-759-240-81	IC TC4081BP	
RV516	1-228-996-00	RES, ADJ, METAL GLAZE 47K		IC508	8-759-240-71	IC TC4071BP	
RV520	1-228-994-00	RES, ADJ, METAL GLAZE 10K		<u>VARIABLE COIL</u>			
RV521	1-228-994-00	RES, ADJ, METAL GLAZE 10K		LV501	1-407-291-00	MICRO INDUCTOR 15MMH	
<u>THERMISTOR</u>				<u>TRANSISTOR</u>			
TH001	1-800-202-XX	THERMISTOR S-10K		Q501 =>8-729-245-83	TRANSISTOR 2SC2458		
	1-800-202-XX	THERMISTOR S-10K		Q502 =>8-729-245-83	TRANSISTOR 2SC2458		
*****				Q503 =>8-729-204-83	TRANSISTOR 2SA1048-GR		
	♂:A-6715-194-A	SD-3 BOARD, COMPLETE		Q504 =>8-729-204-83	TRANSISTOR 2SA1048-GR		
*****				Q506 =>8-729-245-83	TRANSISTOR 2SC2458		
<u>CAPACITOR</u>				<u>RESISTOR</u>			
C501	1-123-356-00	ELECT 10MF 20% 16V		R501	1-247-867-00	CARBON 33K 5% 1/6W	
C502	1-123-380-00	ELECT 1MF 20% 50V		R502	1-247-855-00	CARBON 10K 5% 1/6W	
C503	1-161-036-00	CERAMIC 0.047MF 20% 25V		R503	1-247-855-00	CARBON 10K 5% 1/6W	
C504	1-123-356-00	ELECT 10MF 20% 16V		R504	1-247-865-00	CARBON 27K 5% 1/6W	
C505	1-161-015-00	CERAMIC 0.015MF 10% 25V		R505	1-247-835-00	CARBON 1.5K 5% 1/6W	
C506	1-161-015-00	CERAMIC 0.015MF 10% 25V		R506	1-247-839-00	CARBON 2.2K 5% 1/6W	
C507	1-161-015-00	CERAMIC 0.015MF 10% 25V		R507	1-247-839-00	CARBON 2.2K 5% 1/6W	
C509	1-161-036-00	CERAMIC 0.047MF 20% 25V		R508	1-247-855-00	CARBON 10K 5% 1/6W	
C510	1-102-823-00	CERAMIC 43PF 5% 50V		R509	1-247-867-00	CARBON 33K 5% 1/6W	
C511	1-161-032-00	CERAMIC 0.01MF 20% 25V		R510	1-247-855-00	CARBON 10K 5% 1/6W	
C512	1-123-381-00	ELECT 2.2MF 20% 50V		R511	1-247-867-00	CARBON 33K 5% 1/6W	
C513	1-108-589-00	MYLAR 0.027MF 5% 50V		R514	1-247-895-00	CARBON 470K 5% 1/6W	
C514	1-123-306-00	ELECT 47MF 20% 10V		R515	1-247-863-00	CARBON 22K 5% 1/6W	
C515	1-123-356-00	ELECT 10MF 20% 16V		R516	1-247-831-00	CARBON 1K 5% 1/6W	
C516	1-161-036-00	CERAMIC 0.047MF 20% 25V		R517	1-247-888-00	CARBON 240K 5% 1/6W	
C517	1-161-036-00	CERAMIC 0.047MF 20% 25V		R518	1-247-855-00	CARBON 10K 5% 1/6W	
C521	1-161-032-00	CERAMIC 0.01MF 20% 25V		R519	1-247-846-00	CARBON 4.3K 5% 1/6W	
<u>FILTER</u>				R520	1-247-847-00	CARBON 4.7K 5% 1/6W	
CF501	1-527-998-00	FILTER, CERAMIC		R525	1-247-871-00	CARBON 47K 5% 1/6W	
<u>CONNECTOR</u>				R526	1-247-871-00	CARBON 47K 5% 1/6W	
CN501*:1-560-898-00	PIN, CONNECTOR 10P			R527	1-247-871-00	CARBON 47K 5% 1/6W	
CN502*:1-560-892-00	PIN, CONNECTOR 4P			R528	1-247-870-00	CARBON 43K 5% 1/6W	
				R529	1-247-870-00	CARBON 43K 5% 1/6W	
				R530	1-247-870-00	CARBON 43K 5% 1/6W	

When indicating parts by reference number, please include the board name.

SD-3**TA-15**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R531	1-247-847-00	CARBON	4.7K 5% 1/6W	C030	1-123-351-00	ELECT	0.47 MF 20% 50V
R532	1-247-839-00	CARBON	2.2K 5% 1/6W	C031	1-101-888-00	CERAMIC	68PF 5% 50V
R539	1-247-863-00	CARBON	22K 5% 1/6W	C032	1-101-884-00	CERAMIC	56PF 5% 50V
				C033	1-123-318-00	ELECT	33MF 20% 16V
				C035	1-101-006-00	CERAMIC	0.047 MF 50V
				C036	1-123-356-00	ELECT	10MF 20% 16V
				C037	1-123-356-00	ELECT	10MF 20% 50V
				C038	1-123-298-00	ELECT	470MF 20% 6.3V
				C039	1-102-125-00	CERAMIC	0.0047 MF 10% 50V
				C040	1-102-125-00	CERAMIC	0.0047 MF 10% 50V
				C041	1-102-125-00	CERAMIC	0.0047 MF 10% 50V
				C042	1-102-125-00	CERAMIC	0.0047 MF 10% 50V
				C043	1-102-125-00	CERAMIC	0.0047 MF 10% 50V
				C045	1-123-318-00	ELECT	33MF 20% 16V
				C501	1-130-472-00	MYLAR	0.0012MF 5% 50V
				C502	1-130-472-00	MYLAR	0.0012MF 5% 50V
				C503	1-161-055-00	CERAMIC	0.022MF 10% 50V
				C504	1-123-356-00	ELECT	10MF 20% 16V
				C505	1-123-356-00	ELECT	10MF 20% 16V
				C506	1-123-307-00	ELECT	100MF 20% 10V
				C507	1-123-380-00	ELECT	1MF 20% 50V
				C508	1-123-332-00	ELECT	47MF 20% 16V
				C509	1-123-356-00	ELECT	10MF 20% 16V
				C510	1-123-380-00	ELECT	1MF 20% 50V
				C511	1-123-354-00	ELECT	3.3MF 20% 50V
				C512	1-130-480-00	MYLAR	0.0056MF 5% 50V
				C513	1-130-481-00	MYLAR	0.0068MF 5% 50V
				C514	1-123-380-00	ELECT	1MF 20% 50V
				C515	1-130-475-00	MYLAR	0.0022MF 5% 50V
				C516	1-161-316-00	CERAMIC	270PF 10% 50V
				C517	1-123-381-00	ELECT	2.2MF 20% 50V
				C518	1-107-166-00	MICA	62PF 5% 500V
				C519	1-123-356-00	ELECT	10MF 20% 16V
				C520	1-123-330-00	ELECT	22MF 20% 16V
				C521	1-130-485-00	MYLAR	0.015MF 5% 50V
				C522	1-123-356-00	ELECT	10MF 20% 16V
				C523	1-123-380-00	ELECT	1MF 20% 50V
				C524	1-123-380-00	ELECT	1MF 20% 50V
				C525	1-123-380-00	ELECT	1MF 20% 50V
				C526	1-123-380-00	ELECT	1MF 20% 50V
				C527	1-130-479-00	MYLAR	0.0047MF 5% 50V
				C528	1-130-477-00	MYLAR	0.0033MF 5% 50V
				C529	1-123-332-00	ELECT	47MF 20% 16V
				C530	1-136-051-00	FILM	0.0039MF 10% 630V
				C550	1-123-330-00	ELECT	22MF 20% 16V
				C551	1-130-491-00	MYLAR	0.047 MF 5% 50V
				C801	1-123-354-00	ELECT	3.3MF 20% 50V
				C803	1-125-299-00	*****	47000MF 5V
				C805	1-102-508-00	CERAMIC	10PF 0.5 PF 50V
				C806	1-123-318-00	ELECT	33MF 20% 16V
				C807	1-161-063-00	CERAMIC	0.1MF 10% 50V
				C808	1-161-063-00	CERAMIC	0.1MF 10% 50V
				C809	1-161-063-00	CERAMIC	0.1MF 10% 50V

The components identified by shading and mark **Δ** are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
<u>FILTER</u>							
CF001	1-404-134-00	TRAP, CERAMIC (5.5MHZ)		D030	8-719-100-55	DIODE RD9.1EB3	
CF003	1-527-263-00	CERAMIC FILTER (5.5MHZ)		D501	8-719-911-19	DIODE 1SS119	
CF005	1-404-134-00	TRAP, CERAMIC (5.5MHZ)		D502	8-719-911-19	DIODE 1SS119	
				D503	8-719-911-19	DIODE 1SS119	
<u>CONNECTOR</u>				D504	8-719-911-19	DIODE 1SS119	
CN001	1-560-893-00	PIN, CONNECTOR 5P		D502	8-719-911-19	DIODE 1SS119	
CN501	1-560-893-00	PIN, CONNECTOR 5P		D801	8-719-911-19	DIODE 1SS119	
CN502	1-560-894-00	PIN, CONNECTOR 6P		D802	8-719-911-19	DIODE 1SS119	
CN503	1-560-891-00	PIN, CONNECTOR 3P		D803	8-719-911-19	DIODE 1SS119	
CN504	1-560-893-00	PIN, CONNECTOR 5P		D804	8-719-812-41	DIODE TLR124	
CN801	1-560-892-00	PIN, CONNECTOR 4P		D805	=>8-719-168-07	DIODE RD6.8E-B	
CN802	1-560-896-00	PIN, CONNECTOR 8P		D806	8-719-911-19	DIODE 1SS119	
CN803	1-560-899-00	PIN, CONNECTOR 11P		D807	8-719-191-07	DIODE RD9.1E	
CN804	1-560-891-00	PIN, CONNECTOR 3P		D808	8-719-151-07	DIODE RD5.1E-B	
CN805	1-560-899-00	PIN, CONNECTOR 11P		D811	8-719-911-19	DIODE 1SS119	
CN806	1-560-893-00	PIN, CONNECTOR 5P		D812	8-719-911-19	DIODE 1SS119	
CN807	1-560-896-00	PIN, CONNECTOR 8P		D813	8-719-911-19	DIODE 1SS119	
CN808	1-560-897-00	PIN, CONNECTOR 9P		<u>IC</u>			
CN809	1-560-900-00	PIN, CONNECTOR 12P		IC001	8-758-852-00	IC CX-885B	
<u>TRIMMER</u>				IC002	8-759-600-44	IC M54836AP	
CV801	1-141-022-11	CAP, TRIMMER, CERAMIC		IC003	8-759-157-40	IC UPC574J	
<u>DIODE</u>				IC501	8-759-908-38	IC BA5112LS	
D001	8-719-911-19	DIODE 1SS119		IC502	8-759-101-73	IC UPC1513HA	
D002	8-719-911-19	DIODE 1SS119		IC802	8-759-240-81	IC TC4081BP	
D005	8-719-911-19	DIODE 1SS119		IC803	8-759-101-63	IC UPD7519G-033	
D006	8-719-911-19	DIODE 1SS119		<u>COIL</u>			
D007	8-719-911-19	DIODE 1SS119		L001	1-408-403-00	MICRO INDUCTOR 3.3UH	
D008	8-719-911-19	DIODE 1SS119		L002	1-408-434-00	MICRO INDUCTOR 2.2UH	
D009	8-719-911-19	DIODE 1SS119		L003	1-408-445-00	MICRO INDUCTOR 18UH	
D010	8-719-911-19	DIODE 1SS119		L006	1-408-448-00	MICRO INDUCTOR 33UH	
D011	8-719-911-19	DIODE 1SS119		L007	1-408-438-00	MICRO INDUCTOR 4.7UH	
D012	8-719-911-19	DIODE 1SS119		L010	1-408-408-00	MICRO INDUCTOR 8.2UH	
D013	8-719-911-19	DIODE 1SS119		L011	1-408-430-00	MICRO INDUCTOR 1UH	
D014	8-719-911-19	DIODE 1SS119		L501	1-407-718-00	MICRO INDUCTOR 1.2MMH	
D015	8-719-911-19	DIODE 1SS119		L502	1-407-510-00	MICRO INDUCTOR 33MMH	
D016	8-719-911-19	DIODE 1SS119		<u>FILTER</u>			
D017	8-719-911-19	DIODE 1SS119		LPF501	1-231-726-00	FILTER, LOWPASS	
D018	8-719-911-19	DIODE 1SS119		<u>VARIABLE COIL</u>			
D019	8-719-911-19	DIODE 1SS119		LV501	1-408-523-00	COIL, VARIABLE	
D020	8-719-911-19	DIODE 1SS119		<u>PRESET UNIT</u>			
D021	8-719-911-19	DIODE 1SS119		PS001	1-230-255-00	PRESET UNIT (8 GANG)	
D022	8-719-911-19	DIODE 1SS119		<u>TRANSISTOR</u>			
D023	8-719-911-19	DIODE 1SS119		Q001	=>8-729-204-83	TRANSISTOR 2SA1048-GR	
D024	8-719-911-19	DIODE 1SS119		Q002	=>8-729-204-83	TRANSISTOR 2SA1048-GR	
D025	8-719-911-19	DIODE 1SS119		Q003	=>8-729-204-83	TRANSISTOR 2SA1048-GR	
D026	8-719-911-19	DIODE 1SS119		Q004	8-765-300-00	TRANSISTOR 2SC2009	
D027	8-719-911-19	DIODE 1SS119					
D028	8-719-911-19	DIODE 1SS119					
D029	8-719-100-90	DIODE RD24EB2					

When indicating parts by reference number, please include the board name.

TA-15

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
Q005	=>8-7 29-245-83	TRANSISTOR 2SC2458		R021	1-247-879-00	CARBON 100K 5% 1/6W	
Q006	=>8-7 69-200-20	TRANSISTOR 2SK107-2		R022	1-247-879-00	CARBON 100K 5% 1/6W	
Q008	=>8-7 29-245-83	TRANSISTOR 2SC2458		R023	1-247-879-00	CARBON 100K 5% 1/6W	
Q009	=>8-7 29-245-83	TRANSISTOR 2SC2458		R024	1-247-879-00	CARBON 100K 5% 1/6W	
Q010	=>8-7 29-245-83	TRANSISTOR 2SC2458		R025	1-247-871-00	CARBON 47K 5% 1/6W	
Q011	=>8-7 29-245-83	TRANSISTOR 2SC2458		R026	1-247-863-00	CARBON 22K 5% 1/6W	
Q012	=>8-7 29-245-83	TRANSISTOR 2SC2458		R027	1-247-860-00	CARBON 16K 5% 1/6W	
Q013	=>8-7 29-245-83	TRANSISTOR 2SC2458		R028	1-247-881-00	CARBON 120K 5% 1/6W	
Q014	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR		R029	1-247-863-00	CARBON 22K 5% 1/6W	
Q015	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR		R030	1-247-863-00	CARBON 22K 5% 1/6W	
Q501	=>8-7 29-245-83	TRANSISTOR 2SC2458		R031	1-247-863-00	CARBON 22K 5% 1/6W	
Q502	8-7 61-710-00	TRANSISTOR 2SC1637-1		R032	1-247-863-00	CARBON 22K 5% 1/6W	
Q503	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR		R033	1-247-863-00	CARBON 22K 5% 1/6W	
Q504	8-7 29-900-36	TRANSISTOR DTC124ES		R034	1-247-863-00	CARBON 22K 5% 1/6W	
Q505	8-7 29-900-63	TRANSISTOR DTA124ES		R035	1-247-863-00	CARBON 22K 5% 1/6W	
Q506	=>8-7 29-177-43	TRANSISTOR 2SD774		R036	1-247-863-00	CARBON 22K 5% 1/6W	
Q508	8-7 29-900-63	TRANSISTOR DTA124ES		R037	1-247-869-00	CARBON 39K 5% 1/6W	
Q509	8-7 29-900-36	TRANSISTOR DTC124ES		R039	1-247-837-00	CARBON 1.8K 5% 1/6W	
Q510	8-7 29-900-80	TRANSISTOR DTC114ES		R040	1-247-839-00	CARBON 2.2K 5% 1/6W	
Q511	8-7 29-900-36	TRANSISTOR DTC124ES		R041	1-247-865-00	CARBON 27K 5% 1/6W	
Q512	8-7 29-900-61	TRANSISTOR DTA114ES		R042	1-247-831-00	CARBON 1K 5% 1/6W	
Q513	8-7 29-900-36	TRANSISTOR DTC124ES		R043	1-247-872-00	CARBON 51K 5% 1/6W	
Q514	8-7 29-900-36	TRANSISTOR DTC124ES		R044	1-247-864-00	CARBON 24K 5% 1/6W	
Q515	8-7 29-900-63	TRANSISTOR DTA124ES		R045	1-247-819-00	CARBON 33K 5% 1/6W	
Q516	8-7 29-900-36	TRANSISTOR DTC124ES		R046	1-247-807-00	CARBON 100 5% 1/6W	
Q520	8-7 29-178-54	TRANSISTOR 2SC2785-H		R047	1-247-857-00	CARBON 12K 5% 1/6W	
Q801	=>8-7 29-245-83	TRANSISTOR 2SC2458		R048	1-247-831-00	CARBON 1K 5% 1/6W	
Q802	8-7 29-965-22	TRANSISTOR 2SC1652		R050	1-247-815-00	CARBON 220 5% 1/6W	
Q803	8-7 29-965-22	TRANSISTOR 2SC1652		R051	1-247-829-00	CARBON 820 5% 1/6W	
Q805	8-7 29-965-22	TRANSISTOR 2SC1652		R052	1-247-869-00	CARBON 39K 5% 1/6W	
Q808	8-7 29-245-83	TRANSISTOR 2SC2458		R053	1-247-879-00	CARBON 100K 5% 1/6W	
Q809	8-7 29-245-83	TRANSISTOR 2SC2458		R055	1-247-891-00	CARBON 330K 5% 1/6W	
Q810	=>8-7 29-204-83	TRANSISTOR 2SA1048-GR		R056	1-247-859-00	CARBON 15K 5% 1/6W	
Q811	=>8-7 29-177-43	TRANSISTOR 2SD774		R057	1-247-873-00	CARBON 56K 5% 1/6W	
Q816	=>8-7 29-245-83	TRANSISTOR 2SC2458		R058	1-247-871-00	CARBON 47K 5% 1/6W	
Q817	=>8-7 29-245-83	TRANSISTOR 2SC2458		R059	1-247-843-00	CARBON 3.3K 5% 1/6W	
RESISTOR				R060	1-247-873-00	CARBON 56K 5% 1/6W	
R001	1-247-879-00	CARBON 100K 5% 1/6W		R061	1-247-821-00	CARBON 390 5% 1/6W	
R002	1-247-855-00	CARBON 10K 5% 1/6W		R062	1-247-831-00	CARBON 1K 5% 1/6W	
R003	1-247-855-00	CARBON 10K 5% 1/6W		R063	1-247-821-00	CARBON 390 5% 1/6W	
R004	1-247-855-00	CARBON 10K 5% 1/6W		R064	1-247-825-00	CARBON 560 5% 1/6W	
R005	1-247-855-00	CARBON 10K 5% 1/6W		R065	1-247-806-00	CARBON 91 5% 1/6W	
R006	1-247-855-00	CARBON 10K 5% 1/6W		R066	1-247-807-00	CARBON 100 5% 1/6W	
R007	1-247-855-00	CARBON 10K 5% 1/6W		R067	1-247-825-00	CARBON 560 5% 1/6W	
R011	1-247-855-00	CARBON 10K 5% 1/6W		R068	1-247-803-00	CARBON 68 5% 1/6W	
R012	1-247-895-00	CARBON 470K 5% 1/6W		R074	1-247-831-00	CARBON 1K 5% 1/6W	
R014	1-247-899-00	CARBON 680K 5% 1/6W		R075	1-247-843-00	CARBON 3.3K 5% 1/6W	
R016	1-247-883-00	CARBON 150K 5% 1/6W		R076	1-247-873-00	CARBON 39K 5% 1/6W	
R017	1-247-867-00	CARBON 33K 5% 1/6W		R077 Δ	1-246-998-00	CARBON 4.7 5% 1/6W F	
R018	1-247-871-00	CARBON 47K 5% 1/6W		R078 Δ	1-206-667-00	METAL OXIDE 1.3K 5% 2W F	
R019	1-247-871-00	CARBON 47K 5% 1/6W		R079	1-247-817-00	CARBON 270 5% 1/6W	
R020	1-247-895-00	CARBON 470K 5% 1/6W		R080	1-247-871-00	CARBON 47K 5% 1/6W	
				R081 Δ	1-247-033-00	CARBON 100 5% 1/8W F	

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R082	1-247-863-00	CARBON	22K 5% 1/6W	R558	1-247-843-00	CARBON	3.3K 5% 1/6W
R083	1-247-803-00	CARBON	68 5% 1/6W	R559	1-247-845-00	CARBON	3.9K 5% 1/6W
R084	1-247-847-00	CARBON	4.7K 5% 1/6W	R561	1-247-867-00	CARBON	33K 5% 1/6W
R085	1-247-845-00	CARBON	3.9K 5% 1/6W	R562	1-247-839-00	CARBON	2.2K 5% 1/6W
R086	1-247-824-00	CARBON	510 5% 1/6W	R803	1-247-863-00	CARBON	22K 5% 1/6W
R087	1-247-823-00	CARBON	470 5% 1/6W	R804	1-247-863-00	CARBON	22K 5% 1/6W
R088	1-247-815-00	CARBON	220 5% 1/6W	R805	1-247-855-00	CARBON	10K 5% 1/6W
R091	1-247-867-00	CARBON	33K 5% 1/6W	R808	1-247-855-00	CARBON	10K 5% 1/6W
R092	1-247-863-00	CARBON	22K 5% 1/6W	R809	1-246-473-00	CARBON	1K 5% 1/4W
R501	1-247-867-00	CARBON	33K 5% 1/6W	R810	1-247-855-00	CARBON	10K 5% 1/6W
R502	1-247-867-00	CARBON	33K 5% 1/6W	R811	1-246-473-00	CARBON	1K 5% 1/4W
R503	1-247-877-00	CARBON	82K 5% 1/6W	R814	1-247-855-00	CARBON	10K 5% 1/6W
R504	1-247-867-00	CARBON	33K 5% 1/6W	R815	1-246-473-00	CARBON	1K 5% 1/4W
R505	1-247-867-00	CARBON	33K 5% 1/6W	R816	1-246-497-00	CARBON	10K 5% 1/4W
R506	1-247-839-00	CARBON	2.2K 5% 1/6W	R817	1-246-497-00	CARBON	10K 5% 1/4W
R507	1-247-887-00	CARBON	220K 5% 1/6W	R818	1-246-497-00	CARBON	10K 5% 1/4W
R508	1-247-835-00	CARBON	1.5K 5% 1/6W	R819	1-246-497-00	CARBON	10K 5% 1/4W
R509	1-247-848-00	CARBON	5.1K 5% 1/6W	R820	1-246-497-00	CARBON	10K 5% 1/4W
R510	1-247-859-00	CARBON	15K 5% 1/6W	R821	1-246-473-00	CARBON	1K 5% 1/4W
R511	1-247-827-00	CARBON	680 5% 1/6W	R822	1-246-473-00	CARBON	1K 5% 1/4W
R512	1-247-844-00	CARBON	3.6K 5% 1/6W	R823	1-247-879-00	CARBON	100K 5% 1/6W
R513	1-247-863-00	CARBON	22K 5% 1/6W	R824	1-247-874-00	CARBON	62K 5% 1/6W
R514	1-247-859-00	CARBON	15K 5% 1/6W	R825	1-247-855-00	CARBON	10K 5% 1/6W
R515	1-247-855-00	CARBON	10K 5% 1/6W	R826	1-246-521-00	CARBON	100K 5% 1/4W
R517	1-247-847-00	CARBON	4.7K 5% 1/6W	R827	1-247-867-00	CARBON	33K 5% 1/6W
R518	1-247-855-00	CARBON	10K 5% 1/6W	R828	1-247-886-00	CARBON	200K 5% 1/6W
R519	1-247-863-00	CARBON	22K 5% 1/6W	R829	1-247-872-00	CARBON	51K 5% 1/6W
R520	1-247-811-00	CARBON	150 5% 1/6W	R830	1-247-874-00	CARBON	62K 5% 1/6W
R521	1-247-858-00	CARBON	13K 5% 1/6W	R831	1-247-868-00	CARBON	36K 5% 1/6W
R522	1-247-887-00	CARBON	220K 5% 1/6W	R832	1-247-869-00	CARBON	39K 5% 1/6W
R523	1-247-851-00	CARBON	6.8K 5% 1/6W	R833	1-247-879-00	CARBON	100K 5% 1/6W
R524	1-247-831-00	CARBON	1K 5% 1/6W	R834	1-247-903-00	CARBON	1M 5% 1/6W
R525	1-247-843-00	CARBON	3.3K 5% 1/6W	R835	1-246-509-00	CARBON	33K 5% 1/4W
R526	1-247-875-00	CARBON	68K 5% 1/6W	R836	1-246-505-00	CARBON	22K 5% 1/4W
R529	1-247-875-00	CARBON	68K 5% 1/6W	R837	1-247-827-00	CARBON	680 5% 1/6W
R530	1-247-855-00	CARBON	10K 5% 1/6W	R838	1-247-843-00	CARBON	3.3K 5% 1/6W
R531	1-212-869-00	FUSIBLE	33 5% 1/4W F	R839	1-247-863-00	CARBON	22K 5% 1/6W
R532	1-246-980-00	CARBON	3.3 5% 1/8W F	R840	1-247-879-00	CARBON	100K 5% 1/6W
R533	1-247-863-00	CARBON	22K 5% 1/6W	R841	1-247-855-00	CARBON	10K 5% 1/6W
R534	1-247-847-00	CARBON	4.7K 5% 1/6W	R842	1-247-855-00	CARBON	10K 5% 1/6W
R535	1-247-875-00	CARBON	68K 5% 1/6W	R843	1-247-855-00	CARBON	10K 5% 1/6W
R536	1-247-875-00	CARBON	68K 5% 1/6W	R844	1-247-863-00	CARBON	22K 5% 1/6W
R539	1-247-783-00	CARBON	10 5% 1/6W	R845	1-247-863-00	CARBON	10K 5% 1/6W
R540	1-247-819-00	CARBON	330 5% 1/6W	R846	1-247-863-00	CARBON	22K 5% 1/6W
R541	1-247-863-00	CARBON	22K 5% 1/6W	R847	1-247-863-00	CARBON	10K 5% 1/6W
R542	1-247-843-00	CARBON	3.3K 5% 1/6W	VARIABLE RESISTOR			
R543	1-247-863-00	CARBON	22K 5% 1/6W	RV001	1-228-747-00	RES, ADJ, CARBON 4.7K	
R544	1-247-859-00	CARBON	15K 5% 1/6W	RV002	1-228-747-00	RES, ADJ, CARBON 4.7K	
R550	1-247-863-00	CARBON	22K 5% 1/6W	RV501	1-224-256-XX	RES, ADJ, METAL GLAZE 220K	
R551	1-247-863-00	CARBON	22K 5% 1/6W	RV502	1-228-748-00	RES, ADJ, CARBON 10K	
R552	1-247-863-00	CARBON	22K 5% 1/6W	RV503	1-228-747-00	RES, ADJ, CARBON 4.7K	
R553	1-247-851-00	CARBON	6.8K 5% 1/6W				
R554	1-247-855-00	CARBON	10K 5% 1/6W				

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

TA-15

CS-3

CS-4

N

LM-8

RD-6

RD-7

TM-48

Ref.No. Part No. Description

FILTER

SF001 1-404-323-00 SAWF (38.9MHZ)

SWITCH

SW001 1-516-226-00 SLIDE SWITCH

TRANSFORMER

T002 1-404-404-00 COIL, VIF

T003 1-404-182-00 COIL, VIF

T004 1-404-389-00 COIL, SIF

T006 1-404-124-21 SIFT

T008 1-404-182-00 COIL, VIF

T501 1-433-237-00 TRANSFORMER, OSCILLATOR

CRYSTAL

X801 1-567-121-00 VIBRATOR, CRYSTAL

♣: 1-609-227-00 CS-3 BOARD
*****CONNECTOR

CN301♣: 1-564-029-00 PIN, CONNECTOR 4P

SWITCH

S301 1-554-241-00 SWITCH, LEVER

♣: 1-609-228-00 CS-4 BOARD
*****SWITCH

S302 1-554-241-00 SWITCH, LEVER

♣: 1-606-794-00 N BOARD
*****CAPACITOR

C001 1-123-617-00 ELECT 10MF 20% 16V

C002 1-123-617-00 ELECT 10MF 20% 16V

C003 1-123-617-00 ELECT 10MF 20% 16V

C004 1-161-019-00 CERAMIC 0.033MF 10% 25V

C005 1-108-567-00 MYLAR 0.0033MF 5% 50V

C006 1-123-821-00 ELECT 47 MF 20% 16V

DIODE

D001 8-719-110-32 DIODE PH302B

Remark

Ref.No. Part No.

Description

Remark

IC

IC001 8-759-113-73 IC UPC1373H

COIL

L001 1-404-310-00 COIL

♣: 1-605-071-00 LM-8 BOARD
*****CAPACITOR

C101 1-161-057-00 CERAMIC 0.033MF 10% 50V

C102 1-161-057-00 CERAMIC 0.033MF 10% 50V

COIL

L101 1-408-120-00 MICRO INDUCTOR 18UH

L102 1-408-120-00 MICRO INDUCTOR 18UH

RESISTOR

R101♣: 1-296-479-00 METAL OXIDE 5% 50V

♣: 1-610-401-00 RD-6 BOARD

♣: 3-681-157-00 HOLDER, RD

DIODE

D001 => 8-719-921-03 DIODE GP-2S02B

♣: 1-610-402-00 RD-7 BOARD
*****DIODE

D001 => 8-719-921-03 DIODE GP-2S02B

♣: 1-611-069-00 TM-48 BOARD

♣: 3-682-650-00 HOUSE, INDICATION LAMP

DIODE

D014 8-719-908-54 DIODE SLR-54VC3

D015 8-719-911-19 DIODE 1SS119

D016 8-719-911-19 DIODE 1SS119

D017 8-719-908-54 DIODE SLR-54VC3

D018 8-719-908-54 DIODE SLR-54VC3

D019 8-719-908-49 DIODE SLR-34VC3

The components identified by shading and mark ♣ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

TM-48

TM-49

TR-13

FU-19

<u>Ref.No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
D020	8-7 19-908-49	DIODE SLR-34YC3	
D021	8-7 19-911-19	DIODE 1SS119	
<u>INDICATOR TUBE</u>			
FL001	1-519-305-00	INDICATOR TUBE, FLUORESCENT	
<u>LAMP</u>			
PL001	1-518-544-11	LAMP, PILOT	
PL002	1-518-544-11	LAMP, PILOT	
PL003	1-518-544-11	LAMP, PILOT	
<u>TRANSISTOR</u>			
Q012	8-7 29-245-83	TRANSISTOR 2SC2458	
Q013	8-7 29-245-83	TRANSISTOR 2SC2458	
Q014	8-7 29-245-83	TRANSISTOR 2SC2458	
Q015	8-7 29-245-83	TRANSISTOR 2SC2458	
<u>RESISTOR</u>			
R043	1-247-819-00	CARBON	330 5% 1/6W
R044	1-247-863-00	CARBON	22K 5% 1/6W
R045	1-247-863-00	CARBON	22K 5% 1/6W
R046	1-247-819-00	CARBON	330 5% 1/6W
R047	1-247-819-00	CARBON	330 5% 1/6W
R048	1-247-819-00	CARBON	330 5% 1/6W
R049	1-247-863-00	CARBON	22K 5% 1/6W
R050	1-247-863-00	CARBON	22K 5% 1/6W
R051	1-247-863-00	CARBON	22K 5% 1/6W
R052	1-247-863-00	CARBON	22K 5% 1/6W
<u>SWITCH</u>			
S014	1-554-088-00	SWITCH, KEY BOARD	
S015	1-553-997-00	SWITCH, KEY BOARD	
S016	1-553-997-00	SWITCH, KEY BOARD	

♣:1-611-070-00	TM-49 BOARD		

<u>DIODE</u>			
D009	8-7 19-911-19	DIODE 1SS119	
D010	8-7 19-911-19	DIODE 1SS119	
D011	8-7 19-911-19	DIODE 1SS119	
<u>RESISTOR</u>			
R039	1-247-879-00	CARBON	100K 5% 1/6W
R040	1-247-879-00	CARBON	100K 5% 1/6W
R041	1-247-879-00	CARBON	100K 5% 1/6W
R042	1-247-879-00	CARBON	100K 5% 1/6W
<u>SWITCH</u>			
S001	1-553-997-00	SWITCH, KEY BOARD	
S002	1-553-997-00	SWITCH, KEY BOARD	
S003	1-553-997-00	SWITCH, KEY BOARD	

Ref.No.	Part No.	Description	Remark
S004	1-553-997-00	SWITCH, KEY BOARD	
S005	1-553-997-00	SWITCH, KEY BOARD	
S006	1-553-997-00	SWITCH, KEY BOARD	
S007	1-553-997-00	SWITCH, KEY BOARD	
S008	1-553-997-00	SWITCH, KEY BOARD	
S009	1-553-997-00	SWITCH, KEY BOARD	
S010	1-553-997-00	SWITCH, KEY BOARD	
S011	1-553-997-00	SWITCH, KEY BOARD	
S013	1-554-625-21	SWITCH, SLIDE	

♣:1-611-068-00	TR-13 BOARD		

<u>TRANSISTOR</u>			
Q001	8-7 19-316-16	TRANSISTOR 2SC1061	

♣:1-611-071-00	FU-19 BOARD		

♣:3-679-381-00	PLATE, LIGHT GUIDE		
♣:3-682-645-00	HOUSE, LAMP		
<u>DIODE</u>			
D001	8-7 19-908-53	DIODE SLR-54DC3	
D002	8-7 19-908-50	DIODE SLR-54MC3	
<u>LAMP</u>			
PL001	1-518-546-21	LAMP, PILOT	
PL002	1-518-546-41	LAMP, PILOT	
PL003	1-518-546-21	LAMP, PILOT	
PL004	1-518-546-31	LAMP, PILOT	
PL005	1-518-545-00	LAMP, PILOT	
<u>TRANSISTOR</u>			
Q001	=>8-7 29-245-83	TRANSISTOR 2SC2458	
Q002	=>8-7 29-245-83	TRANSISTOR 2SC2458	
Q003	=>8-7 29-245-83	TRANSISTOR 2SC2458	
Q004	=>8-7 29-245-83	TRANSISTOR 2SC2458	
<u>RESISTOR</u>			
R001	1-247-839-00	CARBON	2.2K 5% 1/6W
R002	1-247-839-00	CARBON	2.2K 5% 1/6W
R003	1-247-839-00	CARBON	2.2K 5% 1/6W
R004	1-247-839-00	CARBON	2.2K 5% 1/6W
R005	1-247-855-00	CARBON	10K 5% 1/6W
R006	1-247-855-00	CARBON	10K 5% 1/6W
R007	1-247-855-00	CARBON	10K 5% 1/6W
R008	1-247-855-00	CARBON	10K 5% 1/6W
R009	1-247-831-00	CARBON	1K 5% 1/6W
R010	1-246-467-00	CARBON	560 5% 1/4W
R011	1-247-831-00	CARBON	1K 5% 1/6W

When indicating parts by reference number, please include the board name.

FU-19

FU-20

VR-3

POWER BLOCK(SR-15)

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R012	1-247-822-00	CARBON 430 5% 1/6W		C612	1-124-162-00	ELECT 47MF	10V
R013	1-247-831-00	CARBON 1K 5% 1/6W		C621	1-108-413-00	POLYESTER 0.0022MF	200V
R014	1-247-831-00	CARBON 1K 5% 1/6W		C622	1-108-413-00	POLYESTER 0.0022MF	200V
<u>SWITCH</u>				C623	1-161-910-00	CERAMIC 390PF	500V
S001	1-553-997-00	SWITCH, KEY BOARD		C624	1-161-910-00	CERAMIC 390PF	500V
S002	1-553-997-00	SWITCH, KEY BOARD		C625	1-124-344-00	ELECT 22MF	100V
S003	1-553-997-00	SWITCH, KEY BOARD		C626	1-108-377-00	POLYESTER 0.01MF	100V
S004	1-553-997-00	SWITCH, KEY BOARD		C627	1-161-915-00	CERAMIC 0.001MF	500V
S005	1-553-997-00	SWITCH, KEY BOARD		C628	1-130-510-00	POLYESTER 0.01MF	50V
S006	1-553-997-00	SWITCH, KEY BOARD		C629	1-130-520-00	POLYESTER 0.022MF	50V
S007	1-553-997-00	SWITCH, KEY BOARD		C630	1-123-974-00	ELECT 2200MF	16V
*****				C631	1-123-985-00	ELECT KM 1000MF	16V
♣:1-611-072-00 FU-20 BOARD				C632	1-123-324-00	ELECT 1000MF	16V
*****				C633	1-123-323-00	ELECT 470MF	16V
<u>JACK</u>				C634	1-123-323-00	ELECT 470MF	16V
CNJ001	1-507-588-32	PIN JACK, 1P		C635	1-130-516-00	POLYESTER 0.01MF	50V
CNJ002	1-557-041-00	CONNECTOR ASSY, BNC		<u>CONNECTOR</u>			
CNJ003	1-507-840-00	JACK, MINIATURE		CN601♣	1-560-893-00	PIN CONNECTOR 5P	
<u>RESISTOR</u>				CN602♣	1-560-895-00	PIN CONNECTOR 7P	
R001	1-247-804-00	CARBON 75 5% 1/6W		CN603♣	1-560-891-00	PIN CONNECTOR 3P	
*****				CN604♣	1-560-891-00	PIN CONNECTOR 3P	
♣:1-611-073-00 VR-3 BOARD				CN605♣	1-560-891-00	PIN CONNECTOR 3P	
*****				CN606♣	1-560-891-00	PIN CONNECTOR 3P	
<u>VARIABLE RESISTOR</u>				CN607♣	1-560-896-00	PIN CONNECTOR 8P	
RV001	1-230-122-00	RES, VAR, CARBON 100K		<u>DIODE</u>			
RV002	1-226-234-00	RES, ADJ, CARBON 2K		D601♣	8-719-503-06	DIODE S3WB60Z	
*****				D602	8-719-101-47	DIODE RD4.7EL2	
<u>POWER BLOCK (SR-15)</u>				D603	8-719-101-47	DIODE RD4.7EL2	
*****				D621	8-719-908-00	DIODE ESAC33-02CS	
♣:1-413-161-11 POWER BLOCK (SR-15) INCLUDE D, C, R BOARDS				D622	8-719-900-93	DIODE V09C	
♣:1-611-044-00 M BOARD				D623	8-719-920-76	DIODE 1S2076	
<u>CAPACITOR</u>				D624	8-719-100-61	DIODE RD11EB2	
C601♣	1-110-085-00	METALLIZED-POLYESTER 0.22MF	AC250V	D625	8-719-923-76	DIODE 1S2076A	
C602♣	1-161-742-00	CERAMIC 0.0022MF	AC400V	D626	8-719-920-76	DIODE 1S2076	
C603♣	1-161-742-00	CERAMIC 0.0022MF	AC400V	D627	8-719-101-67	DIODE RD7.5EL2	
C604♣	1-161-742-00	CERAMIC 0.0022MF	AC400V	D628	8-719-100-23	DIODE RD4.3EB2	
C605♣	1-161-742-00	CERAMIC 0.0022MF	AC400V	D629	8-719-100-23	DIODE RD4.3EB2	
C606♣	1-161-743-00	CERAMIC 0.0047MF	AC400V	D630	8-719-920-76	DIODE 1S2076	
C607♣	1-161-743-00	CERAMIC 0.0047MF	AC400V	D631	8-719-100-30	DIODE RD5.1EB2	
C608♣	1-125-311-00	ELECT 220MF	400V	D632	8-719-920-76	DIODE 1S2076	
C609♣	1-124-023-00	ELECT 4.7MF	350V	D633	8-719-920-76	DIODE 1S2076	
C610♣	1-124-023-00	ELECT 4.7MF	350V	D634	8-719-815-55	DIODE 1S1555	
C611	1-124-162-00	ELECT 47MF	10V	<u>FUSE</u>			
				F601♣	1-532-237-11	TIME LAG 3.15A 250V	
				<u>COIL</u>			
				L601♣	1-421-481-21	LFT	
				L621	1-408-814-11	CHOKE	
				L622	1-421-421-21	100MH	

The components identified by shading and mark ♣ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

POWER BLOCK(SR-15)

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
L623	1-421-465-21	68MH		♣:A-4925-029-A	C BOARD, COMPLETE		
L624	1-421-459-21	5.6MH			*****		
L625	1-421-459-21	5.6MH					
<u>TRANSISTOR</u>				<u>CAPACITOR</u>			
Q601	♣-8-729-104-64	TRANSISTOR 2SC3158		C651	1-123-333-00	ELECT 100MF	16V
Q602	♣-8-729-104-64	TRANSISTOR 2SC3158		C652	1-130-027-00	POLY-PRO 0.0056MF	50V
Q603	8-729-102-03	TRANSISTOR 2SD1020		C653	1-130-022-00	POLY-PRO 0.022MF	50V
Q604	8-729-102-03	TRANSISTOR 2SD1020		C654	1-130-524-00	POLYESTER 0.047MF	50V
Q621	8-729-306-72	TRANSISTOR 2SD667A		C655	1-123-318-00	ELECT 33MF	16V
Q622	8-729-103-43	TRANSISTOR 2S8734		<u>DIODE</u>			
Q623	8-729-188-23	TRANSISTOR 2SD882		D651	8-719-200-01	DIODE 10E-1	
Q624	8-729-217-33	TRANSISTOR 2SC1173		D652	8-719-100-67	DIODE RD13EB1	
Q625	8-729-117-54	TRANSISTOR 2SA1175		<u>IC</u>			
<u>RESISTOR</u>				IC651	8-759-937-59	IC MB3759	
R601	♣-1-217-292-11	WIRE WOUND 3.3K 5W F		<u>RESISTOR</u>			
R602	1-244-929-00	CARBON 220K 1/2W		R651	1-246-485-00	CARBON 3.3K 1/4W	
R603	1-247-937-00	CARBON 15K 1/4W		R652	1-246-473-00	CARBON 1K 1/4W	
R604	1-244-929-00	CARBON 220K 1/2W		R653	1-246-491-00	CARBON 5.6K 1/4W	
R605	1-247-937-00	CARBON 15K 1/4W		R654	1-246-465-00	CARBON 470 1/4W	
R606	♣-1-212-945-00	FUSIBLE 3.3K 1/2W F		R655	1-246-487-00	CARBON 3.9K 1/4W	
R607	♣-1-212-945-00	FUSIBLE 3.3K 1/2W F		R656	1-246-481-00	CARBON 2.2K 1/4W	
R608	1-246-449-00	CARBON 100 1/4W		R656	1-246-480-00	CARBON 2K 1/4W	
R609	1-246-449-00	CARBON 100 1/4W		R656	1-246-482-00	CARBON 2.4K 1/4W	
R621	♣-1-206-475-00	METAL FILM 33 2W F		R657	1-246-503-00	CARBON 18K 1/4W	
R622	♣-1-247-923-00	CARBON 8.2 1/4W F		R658	1-246-509-00	CARBON 33K 1/4W	
R623	1-535-363-00	SHUNT 0.02 2W		R659	1-246-465-00	CARBON 470 1/4W	
R624	♣-1-212-151-00	METAL FILM 3.3K 1/2W F		R660	1-246-481-00	CARBON 2.2K 1/4W	
R625	1-246-473-00	CARBON 1K 1/4W		<u>VARIABLE RESISTOR</u>			
R626	1-246-485-00	CARBON 3.3K 1/4W		RV651	1-228-141-00	METAL GLAZE 500	
R627	1-246-485-00	CARBON 3.3K 1/4W					
R628	1-246-473-00	CARBON 1K 1/4W		♣:A-4925-030-A	D BOARD, COMPLETE		
R629	1-246-453-00	CARBON 150 1/4W			*****		
R630	1-246-429-00	CARBON 15 1/4W		<u>CAPACITOR</u>			
R631	♣-1-205-493-00	CARBON 3.3K 1/2W F		C671	1-123-332-00	ELECT 47MF	16V
R632	1-246-455-00	CARBON 180 1/4W		C672	1-123-333-00	ELECT 100MF	16V
R633	♣-1-205-731-00	CEMENT 1K 1/2W F		C673	1-130-508-00	POLYESTER 0.0022MF	50V
R634	1-246-469-00	CARBON 680 1/4W		C674	1-130-508-00	POLYESTER 0.0022MF	50V
R635	1-247-601-00	CARBON 5.1K 1/4W		C675	1-130-514-00	POLYESTER 0.0068MF	50V
R636	1-247-601-00	CARBON 5.1K 1/4W		C676	1-130-514-00	POLYESTER 0.0068MF	50V
R637	♣-1-246-449-00	CARBON 100 1/4W		C677	1-130-508-00	POLYESTER 0.0022MF	50V
<u>RELAY</u>				C678	1-130-508-00	POLYESTER 0.0022MF	50V
RY621	1-515-462-21	DC12V		C679	1-130-777-00	METAL-POLY 0.22MF	100V
<u>TRANSFORMER</u>				C680	1-130-777-00	METAL-POLY 0.22MF	100V
T601	♣-1-447-677-00	CONV.T		C681	1-130-777-00	METAL-POLY 0.22MF	100V
T602	1-437-120-00	DR.T		C682	1-130-777-00	METAL-POLY 0.22MF	100V
				C683	1-123-357-00	ELECT 22MF	50V

The components identified by shading and mark ♣ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

POWER BLOCK (SR-15S)

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C684	1-123-359-00	ELECT 47MF	50V	RESISTOR			
C685	1-123-357-00	ELECT 22MF	50V	R691	1-247-934-00	CARBON 8.2K	1/4W
C686	1-123-359-00	ELECT 47MF	50V	R692	1-247-600-00	CARBON 4.7K	1/4W
DIODE				R693	1-247-967-00	CARBON 13K	1/4W
D671	8-719-923-76	DIODE 1S2076A		R694	1-247-931-00	CARBON 1.5K	1/4W
D672	8-719-923-76	DIODE 1S2076A		R695	1-246-489-00	CARBON 4.7K	1/4W
D673	8-719-923-48	DIODE 1S2348H		R696	1-246-497-00	CARBON 10K	1/4W
D674	8-719-923-48	DIODE 1S2348H		R697	1-246-481-00	CARBON 2.2K	1/4W
COIL				R698	1-247-930-00	CARBON 1.2K	1/4W
L671	1-421-421-00			R699	1-246-484-00	CARBON 3K	1/4W
L672	1-408-457-00			VARIABLE RESISTOR			
L673	1-408-457-00			RV691	1-228-257-00	METAL-GLAZE 2K	
L674	1-408-439-00			*****			
TRANSISTOR				POWER BLOCK (SR-15S)			
Q671	8-729-177-00	TRANSISTOR 2SD774		*****			
Q672	8-729-177-00	TRANSISTOR 2SD774		9-983-637-01	INSULATOR SHEET A		
RESISTOR				9-983-638-01	INSULATOR SHEET B		
R671	1-247-863-00	CARBON 22K	1/6W	9-983-639-01	INSULATOR SHEET C		
R672	1-247-863-00	CARBON 22K	1/6W	9-983-640-01	INSULATOR SHEET D		
R673	1-247-807-00	CARBON 100	1/6W	▲:9-983-631-01	FUSE, HOLDER		
R674	1-247-807-00	CARBON 100	1/6W	▲:9-983-632-01	ANGLE		
R675	1-246-441-00	CARBON 47	1/4W	CAPACITOR			
R676	1-246-441-00	CARBON 47	1/4W	*****			
R677	1-246-505-00	CARBON 22K	1/4W	*****			
TRANSFORMER				*****			
T671	1-447-678-00	CONV.T		*****			
▲:A-4925-031-A R BOARD, COMPLETE				*****			
*****				*****			
CAPACITOR				C011	9-983-620-01	CERAMIC 0.001MF	1KV
C691	1-124-496-00	ELECT 22MF	35V	C012	1-108-591-00	FILM 0.033MF	50V
C692	1-123-308-00	ELECT 220MF	10V	C013	1-108-591-00	FILM 0.033MF	50V
C693	1-123-321-00	ELECT 220MF	16V	C014	1-123-323-00	ELECT 330MF	16V
DIODE				C015	9-983-621-01	CERAMIC 0.3MF	12V
D691	8-719-100-23	DIODE RD4.3EB2		C016	1-161-772-00	CERAMIC 0.1MF	16V
D692	8-719-815-55	DIODE 1S1555		C017	1-108-555-00	FILM 0.001MF	50V
D693	8-719-100-38	DIODE RD6.2EB2		C018	1-102-114-00	CERAMIC 0.00047MF	50V
TRANSISTOR				C019	1-108-579-00	FILM 0.01MF	50V
Q691	8-729-178-54	TRANSISTOR 2SC2785		C020	1-108-575-00	FILM 0.0068MF	50V
Q692	8-729-117-54	TRANSISTOR 2SA1175		C022	1-161-915-00	CERAMIC 0.001MF	500V
Q693	8-729-178-54	TRANSISTOR 2SC2785		C023	1-161-915-00	CERAMIC 0.001MF	500V
				C024	1-161-915-00	CERAMIC 0.001MF	500V
				C025	1-123-326-00	ELECT 3300MF	16V
				C026	1-123-323-00	ELECT 470MF	16V
				C027	1-123-325-00	ELECT 2200MF	16V

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

POWER BLOCK (SR-15S)

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C028	1-108-591-00	FILM 0.033MF	50V	<u>IC</u>			
C029	1-123-323-00	ELECT 470MF	16V	IC001	8-759-964-94	IC TL494CN	
C030	1-123-326-00	ELECT 3300MF	16V	IC002	9-983-616-01	IC UPC7809	
C031	1-161-772-00	CERAMIC 0.1MF	16V	IC003	8-759-171-05	IC UPC7805H	
C032	1-123-307-00	ELECT 100MF	10V	<u>COIL</u>			
C033	1-161-772-00	CERAMIC 0.1MF	16V	L001	9-983-601-01	LFT	
C034	1-123-307-00	ELECT 100MF	10V	L002	9-983-600-01	CHOCK	
				L003	9-983-604-01	23MH	
C050	1-123-320-00	ELECT 100MF	16V	L004	9-983-605-01	20MH	
C051	1-123-316-00	ELECT 10MF	16V	L005	9-983-612-01	300MH	
C052	1-108-575-00	FILM 0.0068MF	50V	<u>TRANSISTOR</u>			
C053	1-161-772-00	CERAMIC 0.1MF	16V	Q001	8-729-954-22	TRANSISTOR 2SC2452-04	
C054	1-161-772-00	CERAMIC 0.1MF	16V	Q002	8-729-954-22	TRANSISTOR 2SC2452-04	
C055	9-983-622-01	CERAMIC 100PF	500V	Q003	8-729-288-02	TRANSISTOR 2SD880	
C056	1-123-359-00	ELECT 47MF	50V	Q004	8-729-312-12	TRANSISTOR 2SC1213C	
C057	1-123-356-00	ELECT 10MF	50V	Q005	8-729-312-12	TRANSISTOR 2SC1213C	
C058	1-123-343-00	ELECT 33MF	35V	Q006 =>	8-729-374-02	TRANSISTOR 2SB740	
C059	1-123-343-00	ELECT 33MF	35V	Q050	9-983-607-01	TRANSISTOR 2SC3328	
<u>CONNECTOR</u>				Q051 =>	8-729-374-02	TRANSISTOR 2SB740	
CN601▲:	1-560-893-00	PIN CONNECTOR 5P		<u>RESISTOR</u>			
CN602▲:	1-560-895-00	PIN CONNECTOR 7P		R001▲	9-983-623-01	CEMENT	
CN603▲:	1-560-891-00	PIN CONNECTOR 3P		R002	1-246-473-00	CARBON 1K	1/4W
CN604▲:	1-560-891-00	PIN CONNECTOR 3P		R003	1-246-459-00	CARBON 270	1/4W
CN605▲:	1-560-891-00	PIN CONNECTOR 3P		R004	1-246-459-00	CARBON 270	1/4W
CN606▲:	1-560-891-00	PIN CONNECTOR 3P		R005	1-202-657-00	SOL ID 3.3M	1/2W
CN607▲:	1-560-896-00	PIN CONNECTOR 8P		R006	1-202-657-00	SOL ID 3.3M	1/2W
<u>DIODE</u>				R007	1-246-401-00	CARBON 1	1/4W
D001	9-983-609-01	DIODE RB156		R008	1-246-449-00	CARBON 100	1/4W
				R009	1-246-401-00	CARBON 1	1/4W
D005	=>8-719-815-55	DIODE 1S1585		R010	1-246-449-00	CARBON 100	1/4W
D006	=>8-719-815-55	DIODE 1S1585		<u>FUSE</u>			
D007	=>8-719-815-55	DIODE 1S1585		F011▲	1-532-203-11	FUSE 12A	
D008	8-719-912-52	DIODE ESAC25-02C		F012	1-246-401-00	CARBON 1	1/4W
D009	=>8-719-815-55	DIODE 1S1585		F013	1-244-885-00	CARBON 3.3K	1/2W
				F014	1-246-457-00	CARBON 220	1/4W
D050	=>8-719-815-55	DIODE 1S1585		F015	1-246-461-00	CARBON 330	1/4W
D051	9-983-610-01	DIODE ES1A		F016	1-246-461-00	CARBON 330	1/4W
D052	9-983-610-01	DIODE ES1A		F017	1-246-489-00	CARBON 4.7K	1/4W
ZD001	8-719-904-44	ZENER EQA02-10B		F018	1-246-455-00	CARBON 180	1/4W
ZD002	8-719-100-22	ZENER RD4.3EB1		F019	1-246-489-00	CARBON 4.7K	1/4W
ZD050	8-719-903-90	ZENER EQA02-05F		F020	1-246-491-00	CARBON 5.6K	1/4W
ZD051	8-719-904-68	ZENER EQA02-20B		F021	9-983-624-01	CARBON 2M	1/4W
<u>FUSE</u>				F022	1-246-489-00	CARBON 4.7K	1/4W
				F023	1-246-482-00	CARBON 2.4K	1/4W

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

POWER BLOCK (SR-15S)

Ref.No.	Part No.	Description	Remark
R024	1-246-515-00	CARBON 56K	1/4W
R025	1-246-491-00	CARBON 5.6K	1/4W
R026	1-246-485-00	CARBON 3.3K	1/4W
R027	1-246-501-00	CARBON 15K	1/4W
~~R028~~ A	~~1-212-881-00~~	~~FUSIBLE 300~~	~~1/4W~~
R029	9-983-625-01	0.025	
R030	1-246-451-00	CARBON 120	1/4W
~~R031~~ A	~~1-246-455-00~~	~~CARBON 180~~	~~1/4W~~
R032	1-246-503-00	CARBON 18K	1/4W
R033	1-246-465-00	CARBON 470	1/4W
R034	1-246-489-00	CARBON 4.7K	1/4W
R035	1-246-505-00	CARBON 22K	1/4W
R036	1-246-497-00	CARBON 10K	1/4W
R050	1-246-489-00	CARBON 4.7K	1/4W
R051	1-246-453-00	CARBON 150	1/4W
R052	1-246-453-00	CARBON 150	1/4W
R053	1-246-509-00	CARBON 33K	1/4W
R054	1-246-447-00	CARBON 82	1/4W
~~R055~~ A	~~1-212-849-00~~	~~FUSIBLE 4.7~~	~~1/4W~~
RELAY			
RL001	9-983-617-01	RELAY	
SCR			
SCR1	8-719-104-17	2P5M	
SPARK GAP			
SG001	9-983-628-01	SPARK GAP	
SG002	9-983-628-01	SPARK GAP	
TRANSFORMER			
~~T001~~ A	~~9-983-590-01~~	~~POWER~~	
T002	9-983-599-01	CONV.T	
T003	9-983-600-01	DR.T	
T050	9-983-601-01	CONV.T	
VARIABLE RESISTOR			
VR001	9-983-626-01	VARIABLE 1K	
VR002	9-983-627-01	VARIABLE 500	

MISCELLANEOUS			

♣ : A-4910-021-A R STATOR BOARD, COMPLETE (REEL MOTOR BOARD)			
A-6761-065-A ACE ASSY			
~~A~~	~~1-813-160-11~~	~~POWER BLOCK (SR-15S)~~	
~~A~~	~~1-813-161-11~~	~~POWER BLOCK (SR-15S)~~	
1-454-348-00 SOLENOID, BRAKE PLUNGER			
1-454-349-41 SOLENOID, PLUNGER			
1-464-250-00 SENSOR, T COIL			
1-464-286-00 SENSOR, S COIL			

Ref.No.	Part No.	Description	Remark
~~A~~	~~1-464-289-00~~	~~BOOSTER MIXER, RF MODULATOR~~	
~~A~~	~~1-534-817-12~~	~~POWER CORD~~	
1-541-163-00 MOTOR			
♣ : 1-555-716-00 CABLE, PIN			
1-561-468-00 SOCKET, CONNECTOR (DIN8P)			
8-825-508-10 HEAD, FE			
8-838-027-11 MOTOR, DC (BHF-1901B)			
S901	1-554-374-00	SWITCH, LEVER (REC PROOF)	
S902	1-554-374-00	SWITCH, LEVER (CASSETTE IN)	
S903	1-553-539-00	SWITCH, MICRO (LOADING END)	
S904	1-553-718-00	SWITCH, MICRO (UNLOADING END)	

ACCESSORIES AND PACKING MATERIALS


Part No.	Description	Remark
A-6765-205-A	COMMANDER ASSY (GOLD)	
A-6765-291-A	COMMANDER ASSY (SILVER)	
A-6765-292-A	COMMANDER ASSY (RED)	
3-682-684-01	INDIVIDUAL CARTON	
3-682-671-01	CUSHION (UPPER)	
3-682-672-01	CUSHION (LOWER)	
1-551-513-00	CABLE, COAXIAL ASSY	
1-556-893-00	CORD ASSY, COAXIAL	
3-656-301-00	SCREWDRIVER, CONTROL	
3-660-986-00	SHEET, PROTECTION	
3-671-873-00	CASE, ACCESSORY	
3-675-581-00	LID, CASE, ACCESSORY	
3-681-190-00	SHEET (LARGE), PROTECTION	
3-682-686-00	COVER, DUST	
3-701-007-00	BAND, BINDING	
3-773-586-41	MANUAL, INSTRUCTION	

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

RMT-218

SERVICE MANUAL



SPECIFICATIONS

Remote control system	Infrared control
Power requirements	3V dc, 2 IEC designation R6 batteries (size AA)
Dimensions	Approx. 65 × 20 × 153 mm (w/h/d) (2 ⁵ / ₈ × 1 ³ / ₁₆ × 6 ¹ / ₈ inches) incl. projecting parts and controls
Weight	Approx. 140 g (5 oz) incl. batteries


REMOTE COMMANDER
SONY®

REMOTE CONTROL OPERATION


You can control almost all the functions of this video cassette recorder from your armchair using the supplied Remote Commander.

BATTERY INSERTION

1 Open the lid.



2 Insert two IEC designation R6 batteries (size AA) with correct polarity.



3 Close the lid firmly.

Notes on the Remote Commander


- Avoid dropping foreign objects into the cabinet, particularly when replacing batteries.
- Keep the Commander away from extremely hot or humid places.
- Avoid mechanical shock to the commander.
- This Commander may be used only with this video cassette recorder.

Battery life

In normal operation, batteries will last for about six months. If the range of the Remote Commander becomes noticeably short, replace the batteries with new ones. When the batteries are exhausted, the remote function indicator will not light when the buttons on the Commander are pressed.

If the Commander is not to be used for a long period of time, remove the batteries to avoid possible damage from battery leakage.


PREPARATION



Notes

- There should be no obstacles between the Commander and the REMOTE SENSOR of the recorder.
- The shorter the distance between the Commander and the recorder, the wider the angle within which the recorder can be controlled.

FUNCTION OF THE BUTTONS



1 Remote function indicator

Lights up when any of the buttons on the Commander are pressed.

2 II PAUSE button

Press to stop the tape momentarily. To resume the previous mode, press it again.

3 ■ STOP button

Press to stop the tape.

4 ◀◀ REW button

Press to rewind the tape. Used also for reverse picture search operation during playback and for skip scan operation during rewinding.

5 ▶▶ FF button

Press to advance the tape rapidly. Used also for forward picture search operation during playback and for skip scan operation during fast forward mode.

6 ▶ PLAY button

Press to play the tape back.

7 Sliding cover

During playback, slide this cover over the record button to prevent accidental recording. During recording, slide this cover down to prevent accidental interruption of recording.

8 ● REC button

Press to start recording.

9 Channel select buttons

Press to select a channel to be viewed or to be recorded.

10 ON button

Press to turn the power on. To turn it off, press again.

OPERATION

Recording

1 Select the channel to be recorded with the channel select button.


2 Press the ● REC button. The recording will begin. To stop recording, press the ■ STOP button.

Playback


Press the ▶ PLAY button. Playback will begin.

To stop playback, press the ■ STOP button.

2. SCHEMATIC DIAGRAM



3. PRINTED WIRING BOARD



Note:

- All resistors are in ohms, 1/8 W unless otherwise noted.
- All capacitors are in μF (p:pF) unless otherwise noted. 50 V or less are not indicated except for electrolytic capacitors.
- — : B + bus.

The voltage value is measured using a digital tester (10 M Ω /V).

When indicating parts by reference number, please include the board name.


- ○ : indicates a lead wire mounted on the component side.
- ● : indicates a lead wire mounted on the printed side.
- — : Conductor side
- — : B + pattern

IR-14

5. EXPLODED VIEW

NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "♦" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
1	A-6765-205-A	COMMANDER ASSY (GOLD)	2-16	9	2-290-606-21	COVER, BATTERY (GOLD)	
	A-6765-291-A	COMMANDER ASSY (SILVER)	2-16		2-290-606-01	COVER, BATTERY (SILVER)	
	A-6765-292-A	COMMANDER ASSY (RED)	2-16		2-290-606-11	COVER, BATTERY (RED)	
2	2-290-603-00	CURSOR		10	2-290-611-21	CASE, LOWER (GOLD)	
3	X-2290-618-1	CASING ASSY (GOLD)			2-290-611-02	CASE, LOWER (SILVER)	
	X-2374-629-1	CASING ASSY (SILVER)			2-290-611-11	CASE, LOWER (RED)	
	X-2290-628-1	CASING ASSY (RED)		11	4-350-925-00	TERMINAL (C), BATTERY	
4	2-290-633-21	PUSH BUTTON (M)		12	2-290-601-02	TERMINAL (A), BATTERY	
5	2-290-632-21	PUSH BUTTON (L)		13	2-290-602-02	TERMINAL (B), BATTERY	
6	2-290-666-00	RUBBER (N), CONTACT		14	♦:1-610-258-00	IR-14 BOARD	
7	2-298-402-00	MIRROR		15	♦ 2-290-630-00	STOPPER, HOLDER	
8	2-290-608-02	PLATE, FROSTED		16	4-352-958-00	STRAP, HAND	

6. ELECTRICAL PARTS LIST

NOTE:

- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Items marked "♦" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- => Due to standardization, interchangeable replacements may be substituted for parts specified in the diagrams.

CAPACITORS
• MF : μ F, PF : μ F

RESISTORS
• All resistors are in ohms
• F : nonflammable

When indicating parts by reference number, please include the board name.

COILS
• MMH : mH, UH : μ H

Ref.No.	Part No.	Description	Remark
♦:1-610-258-00	IR-14 BOARD	*****	
1-102-108-00	CERAMIC	150PF 10% 50V	
1-247-771-00	CARBON	3.3 5% 1/6W	
1-247-797-00	CARBON	39 5% 1/6W	
1-247-825-00	CARBON	560 5% 1/6W	
1-527-476-00	OSCILLATOR, CERAMIC		
2-290-601-00	TERMINAL (A), BATTERY		
2-290-602-00	TERMINAL (B), BATTERY		
DIODE			
D001	8-719-193-03	DIODE SE303AX	
D002	8-719-193-03	DIODE SE303AX	
D003	8-719-901-44	DIODE SLP144B	
TRANSISTOR			
Q001	8-729-378-84	TRANSISTOR 2SD788	
IC			
IC001	8-759-600-07	IC M50119P	